

Piston Pin Diameter

 [Ford Ecat Electronic Parts Catalog](#)

NOTE: Refer to the appropriate Section 303-01 for the specification.

- 1. Measure the piston pin diameter in 2 directions at the points shown. Verify the diameter is within specification.

