


Fuel Pump Control Module

 [Ford Ecat Electronic Parts Catalog](#)



Item	Part Number	Description
1	—	Fuel Pump Control Module (FPCM) electrical connector (part of 14404)
2	W706027 W706027	FPCM bolt (2 required)
3	9345 9345	FPCM

Removal and Installation

1. Disconnect the Fuel Pump Control Module (FPCM) electrical connector.
2. Remove the 2 bolts and the FPCM .
 - To install, tighten to 9 Nm (80 lb-in).
3. To install, reverse the removal procedure.