

Dust Separator



Removal and Installation

1. **NOTE:** *The Evaporative Emission (EVAP) canister vent solenoid and dust separator are an assembly. This assembly is removed with the EVAP canister vent solenoid.*

For additional information, refer to Evaporative Emission Canister Vent Solenoid in this section.