


Parking Brake Cable — Rear, LH




Removal

NOTE: Removal steps in this procedure may contain installation details.


1. Release the parking brake cable tension. For additional information, refer to Parking Brake Cable Tension Release in this section.
- 2.




- 3.



- 4.



- 5.



Installation

- 1. To install, reverse the removal procedure.
 - Inspect the parking brake system for correct operation.