

Stability/Traction Control Switch



Removal and Installation

1. Refer to Passenger Air Bag Deactivation (PAD) Indicator in Section 501-20B.