


Steering Column Control Module (SCCM)

 [Ford Ecat Electronic Parts Catalog](#)



Item	Part Number	Description
1	—	Steering Column Control Module (SCCM) electrical connectors (3 required) (part of 14401)
2	W715057 W715057	SCCM bolts (3 required)
3	3F7913 3F791	SCCM

Removal and Installation

1. Remove the steering wheel rotation sensor. For additional information, refer to Section 206-09.
2. Disconnect the 3 Steering Column Control Module (SCCM) electrical connectors.
3. Remove the 3 screws and the SCCM .
 - To install, tighten to 2 Nm (18 lb-in).
4. To install, reverse the removal procedure.