



CAMSHAFT
POSITION 11
(CMP11) SENSOR
151-6




CAMSHAFT
POSITION 21
(CMP21) SENSOR
151-6




ELECTRONIC ENGINE CONTROLS



CAMSHAFT
POSITION 12
(CMP12) SENSOR
151-6



CAMSHAFT
POSITION 22
(CMP22) SENSOR
151-6



POWERTRAIN
CONTROL
MODULE (PCM)
151-2

