






TURBOCHARGER INTAKE
PRESSURE AND
TEMPERATURE
(TCIPT) SENSOR
151-5





POWERTRAIN
CONTROL
MODULE (PCM)
151-2



GENERATOR
CURRENT
SENSOR
151-3



TURBOCHARGER BOOST
PRESSURE/CHARGE
AIR COOLER
TEMPERATURE
(TCBP/CACT) SENSOR
151-1



AMBIENT AIR
TEMPERATURE
(AAT) SENSOR
151-2

