

Hot at all times

Hot in Start or Run

Hot at all times

BATTERY
JUNCTION
BOX (BJB)
11-1

BODY
CONTROL
MODULE (BCM)
11-3

POWER
DISTRIBUTION / BCM
13-29

POWERTRAIN
CONTROL
MODULE (PCM)
151-2



