

BODY CONTROL MODULE (BCM)

Fuse	Amps	Circuits protected
F1	30	Power window motor, left front
F2	15	Accessory Protocol Interface Module (APIM)
F3	30	Power window motor, right front
F4	10	Tool link reader, Battery saver relay, Dome lamp, front, Vanity mirror lamps, Interior map / lamps
F5	20	Seat control switch, driver side front with memory
F6	5	Not used
F7	7.5	Exterior rear view mirror switch, Driver Seat Module (DSM)
F8	10	Not used
F9	10	Front Display Interface Module (FDIM) - without navigation, Front Controls Interface Module (FCIM), Global Positioning System Module (GPSM) - with SYNC
F10	10	Run/acc relay
F11	10	Instrument Panel Cluster (IPC)
F12	15	High mounted stoplamp, Exterior rear view mirrors, Interior map / lamps, Dome lamp, front, Ambient lighting switch, Floor shifter, Upfitter switch, Hill descent control switch, Off-road mode switch, Overhead console switch assembly, Hazard/pad/traction switch, Headlamp switch, Instrument panel dimming switch, Audio Control Module (ACM), Mode Select Switch (MSS), Steering wheel switches, In-dash computer
F13	15	Park/turn lamps, Trailer tow relay, right turn, Park/stop/turn lamps, right rear
F14	15	Park/turn lamps, Trailer tow relay, left turn, Park/stop/turn lamps, left rear
F15	15	High mounted stoplamp, Reversing lamp relay, Reversing lamps, Auto-dimming interior mirror
F16	10	Right headlamp - low beam
F17	10	Left headlamp - low beam
F18	10	Brake shift interlock, Passive anti-theft transceiver, Floor shifter, Powertrain Control Module (PCM), Keyless entry keypad
F19	20	Audio Digital Signal Processing (DSP) module
F20	20	Door latch actuators
F21	10	Not used
F22	20	Horn relay
F23	15	Steering Column Control Module (SCCM)

Fuse	Amps	Circuits protected
F24	15	Data Link Connector (DLC), Steering Column Control Module (SCCM)
F25	15	Not used
F26	5	Tire Pressure Monitor (TPM) module
F27	20	Not used
F28	15	Ignition switch
F29	20	Audio Control Module (ACM), In-dash computer
F30	15	Side marker lamps, High mounted stoplamp, Park/stop/turn lamps, Front marker lamps
F31	5	Trailer Brake Control (TBC) module, Brake Pedal Position (BPP) switch, Powertrain Control Module (PCM)
F32	15	Roof opening panel module, Door lock switches, Master window control switch, Power window motors, Window control switch, passenger side, Electronic compass, Auto-dimming interior mirror, Heated seat switches
F33	10	Heated seat module
F34	10	Parking Aid Module (PAM), Video camera, Off-road mode switch, Mode Select Switch (MSS)
F35	5	Hill descent control switch
F36	10	Restraints Control Module (RCM)Occupant Classification System Module (OCSM)
F37	10	Trailer Brake Control (TBC) moduleTelematics module
F38	10	DC/AC inverter module, Audio Control Module (ACM), In-dash computer
F39	15	Headlamps - high beam
F40	10	Trailer tow relay, parking lamps, License plate lamps, Park/stop/turn lamps, Marker lamps
F41	7.5	Hazard/pad/traction switch, Upfitter switch
F42	5	Tow haul switch, Floor shifter
F43	10	Not used
F44	10	Not used
F45	5	Not used
F46	10	HVAC module
F47	15	Fog lamp relay, Exterior rear view mirror, passenger side Exterior rear view mirror, driver side
F48	30 c.b.	Master window control switch, Overhead console switch

