

Brake Shift Interlock Actuator — Floor Shift



Removal and Installation

NOTE: *The Brake Shift Interlock Actuator (BSIA) is not serviced separately. If a new BSIA is required, install a new floor shift selector lever assembly.*

1. For additional information, refer to Selector Lever — Floor Shift in this section.