Getting Started

This section covers the system requirements, installation instructions, and initial configuration steps to get started with the software.

System Requirements

• Operating System: Windows, macOS, or Linux

• RAM: 4 GB minimum

• Disk Space: 500 MB minimum

Installation Instructions

1. Download the installer from the official website.

2. Run the installer and follow the on-screen instructions.

Configuration

After installation, configure the software by following these steps: 1. Open the software. 2. Go to Settings. 3. Configure your preferences.