Computer Architecture

Courtsy L. N. Bhuyan

What is *Computer Architecture* Computer Architecture =

- Instruction Set Architecture (Opcodes,
 addressing modes, architected registers, IEEE
 floating point) +
- Organization (High Level aspects of computer's design i.e Memory System, bus structure, internal CPU where arithmetic, logic, branching and data transfers are implemented)+
- Hardware (Logic designs, Packaging technology, Clock rate, Supply voltage) + ...

Ref pp4 Patterson edition 2nd

Instruction Set


- 1) format
- length, encoding
- 2) operations
- operations, data types, number & kind of operands

Instruction Set

- 3) storage(Address modes)
- internal: accumulator, stack, general-purpose register
- memory: address size, addressing modes, alignments
- 4) control
- branch conditions, special support for procedures, predication

The Instruction Set: a Critical Interface

The actual programmer visible instruction set



Instruction-Set Processor Design

- Architecture (ISA) programmer/compiler view
 - "functional appearance to its immediate user/system programmer"
 - Opcodes, addressing modes, architected registers, IEEE floating point
- Implementation (µarchitecture) processor designer/view
 - "logical structure or organization that performs the architecture"
 - Pipelining, functional units, caches, physical registers
- Realization (chip) chip/system designer view
 - "physical structure that embodies the implementation"
 - Gates, cells, transistors, wires

Hardware

- Machine specifics:
 - Feature size (10 microns in 1971 to 0.18 microns in 2001)
 - Minimum size of a transistor or a wire in either the x or y dimension
 - Logic designs
 - Packaging technology
 - Clock rate
 - Supply voltage

• • •

Relationship Between the Three Aspects

- Processors having identical ISA may be very different in organization.
 - e.g. NEC VR 5432 and NEC VR 4122
- Processors with identical ISA and nearly identical organization are still not nearly identical.
 - e.g. Pentium II and Celeron are nearly identical but differ at clock rates and memory systems

> Architecture covers all three aspects.

Why Study Computer Architecture

- Aren't they fast enough already?
 - Are they?
 - Fast enough to do everything we will EVER want?
 - Al, protein sequencing, graphics
 - Is speed the only goal?
 - Power: heat dissipation + battery life
 - Cost
 - Reliability
 - Etc.

Answer #1: requirements are always changing

Example of Changing Designs

- Having, or not having caches
 - 1970: 10K transistors on a single chip, DRAM faster than logic → having a cache is bad
 - 1990: 1M transistors, logic is faster than DRAM → having a cache is good
 - 2000: 600M transistors -> multiple level caches and multiple CPUs
 - Will caches ever be a bad idea again?

Example of Changing Designs

- During 1970s, Mainframes and minicomputers dominated the industry
- Performance improved 25% to 30% per year due to improved
 - architectures and technological developments
- Late 1970s –microprocessor came (Improvement in ICTechnology) which led to higher rate of improvement – roughly 35% growth per year in performance

Design Changes contd..


- Microprocessor based computers became Commercially successful due to
 - Mass production of microprocessors
 - Portable object-code creation techniques (cross compilers:-each new architecture required time consuming assembly language programming previously)
 - Creation of standardized vendor-independent operating systems, such as UNIX and its clone, Linux

Design Changes contd..

- In the early 1980s, development of a new set of architectures
 - RISC (Reduced Instruction Set Computer)
 - RISC-based machines focused critical performance techniques
 - Exploitation of instruction level parallelism (pipelining, multiple instruction issue)
 - –Use of caches

Performance Growth in Perspective

- Same absolute increase in computing power
 - Big Bang 2001
 - -2001 2003
- 1971 2001: performance improved 35,000X!!!
 - What if cars or planes improved at this rate?



Since 2002, the limits of power, available instruction-level parallelism, and long memory latency have slowed uniprocessor performance recently, to about 20% per year.

Multiprocessor per Chip

- Instruction Level Parallelism ILP(started on Uniprocessor)
 - compiler and hardware used it
- Thread Level Parallelism(TLP) and Data Level Parallelism (DTL)
 - Explicitly parallel
 - Require programmer to write code to gain performance

Applications and Requirements

- Scientific/numerical: weather prediction, molecular modeling
 - Need: large memory, floating-point arithmetic
- Commercial: inventory, payroll, web serving, e-commerce
 - Need: integer arithmetic, high I/O
- Embedded: automobile engines, microwave, PDAs
 - Need: low power, low cost, interrupt driven
- Home computing: multimedia, games, entertainment
 - Need: high data bandwidth, graphics

Classes of Computers

- High performance (supercomputers-going towards cluster of Low cost/power)
 - Supercomputers Cray T-90
 - Massively parallel computers Cray T3E
- Balanced cost/performance (high reliability, scalability)
 - Workstations SPARCstations
 - Servers SGI Origin, UltraSPARC
 - High-end PCs Pentium quads
- Low cost/power
 - Low-end PCs, laptops, PDAs mobile Pentiums