ADB interface driver

Version 1.0

Version History


Version	Date	Handled by	Comments
V1.0	27-May-2019	ZL Chen	First version release.
V1.1	06-June-2019	ZL Chen	Join the Block Diagram.

Precondition Setting:

N/A

Please follow the implement as below:

Block Diagram:



Step 1: Please insert the micro USB to any computer and DUT (Android System).





Figure 1 Figure 2

Step 2: Install the ADB Interface driver by USB driver under the device manager. (Figure 2) The USB driver is under the installer folder. (\automation\installer\usb_driver)



Step 3: Open the "Developer options" in the Setting button and launch "USB debugging". (Figure 1)

