

CHAPTER FILE.CIO

SWAT+ INPUT DATA:

File management is performed with the master watershed file (file.cio). The master watershed file contains the file names for the simulation run.

The master watershed file is divided into several sections. A brief description of the variables in the master watershed file follows. They are grouped by section and listed in the order they appear within the file.

SWAT+ Model:

Over the past 20 years, the Soil and Water Assessment Tool (SWAT) has become widely used across the globe. The large numbers of applications across the globe have also revealed limitations and identified model development needs. Numerous additions and modifications of the model and its individual components have made the code increasingly difficult to manage and maintain. In order to face present and future challenges in water resources modeling SWAT code has undergone major modifications over the past few years, resulting in SWAT+, a completely revised version of the model. Even though the basic algorithms used to calculate the processes in the model have not changed, the structure and organization of both the code (object based) and the input files (relational based) have undergone considerable modification. This is expected to facilitate model maintenance, future code modifications, and foster collaboration with other researchers to integrate new science into SWAT modules. SWAT+ provides a more flexible spatial representation of interactions and processes within a watershed.

Descriptions of the SWAT+ input data files are listed and described in this document.

X.1 FILE.CIO

Variable name	Definition
TITLE	The first line of ‘file.cio’ is reserved for a description of the simulation run. The description may take up to 80 spaces. The description is optional, the line is required.

X.2 GENERAL INFORMATION

SIMULATION – The simulation section of file.cio contains filenames for the entire simulation run. The list of the filenames are listed below with a brief description of the inputs within each file.

TIME.SIM

The time simulation file includes the number of years to run the simulation and time step and is space delimited. Below is a sample TIME.SIM file:

time.sim:				
DAY_START	YRC_START	DAY_END	YRC_END	STEP
0	2006	0	2007	0

Variable name	Definition
TITLE	Description of the time.sim file (may be blank)
HEADER	
DAY_START	<p>Beginning Julian day of simulation.</p> <p>With this variable, SWAT is able to begin a simulation at any time of the year. If the variable is left blank or set to zero, the model starts the simulation on January 1st.</p> <p>Required.</p>
YRC_START	<p>Beginning year of simulation (for example, 1980).</p> <p>The value entered for this variable is not important unless measured data (e.g. weather) is used in the run. When measured data is used, the model uses YR_START to locate the beginning year within the data file.</p> <p>Required.</p>
DAY_END	<p>Ending Julian day of simulation.</p> <p>With this variable, SWAT is able to end a simulation at any time of the year. If the variable is left blank or set to zero, the model ends the simulation on December 31st.</p> <p>Required.</p>
YRC_END	Ending year of simulation
STEP	<p>Timestep of the simulation.</p> <p>0 = daily; 1=increment (12 hrs); 24=hourly; 96-15 mins; 1440 = minute)</p> <p>Required.</p>

PRINT.PRT

The print file controls the occurrence of the output files and is space delimited. Below is a sample PRINT.PRT file. Some pointers:

- The user will input the actual start and stop julian day for daily printing.
- NYSKIP will not print until NYSKIP is over.
- When time crosses the end of the year, the print will continue to increment the print INTERVAL.
- Daily printing of all files could cause very large output files (exceeding hard drive capabilities)

print.prt:	Output	print	settings		
NYSKIP	DAY_START	YRC_START	DAY_END	YRC_END	INTERVAL
0	0	0	0	0	1
AA_NUMINT					
0					
CSV	DB	NETCDF			
n	n	n			
SOIL	MGT	HYDCON	FDC		
n	n	n	n		
OBJECTS	DAILY	MONTHLY	YEARLY	AVANN	
basin_wb	y	n	n	y	
basin_nb	n	n	y	n	
basin_ls	y	n	n	n	
basin_pw	n	y	n	n	
basin_aqu	n	n	n	n	
basin_res	n	n	n	n	
basin_cha	n	n	n	n	
basin_sd_cha	y	n	n	y	
basin_psc	n	n	n	n	
region_wb	n	n	n	n	
region_nb	n	n	n	n	
region_ls	n	n	n	n	
region_pw	n	n	n	n	
region_aqu	n	n	n	n	
region_res	n	n	n	n	
region_cha	n	n	n	n	
region_sd_cha	n	n	n	n	
region_psc	n	n	n	n	
lsunit_wb	n	n	n	n	
lsunit_nb	n	n	n	n	
lsunit_ls	n	n	n	n	
lsunit_pw	n	n	n	n	
hru_wb	n	n	y	n	
hru_nb	n	y	n	n	
hru_ls	n	y	n	n	
hru_pw	n	n	n	y	
hru-lte_wb	n	n	n	n	
hru-lte_nb	n	n	n	n	
hru-lte_ls	n	n	n	n	
hru-lte_pw	n	n	n	n	
channel	n	n	n	n	
channel_sd	y	n	n	n	
aquifer	n	n	n	n	

reservoir	n	n	n	n	
recall	n	n	n	n	
hyd	y	n	n	n	
ru	n	n	n	n	
pest	n	n	n	n	

Variable name	Definition
TITLE	Description of the print.prt file
HEADER	Headings
NYSKIP	<p>Number of years to <i>not</i> print output.</p> <p>The options are</p> <ul style="list-style-type: none"> 0 print output for all years of the simulation 1 print output after the first year of simulation 2 print output after the second year of simulation ↓ nbyr no output will be printed <p>Some simulations will need a warm-up or equilibration period. The use of an equilibration period becomes more important as the simulation period of interest shortens. For 30-year simulations, an equilibrium period is optional. For a simulation covering 5 years or less, an equilibrium period is recommended. An equilibration period of one year is usually adequate to get the hydrologic cycle fully operational.</p> <p>Examples: If NYSKIP =2, the model will skip printing the first two years regardless of the starting year. In other words, if YRC_START = 2000, we start printing in 2002. If YRC_START = 2005, printing starts in 2007.</p> <p>Notes: The daily print start and end time has nothing to do with NYSKIP. If the daily print time is skipped, it simply won't print the daily output.</p> <p>The start year of printing is $\max(YRC_START+NYSKIP)$.</p>
DAY_START	Beginning Julian day of simulation to start printing output files for daily printing only
YRC_START	Beginning year of simulation to start printing files.
DAY_END	Ending Julian day of simulation to stop printing output files for daily printing only
YRC_END	Ending year of simulation to stop printing output files.

INTERVAL	Daily print within the period
	Specifies the interval within the specified printing time (i.e., INTERVAL =2) will print every other day.
HEADER	Headings
AA_NUMINT	Number of print intervals for ave annual output Example: If AA_NUMINT == 1955 1965 1975, Average annual results will be printed for the time periods ending in 1955, 1965, 1975. Leaving the first number zero on this line will print average annual for the entire period (after NYSKIP).
AA_YEARS	End years for aveage annual output
HEADER	Header
CSVOUT	Code to print .csv files n=no print; y = print
DBOUT	Code to print database (db) files n=no print; y = print (not currently active)
CDFOUT	Code to print netcdf (cdf) files n=no print; y = print (not currently active)
HEADER	Header
SNUTC	Soil nutrients carbon output file; input should be character - d(daily; m/(monthly); y(yearly); aa(ave annual);
MGTOUT	Management output file (print codes apply) (mgt.out)
HYDCON	Hydrograph connect output file (hydcon.out)
FDCOUT	Flow duration curve output file n=no print; avann=print
HEADER	Header. All of the following codes are entered as : 'y' (yes) or 'n' (no) to print on a daily, monthly, yearly or avann timestep.
WB_BSN	Water balance BASIN output variables
NB_BSN	Nutrient balance BASIN output variables
LS_BSN	Losses BASIN output variables
PW_BSN	Plant weather BASIN output variables
AQU_BSN	Aquifer BASIN output variables
RES_BSN	Reservoir BASIN output file variables
CHAN_BSN	Channel BASIN output file variables
SD_CHAN_BSN	CHANDEG BASIN output file variables
RECALL_BSN	Point source BASIN output file variables
WB_REG	Water balance REGION output variables
NB_REG	Nutrient balance REGION output variables
LS_REG	Losses REGION output variables
PW_REG	Plant weather REGION output variables
AQU_REG	Aquifer REGION output variables

RES_REG	Reservoir REGION output variables
CHAN_REG	Channel REGION output variables
SD_CHAN_REG	SWATDEG Channel REGION output variables
RECALL_REG	Point source REGION output variables
WB_SUB	Water balance ROUTING UNIT output variables
NB_SUB	Nutrient balance ROUTING UNIT output variables
LS_SUB	Losses ROUTING UNIT output variables
PW_SUB	Plant weather ROUTING UNIT output variables
WB_HRU	Water balance HRU output variables
NB_HRU	Nutrient balance HRU output variables
LS_HRU	Losses HRU output variables
PW_HRU	Plant weather HRU output variables
WB_SD	Water balance HRU-LTE output variables
NB_SD	Nutrient balance HRU-LTE output variables
LS_SD	Losses HRU-LTE output variables
PW_SD	Plant weather HRU-LTE output variables
CHAN	Channel output variables
SD_CHAN	SWAT DEG (lte) channel output variables
AQU	Aquifer output variables
RES	Reservoir output variables
RECALL	Recall output variables
HYD	Hydin output and hydout_output variables
RU	Routing Unit output variables
PEST	Pesticide constituents outputs

OBJECT.PRT

The object print file allows the user to define output and is space delimited. Below is a sample OBJECT.PRT file:

object.prt:	NUMB	OBTYP	OBTYPNO	HYDTYP	FILENAME
	1	sdc	1	tot	two_stage.out

Variable name	Definition
TITLE	Description of the object print file
HEADER	Header
NUMB	The sequential number
OBTYP	Type of object to print (cha, res...)
OBTYPNO	Object type number
HYDTYP	Hydrograph type to print
FILENAME	Filename of output file (user defined).

OBJECT.CNT

The object count file contains the total counts for the watershed simulation and is space delimited. Below is a sample OBJECT.CNT file:

object.cnt:	NAME	AREA_LS_HA	AREA_TOT_HA	OBJ	HRU	LTE	RU	MODFLOW	AQU	CHA	RES	REC	EXCO	DR	CANAL	PUMP	OUT	CHANDEG	2DAQU
2_stage		30	33	3	0	0	0	0	0	0	0	1	1	1	0	0	0	0	

Variable name	Definition
TITLE	Description of the object count file
HEADER	Header to describe the following inputs; Not used in model;
NAME	Name of the watershed
AREA_LS_HA	Area of the landscape units (ha)
AREA_TOT_HA	Total area of the watershed (ha)
OBJS	Total number of objects (sum of all following objects)
HRU	Total number of HRU's
HRU_LTE	Total number of HRU LTE (SWAT-DEG)
RU	Total number of routing units
MODFLOW	Total number of modflow
AQU	Total number of aquifers
CHAN	Total number of channels
RES	Total number of reservoirs
RECALL	Total number of recdays
EXCO	Total number of export coefficients
DR	Total number of delivery ratios
CANAL	Total number of canals
PUMP	Total number of pumps
OUTLET	Total number of outlets
CHANDEG	Total number of LTE channels (SWAT-DEG)
AQU2D	Total number of 2D aquifers
HERD	Total number of herds (not used at this time)
WRO	Total number of water right objects (not used at this time)

CONSTITUENTS.CS

The CONSTITUENTS.CS file contains the input variables for the pesticide constituents. Below is a sample CONSTITUENTS.CS file:

constituents.cs				
4	!pesticides			
aatrex	banvel	prowl	roundup	
2	!pathogens			
fecal_col_form	e_coli			
1	!metals			
mercury				
2	!salts			
sodium	magnesium			

Variable name	Definition
TITLE	The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
NUM_PESTS	Number of pesticides simulated
NAME	Pesticide names (for each NUM_PESTS)
NUM_PATHS	Number of pathogens simulated
NAME	Pathogen names (for each NUM_PATHS)
NUM_METALS	Number of heavy metals simulated
NAME	Heavy metal names (for each NUM_METALS)
NUM_SALTS	Number of salts simulated

BASIN – General watershed attributes are defined in the basin input file. These attributes control a diversity of physical processes at the watershed level. The interfaces will automatically set these parameters to the “default” or recommended values listed in the variable documentation. Users can use the default values or change them to better reflect what is happening in a given watershed. Variables governing bacteria or pesticide transport need to be initialized only if these processes are being modeled in the watershed. Even if nutrients are not being studied in a watershed, some attention must be paid to these variables because nutrient cycling impacts plant growth which in turn affects the hydrologic cycle.

CODES.BSN

Below is a partial sample CODES.BSN FILE:

codes.bsn:	Basin contro			-																				
PETFILE	WWQFILE	PET	EVENT	-	CRK	SUBWQ	SED_DET	RTE	DEG	WQ	RTPEST	CN	CFAC	CSWAT	BF_FLG	UHYD	SED_CH	TDRN	WTDN	P_MODEL	ABSTR	ATMO	SMAX	I_SUBHW
test.pet	test.wwq	1	0	0	1	1	1	0	0	0	0	0	0	2	0	0	0	0	0	0	0	0	0	0

Variable name	Definition
----------------------	-------------------

TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank.
	Optional.
HEADER	Headers for the codes.bsn file.
PETFILE	Potential ET filename
WWQFILE	Watershed stream water quality filename
PET	Potential evapotranspiration (PET) method. There are four options for potential ET calculations: 0 Priestley-Taylor method 1 Penman/Monteith method 2 Hargreaves method 3 read in potential ET values
	Numerous methods exist to calculate potential evapotranspiration. Three of the most popular or widely-used are included in SWAT. However, if a method other than Priestley-Taylor, Penman/Monteith, or Hargreaves is recommended for the area in which the watershed is located, the user can calculate daily PET values with the recommended method and import them into SWAT. A discussion of Priestley-Taylor, Penman-Monteith and Hargreaves PET methods is found in Chapter 2:2 of the theoretical documentation.
	Required.
EVENT	Rainfall/runoff/routing option: 0 daily rainfall/curve number runoff/daily routing 1 sub-daily rainfall/Green & Ampt infiltration/sub-daily routing
	Option 0 is the default option.
	Required.
CRK	Crack flow code. There are two options: 0 do not model crack flow in soil 1 model crack flow in soil
	Crack, or bypass, flow is a newer feature in SWAT and has been tested on a limited basis in simulations of some areas in Texas. This type of flow should be modeled only on soils classified as Vertisols.
	The default option is to model the watershed without crack flow.
	Required.

SUBWQ

Subbasin water quality code.

The algorithms used to calculate loadings of algae, organic carbonaceous biological oxygen demand and dissolved oxygen to the stream network (see Chapter 4:4 in Theoretical Documentation) were derived from results of limited studies and are still in the testing phase. ISUBWQ allows the user to choose to apply or not apply the algorithms.

- 0 do not calculate algae/CBOD loadings and set dissolved oxygen to saturated oxygen concentration
- 1 calculate algae/CBOD/dissolved oxygen loadings using algorithms documented in Theoretical Documentation

The default option is ISUBWQ=0.

Required.

SED_DET

Code governing calculation of daily maximum half-hour rainfall value:

- 0 generate daily value using triangular distribution
- 1 use monthly maximum half-hour rainfall value for all days in month

The user has the option of using the monthly maximum half-hour rainfall for all days in the month. The randomness of the triangular distribution used to generate daily values causes the maximum half-hour rainfall value to jump around. For small plots or microwatersheds in particular, the variability of the triangular distribution is unrealistic.

Required.

RTE

Channel water routing method:

- 0 variable storage method
- 1 Muskingum method

The user must be careful to define MSK_CO1, MSK_CO2 and MSK_X when the Muskingum method is chosen.

The default option is IRTE=0.

Required.

DEG

Channel degradation code.

There are two options:

- 0 channel dimensions are not updated as a result of degradation (the dimensions remain constant for the entire simulation)
- 1 channel dimensions are updated as a result of degradation

Traditionally, channel dimensions remain fixed, or constant, throughout the simulation. The change in channel dimensions with time is a new feature in SWAT that is still in the testing phase. The recommended option is to keep the channel dimensions constant.

Required.

WQ	In-stream water quality code. The variable identifies whether in-stream transformation of nutrients using the QUAL2E algorithms and in-stream transformation of pesticides is allowed to occur. 0 do not model in-stream nutrient and pesticide transformations 1 model in-stream nutrient and pesticide transformations The default option is IWQ=0.
RTPEST	Required. Redefined to the sequence number -- changed to no nutrient stress of pest in NPNO(:)to be routed through the watershed
CN	Daily curve number calculation method: 0 calculate daily CN value as a function of soil moisture 1 calculate daily CN value as a function of plant evapotranspiration 2 use traditional SWAT method which bases CN on soil moisture but retention is adjusted for mildly-sloped tiled-drained watersheds Option 0 was the only method used to calculate the daily CN value in versions of SWAT prior to SWAT2012. Calculation of the daily CN value as a function of plant evapotranspiration was added because the soil moisture method was predicting too much runoff in shallow soils. By calculating daily CN as a function of plant evapotranspiration, the value is less dependent on soil storage and more dependent on antecedent climate. Required.
CFAC	CFAC = 0 for C-factor calculation using Cmin. = 1 for new C-factor calculation. (0-1)
CSWAT	Code for new carbon routines: 0 = original routines 1 = new carbon routines
BF_FLG	Baseflow distribution factor during the day for subdaily runs. 0 = baseflow evenly distributed to each time step during the day 0.5 = even weights between even distribution and rainfall pattern 1= profile of baseflow in a day follows rainfall pattern
UHYD	Unit hydrograph method: 1 = triangular UH 2 = gamma function UH
SED_CH	Instream sediment model, 0=Bagnold model, 1=Brownlie model, 2=Yang model

TDRN	Tile drainage equations flag/code Tile drainage routines flag/code: 1 = DRAINMOD tile equations (Subroutine DRAINS) 1 simulate tile flow using subroutine drains(wt_shall) 0 simulate tile flow using subroutine origtile(wt_shall,d)
WTDN	water table depth algorithms flag/code 1 simulate wt_shall using subroutine new water table depth routine 0 simulate wt_shall using subroutine original water table depth routine
SOL_P_MODEL	Soil phosphorus model 0 = original soil phosphorus model 1 = new soil phosphorus model
ABSTR	Initial abstraction on impervious cover (mm)
ATMO	Atmospheric deposition interval (character) 'm' = monthly 'y' = yearly 'a' = annual
SMAX	Maximum depressional storage code; 1=dynamic stmaxd computed as a function of random roughness and rain intensity by depstor.f; 0 = static stmaxd from .bsn for global value or .sdr for specific HRU's
I_SUBHW	Code for routing headwaters

PARAMETERS.BSN

General watershed attributes are defined in the basin input file. These attributes control a diversity of physical processes at the watershed level. The interfaces will automatically set these parameters to the "default" or recommended values listed in the variable documentation. Users can use the default values or change them to better reflect what is happening in a given watershed. Variables governing bacteria or pesticide transport need to be initialized only if these processes are being modeled in the watershed. Even if nutrients are not being studied in a watershed, some attention must be paid to these variables because nutrient cycling impacts plant growth which in turn affects the hydrologic cycle.

Below is a sample PARAMETERS.BSN FILE:

Parameter Basin para		NAME	EVALAI	FFCB	SURLAG	ADU_PKR	PRF	SPCON	SPEXP	CMN	N_UPDIS	P_UPDIS	NPERCO	PPERCO	PHOSD	PSP	RSDCO	PERCOP	MSK_CD1	MSK_CD2	MSK_X_TRNSRCH	EVRCII	CNCDEF	CDN	SDNCOJACT_SWF	TB	ADU	CN	FROZFORM_HR	SMACO	FIKCO	NFMAM_JECD_MN_D_COVCO	VCRIT	STUR_CO	UHALPHA	ERO_SPLILL_MULT	EXPO_FACTOR	CH_DSO	SIG_G	R2ADI	IGEN
		NAME	5	1	4	0.7	0	0.005	1	0.004	0	5	0	0	120	100	0.2	0	0	0	1	0	1.5	0	0	0	0.004	0	0	0	0	0	0	1	0.7	1.2	0.3	50	1.57	0	

Variable name

Definition

TITLE

The first line is reserved for user comments. This line is not processed by the model and may be left blank.

Optional.

HEADER

Headers

NAME

Name

EVLAI	<p>Leaf area index at which no evaporation occurs from water surface.</p> <p>EVLAI is used in HRUs where a plant is growing in a ponded environment (e.g. rice). Currently, this is simulated only in HRUs defined as depressional areas/potholes.</p> <p>Evaporation from the water surface is allowed until the leaf area of the plant reaches the value specified for EVLAI. Chapter 8:1 in the Theoretical Documentation provides more detail on the use of this parameter.</p> <p>EVLAI should be set between 0.0 and 10.0. If no value for EVLAI is entered, the model will set EVLAI = 3.0.</p> <p>Required if depressional areas/potholes are modeled in the watershed.</p>
FFCB	<p>Initial soil water storage expressed as a fraction of field capacity water content.</p> <p>All soils in the watershed will be initialized to the same fraction.</p> <p>FFCB should be between 0.0 and 1.0. If FFCB is not set to a value, the model will calculate it as a function of average annual precipitation. The default method is to allow the model to calculate FFCB (set FFCB = 0.0).</p> <p>We recommend using a 1 year equilibration period for the model where the watershed simulation is set to start 1 year prior to the period of interest. This allows the model to get the water cycling properly before any comparisons between measured and simulated data are made. When an equilibration period is incorporated, the value for FFCB is not going to impact model results.</p> <p>Required.</p>

SURLAG

Surface runoff lag coefficient.

In large subbasins with a time of concentration greater than 1 day, only a portion of the surface runoff will reach the main channel on the day it is generated. SWAT incorporates a surface runoff storage feature to lag a portion of the surface runoff release to the main channel.

SURLAG controls the fraction of the total available water that will be allowed to enter the reach on any one day. Figure 4-7 plots the fraction of total available water entering the reach at different values for *surlag* and *t_{conc}*.

Note that for a given time of concentration, as *surlag* decreases in value more water is held in storage. The delay in release of surface runoff will smooth the streamflow hydrograph simulated in the reach.

If no value for SURLAG is entered, the model will set SURLAG = 4.0.

Required.




Figure 4-7: Influence of *surlag* and *t_{conc}* on fraction of surface runoff released.

ADJ_PKR

Peak rate adjustment factor for sediment routing in the *subbasin (tributary channels)*.

Sediment routing is a function of peak flow rate and mean daily flow. Because SWAT originally could not directly calculate the sub-daily hydrograph due to the use of precipitation summarized on a daily basis, this variable was incorporated to allow adjustment for the effect of the peak flow rate on sediment routing. This factor is used in the MUSLE equation and impacts the amount of erosion generated in the HRUs.

If no value for ADJ_PKR is entered, the model will set ADJ_PKR=1.0.

Required.

PRF	Peak rate adjustment factor for sediment routing in the main channel.
	Sediment routing is a function of peak flow rate and mean daily flow. Because SWAT originally could not directly calculate the sub-daily hydrograph, this variable was incorporated to allow adjustment for the effect of the peak flow rate on sediment routing. This variable impacts channel degradation.
	If no value for PRF is entered, the model will set PRF = 1.0.
	Required.
SPCON	Linear parameter for calculating the maximum amount of sediment that can be reentrained during channel sediment routing.
	The maximum amount of sediment that can be transported from a reach segment is calculated $conc_{sed, ch, mx} = c_{sp} \cdot v_{ch, pk}^{spexp}$ where concsed, ch, mx is the maximum concentration of sediment that can be transported by the water (ton/m ³ or kg/L), csp is a coefficient defined by the user, vch, pk is the peak channel velocity (m/s), and spexp is an exponent defined by the user.
	SPCON should be between 0.0001 and 0.01. If no value for SPCON is entered, the model will set SPCON = 0.0001.
	Required.
SPEXP	Exponent parameter for calculating sediment reentrained in channel sediment routing
	The maximum amount of sediment that can be transported from a reach segment is calculated $conc_{sed, ch, mx} = c_{sp} \cdot v_{ch, pk}^{spexp}$ where concsed, ch, mx is the maximum concentration of sediment that can be transported by the water (ton/m ³ or kg/L), csp is a coefficient defined by the user, vch, pk is the peak channel velocity (m/s), and spexp is an exponent defined by the user.
	The exponent, spexp, normally varies between 1.0 and 2.0 and was set at 1.5 in the original Bagnold stream power equation (Arnold et al., 1995). If no value for SPEXP is entered, the model will set SPEXP = 1.0.
	Required.

CMN

Rate factor for humus mineralization of active organic nutrients (N and P).

Chapters 3:1 and 3:2 of the Theoretical Documentation describe the use of this parameter in the mineralization calculations.

If no value for CMN is specified, the model will set CMN = 0.0003.

Required.

N_UPDIS

Nitrogen uptake distribution parameter.

Root density is greatest near the surface, and plant nitrogen uptake in the upper portion of the soil will be greater than in the lower portion. The depth distribution of nitrogen uptake is controlled by β_n , the nitrogen uptake distribution parameter.

The importance of the nitrogen uptake distribution parameter lies in its control over the maximum amount of nitrate removed from the upper layers. Because the top 10 mm of the soil profile interacts with surface runoff, the nitrogen uptake distribution parameter will influence the amount of nitrate available for transport in surface runoff. The model allows lower layers in the root zone to fully compensate for lack of nitrate in the upper layers, so there should not be significant changes in nitrogen stress with variation in the value used for β_n .

If no value for N_UPDIS is entered, the model will set N_UPDIS = 20.0.

Figure 4-9 illustrates nitrogen uptake as a function of depth for four different uptake distribution parameter values.

Required.




Figure 4-9: Depth distribution of nitrogen uptake

P_UPDIS

Phosphorus uptake distribution parameter.

This parameter controls plant uptake of phosphorus from the different soil horizons in the same way that UBN controls nitrogen uptake. The illustration of nitrogen uptake as a function of depth for four different uptake distribution parameter values in Figure 4-9 is valid for phosphorus uptake as well.

Phosphorus removed from the soil by plants is taken from the solution phosphorus pool. The importance of the phosphorus uptake distribution parameter lies in its control over the maximum amount of solution P removed from the upper layers. Because the top 10 mm of the soil profile interacts with surface runoff, the phosphorus uptake distribution parameter will influence the amount of labile phosphorus available for transport in surface runoff. The model allows lower layers in the root zone to fully compensate for lack of solution P in the upper layers, so there should not be significant changes in phosphorus stress with variation in the value used for β_p .

If no value for P_UPDIS is entered, the model will set P_UPDIS = 20.0.

Required.

NPERCO

Nitrate percolation coefficient.

NPERCO controls the amount of nitrate removed from the surface layer in runoff relative to the amount removed via percolation.

The value of NPERCO can range from 0.01 to 1.0. As NPERCO \rightarrow 0.0, the concentration of nitrate in the runoff approaches 0. As NPERCO \rightarrow 1.0, surface runoff has the same concentration of nitrate as the percolate.

If no value for NPERCO is entered, the model will set NPERCO = 0.20.

Required.

PPERCO

Phosphorus percolation coefficient ($10 \text{ m}^3/\text{Mg}$).

The phosphorus percolation coefficient is the ratio of the solution phosphorus concentration in the surface 10 mm of soil to the concentration of phosphorus in percolate.

The value of PPERCO can range from 10.0 to 17.5 If no value for PPERCO is entered, the model will set PPERCO = 10.0.

Required.

PHOSKD Phosphorus soil partitioning coefficient (m³/Mg).

The phosphorus soil partitioning coefficient is the ratio of the soluble phosphorus concentration in the surface 10 mm of soil to the concentration of soluble phosphorus in surface runoff.

The primary mechanism of phosphorus movement in the soil is by diffusion. Diffusion is the migration of ions over small distances (1-2 mm) in the soil solution in response to a concentration gradient. Due to the low mobility of solution phosphorus, surface runoff will only partially interact with the solution P stored in the top 10 mm of soil.

If no value for PHOSKD is entered, the model will set PHOSKD = 175.0.

Required.

PSP

Phosphorus availability index.

Many studies have shown that after an application of soluble P fertilizer, solution P concentration decreases rapidly with time due to reaction with the soil. This initial “fast” reaction is followed by a much slower decrease in solution P that may continue for several years (Barrow and Shaw, 1975; Munns and Fox, 1976; Rajan and Fox, 1972; Sharpley, 1982). In order to account for the initial rapid decrease in solution P, SWAT assumes a rapid equilibrium exists between solution P and an “active” mineral pool. The subsequent slow reaction is simulated by the slow equilibrium assumed to exist between the “active” and “stable” mineral pools. The algorithms governing movement of inorganic phosphorus between these three pools are taken from Jones et al. (1984).

Equilibration between the solution and active mineral pool is governed by the phosphorus availability index. This index specifies the fraction of fertilizer P which is in solution after an incubation period, i.e. after the rapid reaction period.

A number of methods have been developed to measure the phosphorus availability index. Jones et al. (1984) recommends a method outlined by Sharpley et al. (1984) in which various amounts of phosphorus are added in solution to the soil as K₂HPO₄. The soil is wetted to field capacity and then dried slowly at 25°C. When dry, the soil is rewetted with deionized water. The soil is exposed to several wetting and drying cycles over a 6-month incubation period. At the end of the incubation period, solution phosphorus is determined by extraction with anion exchange resin.

The P availability index is then calculated:

$$pai = \frac{P_{solution,f} - P_{solution,i}}{fert_{minP}}$$

where *pai* is the phosphorus availability index, *P_{solution,f}* is the amount of phosphorus in solution after fertilization and incubation, *P_{solution,I}* is the amount of phosphorus in solution before fertilization, and *fert_{minP}* is the amount of soluble P fertilizer added to the sample.

If no value for PSP is entered, the model will set PSP = 0.40.

Required.

RSDCO

Residue decomposition coefficient.

The fraction of residue which will decompose in a day assuming optimal moisture, temperature, C:N ratio and C:P ratio.

If no value for RSDCO is entered, the model will set RSDCO = 0.05.

Required.

PERCOP

Pesticide percolation coefficient.

PERCOP controls the amount of pesticide removed from the surface layer in runoff and lateral flow relative to the amount removed via percolation. The value of PERCOP can range from 0.01 to 1.0. As PERCOP \rightarrow 0.0, the concentration of pesticide in the runoff and lateral flow approaches 0. As PERCOP \rightarrow 1.0, surface runoff and lateral flow has the same concentration of pesticide as the percolate.

If no value for PERCOP is entered, the model will set PERCOP = 0.50.

Required if pesticide transport is of interest.

MSK_CO1

Calibration coefficient used to control impact of the storage time constant (K_m) for normal flow (where normal flow is when river is at bankfull depth) upon the K_m value calculated for the reach.

Required only if IRTE = 1.

MSK_CO2

Calibration coefficient used to control impact of the storage time constant (K_m) for low flow (where low flow is when river is at 0.1 bankfull depth) upon the K_m value calculated for the reach.

Required only if IRTE = 1.

MSK_X

MSK_X is a weighting factor that controls the relative importance of inflow and outflow in determining the storage in a reach.

The weighting factor has a lower limit of 0.0 and an upper limit of 0.5. This factor is a function of the wedge storage. For reservoir-type storage, there is no wedge and $X = 0.0$. For a full-wedge, $X = 0.5$. For rivers, X will fall between 0.0 and 0.3 with a mean value near 0.2.

If no value for MSK_X is entered, the model will set MSK_X = 0.2.

Required only if IRTE = 1.

TRNSRCH

Fraction of transmission losses from main channel that enter deep aquifer. The remainder if the transmission losses enter bank storage.

In arid watersheds, transmission losses from the main channel network may be permanently lost due to transmission to aquifers that do not contribute flow back to the stream network. This variable allows the user to specify the fraction of transmission losses from the channel network that is permanently lost.

TRNSRCH varies between 0.00 and 1.00. The default value for TRNSRCH is 0.00.

Required.

EVRCH

Reach evaporation adjustment factor.

The evaporation coefficient is a calibration parameter for the user and is allowed to vary between 0.0 and 1.0. This coefficient was created to allow reach evaporation to be damped in arid regions. The original equation tends to overestimate evaporation in these areas.

If no value for EVRCH is entered, the model will set EVRCH = 1.00.

Required.

OPENVAR1

This input is not currently being used (formerly CNCOEF).

CDN

Denitrification exponential rate coefficient.

This coefficient allows the user to control the rate of denitrification.

Acceptable values for CDN range from 0.0 to 3.0. If no value for CDN is specified, the model will set CDN = 1.4.

Required.




Fig 4-8: Impact of **CDN** value on amount of nitrogen lost to denitrification assuming initial nitrate content in layer is 200 kg/ha, temperature of layer is 10 °C, and organic carbon content of layer is 2%.

SDNCO	<p>Denitrification threshold water content.</p> <p>Fraction of field capacity water content above which denitrification takes place.</p> <p>Denitrification is the bacterial reduction of nitrate, NO_3^-, to N_2 or N_2O gases under anaerobic (reduced) conditions. Because SWAT does not track the redox status of the soil layers, the presence of anaerobic conditions in a soil layer is defined by this variable. If the soil water content calculated as fraction of field capacity is \geq SDNCO, then anaerobic conditions are assumed to be present and denitrification is modeled. If the soil water content calculated as a fraction of field capacity is $<$ SDNCO, then aerobic conditions are assumed to be present and denitrification is not modeled.</p> <p>If no value for SDNCO is specified, the model will set SDNCO = 1.10.</p> <p>Required.</p>
BACT_SWF	<p>Fraction of manure applied to land areas that has active colony forming units.</p> <p>If no value for BACT_SWF is specified, the model will set BACT_SWF = 0.15.</p> <p>Required if bacteria processes are of interest.</p>
TB_ADJ	<p><i>New variable in testing.</i></p> <p><i>Adjustment factor for subdaily unit hydrograph basetime.</i></p>
CN_FROZ	<p>Parameter for frozen soil adjustment on infiltration/runoff.</p> <p>If no value for CNFROZ_BSN is entered, the model will set CNFROZ_BSN = 0.000862.</p> <p>Optional.</p>
DORM_HR	<p>Time threshold used to define dormancy (hours). The maximum day length minus DORM_HR is equal to when dormancy occurs.</p> <p>Optional.</p>
OPENVAR2	This input variable currently not being used (formerly smxco).
FIXCO	Nitrogen fixation coefficient. (0.0 – 1.0) 1.0 = fixes 100% of nitrogen demand. 0.0 = fixes none of nitrogen demand.
NFIXMX	Maximum daily-n fixation (kg/ha). (1.0 – 20.0)
DECR_MIN	Minimum daily residue decay (fraction 0.0 – 0.05)
RSD_COVCO	Residue cover factor for computing fraction of cover. (0.1 – 0.5)
VCRIT	Critical velocity
RES_STR_CO	Reservoir sediment settling coefficient (0.09 – 0.27)

UHALPHA	Alpha coefficient for gamma function unit hydrograph. Required if iuh = 2 is selected
EROS_SPL	Splash erosion coefficient (0.9 – 3.1)
RILL_MULT	Rill erosion coefficient – multiplier to USLE_K for soil susceptible to rill erosion (0.5-2.0)
EROS_EXPO	Exponential coefficient for overland flow – (1.5-3.0)
C_FACTOR	Scaling parameter for cover and management factor for overland flow erosion (0.03/0.001/0.45)
CH_D50	Median particle diameter of main channel (mm) (50/10/100)
SIG_G	Geometric standard deviation of particle size (1.57/1.0/5.0)
OPENVAR3	This input variable currently not being used (formerly r2adj).
IGEN	Random generator code 0 = use default number; 1 = generate new numbers in every simulation

CLIMATE – The CLIMATE section of file.cio contains filenames for the entire simulation run. The list of the filenames are listed below with a brief description of the inputs within each file.

WEATHER-STA.CLI

The weather station climate file contains the weather stations that will be included in the simulation and is space delimited. Below is a sample WEATHER-STA.CLI file:

weather-sta.cli								
NAME	WGN	PGAGE	TGAGE	SGAGE	HGAGE	WGAGE	WNDIR	ATMODEP
wea1	wgn001	mentone.pcp	mentone.tmp	sim	sim	sim	null	atmo_2
wea2	wgn001	warsaw.pcp	warsaw.tmp	sim	sim	sim	null	atmo_3

Variable name Definition

TITLE	title of the weather station.
HEADER	Headings
WST_NAME	The weather station name
WGN	The weather generator station name (from the weather-wgn.cli file)
PGAGE	The precipitation station name (from pcp.cli file). If precipitation is generated, ‘sim’ should be input.
TGAGE	The temperature station name (from tmp.cli file). If temperature will be generated, ‘sim’ should be input.

SGAGE	The solar radiation station name (from slr.cli file). If solar radiation will be generated, 'sim' should be input.
HGAGE	The relative humidity station name (from hmd.cli file). If relative humidity will be generated, 'sim' should be input.
WGAGE	The wind station name (from wnd.cli file). If wind will be generated, 'sim' should be input.
WNDIR	The wind direction name (from wind-dir.cli file). If wind direction will be generated, 'sim' should be input.
ATMODEP	The atmospheric deposition file name. If no atmospheric deposition file is used, 'null' should be input.

WEATHER-WGN.CLI

The weather generator climate file contains the weather generator stations that will be included in the simulation and is space delimited. Below is a sample WEATHER-WGN.CLI file:

weather-w	Weather													
wgn001	43.07	-94.3	374.9	31										
TMPMX	TMPMN	TMPSTDM	TMPTDMN	PCPMMM	PCPSTD	PCPSKW	PR_WD	PR_WW	PCPD	RAINHMX	SOLARAV	DEWPPT	WINDAV	
-3.9	-13.52	6.76	7.5	18.5	4.01	2.09	0.12	0.32	4.48	3.35	7.12	-11.06	5.61	
-1.22	-10.79	7.04	7.72	18	4.6	2.72	0.12	0.25	3.83	4.43	10.81	-8.92	5.59	
5.8	-4.3	7.36	6.22	43.4	8.24	1.81	0.15	0.33	5.6	6.5	15	-3.91	5.8	
14.81	2.12	7.32	4.87	80.4	9.58	1.69	0.22	0.39	7.83	18.45	17.93	0.87	6.04	
21.53	8.87	5.64	4.55	107.3	11.83	2.31	0.25	0.46	9.9	24.11	20.78	4.12	5.47	
26.52	14.38	4.49	3.74	128.6	17.15	2.84	0.28	0.39	9.47	40.11	22.84	6.66	4.78	
28.12	16.55	3.58	3.16	107.4	12.61	1.59	0.25	0.32	8.37	35.16	23.21	15.92	3.89	
26.69	15.22	3.67	3.48	105.3	18	4.34	0.21	0.36	7.77	39.17	20.41	15.27	3.57	
23.15	10.25	5.33	4.86	72.6	12.77	2.61	0.2	0.33	6.8	15.72	15.92	5.13	4.22	
15.74	3.41	6.44	5.13	59.2	9.29	1.59	0.15	0.41	6.44	12.93	11.1	1.54	4.9	
6.07	-3.99	7.17	5.86	39.8	8.97	2.6	0.13	0.36	5.17	5.93	7.16	-3.25	5.42	
-2.17	-11.12	7.07	7.4	24.6	4.88	1.77	0.13	0.23	4.62	3.21	5.66	-8.88	5.48	

Variable name	Definition
TITLE	Description of the weather-wgn.cli file
WGN_NAME	The weather station name (to be referenced in weather-sta.cli file).
LATITUDE	Latitude of weather station used to create statistical parameters (degrees). The latitude is expressed as a real number with minutes and seconds converted to fractions of a degree.
LONGITUDE	Longitude of weather station (degrees).
ELEV	Elevation of weather station (m). Required if elevation bands are modeled in watershed.

RAIN_YRS The number of years of maximum monthly 0.5 h rainfall data used to define values for RAIN_HHMX(1) - RAIN_HHMX(12).

If no value is input for RAIN_YRS, SWAT will set RAIN_YRS = 10.

Required.

TMPMX(MON) Average or mean daily maximum air temperature for month (°C).

This value is calculated by summing the maximum air temperature for every day in the month for all years of record and dividing by the number of days summed:

$$\mu mx_{mon} = \frac{\sum_{d=1}^N T_{mx,mon}}{N}$$

where μmx_{mon} is the mean daily maximum temperature for the month (°C), $T_{mx,mon}$ is the daily maximum temperature on record d in month mon (°C), and N is the total number of daily maximum temperature records for month mon.

Required.

TMPMN(MON) Average or mean daily minimum air temperature for month (°C).

This value is calculated by summing the minimum air temperature for every day in the month for all years of record and dividing by the number of days summed:

$$\mu_{mn_{mon}} = \frac{\sum_{d=1}^N T_{mn,mon}}{N}$$

where $\mu_{mn_{mon}}$ is the mean daily minimum temperature for the month (°C), $T_{mn,mon}$ is the daily minimum temperature on record d in month mon (°C), and N is the total number of daily minimum temperature records for month mon .

Required.

TMPSTDMX_(MO_N) Standard deviation for daily maximum air temperature in month (°C).

This parameter quantifies the variability in maximum temperature for each month. The standard deviation is calculated:

$$\sigma_{mx_{mon}} = \sqrt{\left(\frac{\sum_{d=1}^N (T_{mx,mon} - \mu_{mx_{mon}})^2}{N - 1} \right)}$$

where $\sigma_{mx_{mon}}$ is the standard deviation for daily maximum temperature in month mon (°C), $T_{mx,mon}$ is the daily maximum temperature on record d in month mon (°C), $\mu_{mx_{mon}}$ is the average daily maximum temperature for the month (°C), and N is the total number of daily maximum temperature records for month mon .

Required.

$\text{TMPSTDMN}_{(MO_N)}$ Standard deviation for daily minimum air temperature in month ($^{\circ}\text{C}$).

This parameter quantifies the variability in minimum temperature for each month. The standard deviation is calculated:

$$\sigma_{mn_{mon}} = \sqrt{\left(\frac{\sum_{d=1}^N (T_{mn,mon} - \mu_{mn_{mon}})^2}{N - 1} \right)}$$

where $\sigma_{mn_{mon}}$ is the standard deviation for daily minimum temperature in month mon ($^{\circ}\text{C}$), $T_{mn,mon}$ is the daily minimum temperature on record d in month mon ($^{\circ}\text{C}$), $\mu_{mn_{mon}}$ is the average daily minimum temperature for the month ($^{\circ}\text{C}$), and N is the total number of daily minimum temperature records for month mon .

Required.

$\text{PCPMM}_{(\text{MON})}$ Average or mean total monthly precipitation (mm H₂O).

$$\bar{R}_{mon} = \frac{\sum_{d=1}^N R_{day,mon}}{yrs}$$

where \bar{R}_{mon} is the mean monthly precipitation (mm H₂O), $R_{day,mon}$ is the daily precipitation for record d in month mon (mm H₂O), N is the total number of records in month mon used to calculate the average, and yrs is the number of years of daily precipitation records used in calculation.

Required.

PCPSTD_(MON) Standard deviation for daily precipitation in month (mm H₂O/day).

This parameter quantifies the variability in precipitation for each month. The standard deviation is calculated:

$$\sigma_{mon} = \sqrt{\left(\frac{\sum_{d=1}^N (R_{day,mon} - \bar{R}_{mon})^2}{N - 1} \right)}$$

where σ_{mon} is the standard deviation for daily precipitation in month mon (mm H₂O), $R_{day,mon}$ is the amount of precipitation for record d in month mon (mm H₂O), \bar{R}_{mon} is the average precipitation for the month (mm H₂O), and N is the total number of daily precipitation records for month mon . (Note: daily precipitation values of 0 mm are included in the standard deviation calculation).

Required.

PCPSKW_(MON) Skew coefficient for daily precipitation in month.

This parameter quantifies the symmetry of the precipitation distribution about the monthly mean. The skew coefficient is calculated:

$$g_{mon} = \frac{N \cdot \sum_{d=1}^N (R_{day,mon} - \bar{R}_{mon})^3}{(N - 1) \cdot (N - 2) \cdot (\sigma_{mon})^3}$$

where g_{mon} is the skew coefficient for precipitation in the month, N is the total number of daily precipitation records for month mon , $R_{day,mon}$ is the amount of precipitation for record d in month mon (mm H₂O), \bar{R}_{mon} is the average precipitation for the month (mm H₂O), and σ_{mon} is the standard deviation for daily precipitation in month mon (mm H₂O). (Note: daily precipitation values of 0 mm are included in the skew coefficient calculation).

Required.

PR_WD_(MON)

Probability of a wet day following a dry day in the month.

This probability is calculated:

$$P_i(W/D) = \frac{days_{W/D,i}}{days_{dry,i}}$$

where $P_i(W/D)$ is the probability of a wet day following a dry day in month i , $days_{W/D,i}$ is the number of times a wet day followed a dry day in month i for the entire period of record, and $days_{dry,i}$ is the number of dry days in month i during the entire period of record. A dry day is a day with 0 mm of precipitation. A wet day is a day with > 0 mm precipitation.

Required.

PR_WW_(MON)

Probability of a wet day following a wet day in the month.

This probability is calculated:

$$P_i(W/W) = \frac{days_{W/W,i}}{days_{wet,i}}$$

where $P_i(W/W)$ is the probability of a wet day following a wet day in month i , $days_{W/W,i}$ is the number of times a wet day followed a wet day in month i for the entire period of record, and $days_{wet,i}$ is the number of wet days in month i during the entire period of record. A dry day is a day with 0 mm of precipitation. A wet day is a day with > 0 mm precipitation.

Required.

PCPD_(MON)

Average number of days of precipitation in month.

This parameter is calculated:

$$\bar{d}_{wet,i} = \frac{days_{wet,i}}{yrs}$$

where $\bar{d}_{wet,i}$ is the average number of days of precipitation in month i , $days_{wet,i}$ is the number of wet days in month i during the entire period of record, and yrs is the number of years of record.

Required.

RAINHMX_(MON)

Maximum 0.5 hour rainfall in entire period of record for month (mm H₂O).

This value represents the most extreme 30-minute rainfall intensity recorded in the entire period of record.

Required.

SOLARAV_(MON) Average daily solar radiation for month (MJ/m²/day).

This value is calculated by summing the total solar radiation for every day in the month for all years of record and dividing by the number of days summed:

$$\mu rad_{mon} = \frac{\sum_{d=1}^N H_{day,mon}}{N}$$

where μrad_{mon} is the mean daily solar radiation for the month (MJ/m²/day), $H_{day,mon}$ is the total solar radiation reaching the earth's surface for day d in month mon (MJ/m²/day), and N is the total number of daily solar radiation records for month mon .

Required.

DEWPT_(MON)

Average daily dew point temperature for each month (°C) or relative humidity (fraction) can be input.

If all twelve months are less than one, the model assumes relative humidity is input. Relative humidity is defined in equation 1:3.5.1 in the SWAT Theoretical documentation as the amount of water vapor in the air as a fraction of saturation humidity. If any month has a value greater than 1.0, the model assumes dewpoint temperature is input.

Dew point temperature is the temperature at which the actual vapor pressure present in the atmosphere is equal to the saturation vapor pressure. This value is calculated by summing the dew point temperature for every day in the month for all years of record and dividing by the number of days summed:

$$\mu dew_{mon} = \frac{\sum_{d=1}^N T_{dew,mon}}{N}$$

where μdew_{mon} is the mean daily dew point temperature for the month (°C), $T_{dew,mon}$ is the dew point temperature for day d in month mon (°C), and N is the total number of daily dew point records for month mon . Dew point is converted to relative humidity using equations 1:3.5.1 and 1:3.5.2 in the Theoretical Documentation.

Required for Penman-Monteith potential evaporation equation.

WINDAV_(MON)

Average daily wind speed in month (m/s).

This value is calculated by summing the average or mean wind speed values for every day in the month for all years of record and dividing by the number of days summed:

$$\mu_{wind}_{mon} = \frac{\sum_{d=1}^N \mu_{wind,mon}}{N}$$

where μ_{wind}_{mon} is the mean daily wind speed for the month (m/s), $\mu_{wind,mon}$ is the average wind speed for day d in month mon (m/s), and N is the total number of daily wind speed records for month mon .

Required.

WIND-DIR.CLI

This file contains the wind direction values that will be included in the simulation and is space delimited. Below is a sample WIND-DIR.CLI file:

wind-dir.cl											
2											
AL_BAN											
0	0										
3.46	3.47	3.64	3.3	2.55	2.26	2.09	2.06	2.44	2.37	2.8	3.11
10	10	8	7	8	7	6	9	13	14	12	11
4	5	4	4	4	4	4	6	9	8	6	5
4	4	4	4	6	6	6	8	9	8	6	5
3	4	4	4	5	6	6	7	9	8	5	4
5	6	5	5	6	8	8	9	12	10	6	7
5	5	5	4	5	6	6	5	7	6	4	7
9	7	7	7	7	7	7	6	7	6	8	8
9	7	8	9	7	7	7	5	5	5	6	7
12	9	11	13	11	10	12	8	6	5	7	8
7	6	7	9	8	8	9	5	4	3	5	4
3	4	4	5	6	6	7	5	3	2	3	3
2	3	3	4	4	5	5	4	2	2	3	3
3	4	5	4	5	5	6	5	2	3	4	5
6	7	7	7	5	5	4	4	2	4	7	6
9	8	8	7	6	6	4	6	4	7	10	8
7	8	8	7	6	5	4	6	7	9	9	8

Variable name	Definition
TITLE	Description of the wind direction file (may be blank)
MWND_DIR	The maximum number of wind direction stations in the file.
NAME	Wind Station name
SKIP	Next 2 lines are not read in by the model
WND_DIR	The monthly wind directions input data (16 lines/directions)

PCP.CLI

This file contains the information on the precipitation gages included in the simulation and is space delimited. A path has been added to file.cio to enable the daily files to be present in another folder; if path is null daily is in same project folder as other data. Below is a sample PCP.CLI file:

pcp.cli
FILENAME
mentone.pcp
warsaw.pcp

Variable name	Definition
TITLE	Description of the precipitation climate file (may be blank)
HEADER	The header information for the pcp.cli file
PCP_FILENAME	The name of the precipitation file containing daily precipitation input data (description of the pcp_filename data follows)

PCP_FILENAME

The pcp_filename is input in the pcp.cli file. The description of the ‘pcp_filename’ contains the daily precipitation amounts for the simulation and is space delimited. A path has been added to file.cio to enable the daily files to be present in another folder; if path is null daily is in same project folder as other data. Below is a sample of the file (partial listing):

mentone.pcp				
NBYR	TSTEP	LAT	LONG	ELEV
114	0	41.14	-85.98	268
1900	1	0.3		
1900	2	0		
1900	3	0		
1900	4	0		
1900	5	0		
1900	6	0.6		
1900	7	0.5		
1900	8	0		
1900	9	3.6		
1900	10	3.5		
1900	11	2.3		

Variable name	Definition
TITLE	Description of the precipitation file (may be blank)
HEADER	
NBYR	The header information for the file
TSTEP	Timestep of the simulation
LAT	Latitude of the precipitation gage
LONG	Longitude of the precipitation gage
ELEV	Elevation of the precipitation gage
IYR	The year of the precipitation amount
ISTEP	The step (day, sub-daily) of the precipitation amount
PCP	The amount of precipitation amount (mm) for istep (enter -99.0 for missing days)

TMP.CLI

This file contains information on the maximum and minimum temperatures included in the simulation and is space delimited. A path has been added to file.cio to enable the daily files to be present in another folder; if path is null daily is in same project folder as other data. Below is a sample TMP.CLI file:

tmp.cli
FILENAME
mentone.tmp
warsaw.tmp

Variable name	Definition
TITLE	Description of the maximum and minimum temperature file (may be blank)
HEADER	The header information for the tmp.cli file
TMP_FILENAME	The name of the temperature file containing daily maximum and minimum temperatures.

TMP_FILENAME

The tmp_filename is input in the tmp.cli file. The description of the ‘tmp_filename’ contains the daily maximum and minimum temperatures for the simulation and is space delimited. Below is a sample of the file:

mentone.tmp			
NBYR	LAT	LONG	ELEV
114	41.14	-85.98	268
1900	1	-99	-99
1900	2	-99	-11.5
1900	3	-99	-7.5
1900	4	3.1	-9.4
1900	5	5.7	-0.2
1900	6	6.8	-0.1
1900	7	11.2	2.6
1900	8	7.7	-99
1900	9	8	-3.4
1900	10	4.9	1.3
1900	11	-99	-1.2

Variable name	Definition
TITLE	Description of the temperature file (may be blank)
HEADER	Headings
NBYR	The header information for the file
LAT	Latitude of the temperature gage
LONG	Longitude of the temperature gage
ELEV	Elevation of the temperature gage
IYR	The year of the temperature data
ISTEP	Timestep
TMP_MAX	The maximum temperatures for istep (enter -99.0 for missing days)
TMP_MIN	The minimum temperatures for istep (enter -99.0 for missing days)

SLR.CLI

This file contains the information on the solar radiation daily data included in the simulation and is space delimited. A path has been added to file.cio to enable the daily files to be present in another folder; if path is null daily is in same project folder as other data. Below is a sample SLR.CLI file:

slr.cli	
NUMB	FILENAME
1	gage1.slr

Variable name	Definition
---------------	------------

TITLE	Description of the solar radiation file (may be blank)
HEADER	The header information for the slr.cli file
SLR_FILENAME	The name of the solar radiation file containing values of solar radiation

SLR_FILENAME

The slr_filename is input in the slr.cli file. The description of the ‘slr_filename’ contains the daily solar radiation values for the simulation and is space delimited. Below is a sample of the file (partial listing):

gage1.slr	NBYR	LAT	LONG	ELEV
	25	0.0	0.0	0.0
	1988	1	12.9	
	1988	2	27.4	
	1988	3	22.7	
	1988	4	0	
	1988	5	9.7	

Variable name	Definition
TITLE	Description of the solar radiation file (may be blank)
HEADER	Headings
NBYR	The header information for the file
LAT	Latitude of the solar radiation gage
LONG	Longitude of the solar radiation gage
ELEV	Elevation of the solar radiation gage
IYR	The year of the solar radiation data
ISTEP	Timestep
SLR	The solar radiation value for istep (MJ/m^2; -99.0 to generate missing days)

HMD.CLI

This file contains the information on the relative humidity stations included in the simulation and is space delimited. A path has been added to file.cio to enable the daily files to be present in another folder; if path is null daily is in same project folder as other data. Below is a sample HMD.CLI file:

HMD.CLI	
NUMB	FILENAME
1	gage1.hmd

Variable name Definition

TITLE	Description of the relative humidity file (may be blank)
HEADER	The header information for the hmd.cli file
HMD_FILENAME	The name of the relative humidity file containing daily relative humidity input data

HMD_FILENAME

The hmd_filename is input in the hmd.cli file. The description of the 'hmd_filename' contains the daily relative humidity values for the simulation and is space delimited. Below is a sample of the file (partial listing):

gage1.HMD			
NBYR	LAT	LONG	ELEV
25	0.0	0.0	0.0
1988	1	1	
1988	2	0.8	
1988	3	0.7	
1988	4	1	
1988	5	0.5	

Variable name Definition

TITLE	Description of the relative humidity file (may be blank)
HEADER	Headings
NBYR	The header information for the file
LAT	Latitude of the relative humidity gage
LONG	Longitude of the relative humidity gage
ELEV	Elevation of the relative humidity gage
IYR	The year of the relative humidity data
ISTEP	Timestep
RELHUM	The relative humidity value for istep (-99.0 to generate missing days)

WND.CLI

This file contains the information on the windspeed input data included in the simulation and is space delimited. A path has been added to file.cio to enable the daily files to be present in another folder; if path is null daily is in same project folder as other data. Below is a sample WND.CLI file (partial listing):

WND.CLI	
NUMB	FILENAME
1	gage1 wnd

Variable name Definition

TITLE Description of the wnd.cli file (may be blank)

HEADER The header information for the wnd.cli file

WND_FILENAME The name of the precipitation file containing daily windspeed input data

WND_FILENAME

The wnd_filename is input in the wnd.cli file. The description of the ‘wnd_filename’ contains the daily wind values for the simulation and is space delimited. Below is a sample of the file (partial listing):

gage1.WND			
NBYR	LAT	LONG	ELEV
25	0.0	0.0	0.0
1988	1	3.8	
1988	2	4.4	
1988	3	2.8	
1988	4	2	
1988	5	3.1	

Variable name Definition

TITLE Description of the windspeed file (may be blank)

HEADER Headings

NBYR The header information for the file

LAT Latitude of the windspeed gage

LONG Longitude of the windspeed gage

ELEV Elevation of the windspeed gage

IYR The year of the windspeed data

ISTEP Timestep

WNDSPD The windspeed value for istep (-99.0 to generate missing days)

ATMO.CLI

The ATMO.CLI file contains the input variables for atmospheric deposition. The atmospheric deposition input file contains annual average atmospheric nitrogen deposition values including ammonium, nitrate, dry ammonium and dry nitrate and can be read in as average annual, yearly or monthly. This file is optional. An example annual file is listed below:

ATMO_ANNUAL.TXT:


```

Atmodep_file example - annual
NUM_STA   TIMESTEP    MO_INIT    YR_INIT    NUM_AA
      2          aa          0          0          0
atmo_1
      0.35      (NH4_RF)
      3.24      (NO3_RF)
      0.13      (NH4_DRY)
      0.12      (NO3_DRY)
atmo_2
      0.35      (NH4_RF)
      3.24      (NO3_RF)
      0.13      (NH4_DRY)
      0.12      (NO3_DRY)

```

Variable name	Definition
TITLE	The first line is reserved for user comments. The title line is not processed by the model and may be left blank.
HEADER	The second line is the header for the inputs. This line is not processed by the model.
NUM_STA	Total number of deposition stations in the file
TIMESTEP	There are three different timesteps for the file to be read and should be character. ‘aa’ = annual average (constant) ‘mo’ = monthly ‘yr’ = yearly
MO_INIT	Initial month of the input data (applies to month option only) input 0 for other options;
YR_INIT	Initial year of the input data (applies to year and monthly option only) input 0 for annual;
NUM_AA	Number of average annual values in file;
NAME	Initial month of the input data (applies to month option only) input 0 for other options;
NH4_RF	Ammonia in rainfall (mg/l)
NO3_RF	Nitrate in rainfall (mg/l)
NH4_DRY	Ammonia deposition (kg/ha/yr)
NO3_DRY	Nitrate dry deposition (kg/ha/yr)

CONNECT – The CONNECT section of file.cio contains the filenames for the object connectivity for the simulation run. All connect (.con) files read in the same input variables, only differing in the connect units (HRU, HRU-LTE, ROUT_UNIT, modflow, aquifer, aquifer2d, channel, reservoir, recall, exco, delivery ratio, outlet and chandeg).



EXPLANATION OF SPATIAL OBJECTS

SUBBASIN

The subbasin is defined by the DEM in the GIS interface as it always has been. All flow within the subbasin drains to the subbasin outlet.

LANDSCAPE UNIT

A landscape unit is defined as a collection of HRU's and can be defined as a subbasin, or it could be a flood plain or upland unit, or it could be a grid cell with multiple HRU's. The landscape unit is not routed, it only used for output. The landscape unit output files (waterbal, nutbal, losses, and plant weather) are output for HRU's, landscape units, and for the basin. Two input files are required: 1) landscape elements and, 2) landscape define. The elements file includes HRU's and their corresponding LSU fraction and basin fractions. The define file specifies which HRU's are contained in each LSU.

ROUTING UNIT

A routing unit is a collection of hydrographs that can be routed to any spatial object. The routing unit can be configured as a subbasin, then total flow (surface, lateral and tile flow) from the routing unit can be sent to a channel and all recharge from the routing unit sent to an aquifer. This is analogous to the current approach in SWAT. However, SWAT+ gives us much more flexibility in configuring a routing unit. For example, in CEAP, we are routing each HRU (field) through a small channel (gully or grass waterway) before it reaches the main channel. In this case, the routing unit is a collection of flow from the small channels. We also envision simulating multiple representative hillslopes to define a routing unit. Also, we are setting up scenarios that define a routing unit using tile flow from multiple fields and sending that flow to a wetland.

The routing unit is the spatial unit SWAT+ that allows us to lump outputs and route the outputs to any other spatial object. It gives us considerably more flexibility than the old subbasin lumping approach in SWAT, and will continue to be a convenient way of spatial lumping until we can simulate individual fields or cells in each basin.

HRU.CON

The HRU.CON file contains the connectivity for the HRU spatial objects within the watershed that will be included in the simulation and is space delimited. Below is a sample HRU.CON file:

```
hru.con
NUMB NAME GIS_ID AREA LAT LONG ELEV HRU WST CONST_TYPE OVERFLOW RULESET OUT_TOT OBJ_TYP1 OBJ_ID1 HYDRO_TYP1 FRAC
 1  bench   1    0.480  0.000  0.000  0.000   1  weal      0        0       0       0       0       0       0       0
 2  field    2    495.27 0.000  0.000  0.000   2  wea2      0        0       0       0       0       0       0       0
```

Variable name	Definition
TITLE	Description of the connect file
HEADER	The header information for the HRU connect file
NUMB	Number of object unit
NAME	Name of the object connect
GIS_ID	ID number (used for GIS_ID number for manipulating databases)
AREA_HA	Area of the object (ha)
LAT	Latitude of the object
LONG	Longitude of the object
ELEV	Elevation of the object
PROPS	Object properties number (Spatial objects for PROPS abbreviations - HRU, HLT, RU, MFL, AQU, CHA, RES, REC, EXC, DR, OUT, SDC)
WST	Weather station number ('weather-sta.cli' file)
CONSTIT	Constituent data pointer (pesticides, pathogens, heavy metals, salts)
PROPS2(OVERFLOW)	Overbank connectivity pointer to landscape units
RULESET	Ruleset pointer for flow fraction of hydrograph
SRC_TOT	Total number of incoming (source) objects

OBTYP_OUT Outflow object type
 ('hru';'hlt','ru';'mfl'; aqu'; cha'; res'; exc'; dr';
 'out';'sdc') (default == 'null')

SPATIAL OBJECTS	
HRU	HYDROLOGIC RESPONSE UNIT
HLT	HRU LITE
RU	ROUTING UNIT
MFL	MODFLOW
AQU	AQUIFER
CHA	CHANNEL
RES	RESERVOIR
REC	RECALL
EXC	EXPORT COEFFICIENTS
DR	DELIVERY RATIO
CAN	CANAL
PUM	PUMP
OUT	OUTLET
SDC	SWAT DEG CHANNEL

OBTYPNO_OUT Outflow object type name

HTYP_OUT Outflow hydrograph (1='tot';
 2='rhg';3='sur';4='lat';5='til';
 (default = 'null')

OUTFLOW HYDROGRAPHS	
TOT	TOTAL
RHG	RECHARGE
SUR	SURFACE
LAT	LATERAL
TIL	TILLAGE

FRAC_OUT Fraction of hydrograph

CHANNEL – The CHANNEL section of file.cio contains the filenames for simulation of a channel in the model. In order to simulate the physical processes affecting the flow of water and transport of sediment in the channel network of the watershed, SWAT requires information on the physical characteristics of the main channel within each subbasin. The channel input files summarizes the physical characteristics of the channel which affect water flow and transport of sediment, nutrients and pesticides.

INITIAL.CHA

The INITIAL.CHA file contains the input variables for the initialization of a channel. Below is a sample INITIAL.CHA file:

initial.cha						
NAME	ORG-MIN	PESTICIDES	PATHOGENS	HEAVY_METALS	SALTS	
low_init	low_init	no_ini	no_ini	null	null	
high_init	high_init	low_ini	low_ini	null	null	

Variable name	Definition
TITLE	Title of the initial channel file
HEADER	The header information for the initial channel file
NAME	Name of the initial channel
ORG-MIN	Organic mineral in channel (points to OM_WATER.INI file)
PESTICIDES	Pesticides initialization in channel (points to PEST_WATER.INI file)
PATHOGENS	Pathogens initialization in channel (points to PATH_WATER.INI file)
HEAVY METALS	Heavy metals initialization in channel (points to HMET_WATER.INI file)
SALTS	Salts initialization in channel (points to SALT_WATER.INI file)

CHANNEL.CHA

The CHANNEL.CHA file contains the input variables for the initialization of a channel. Below is a sample CHANNEL.CHA file:

channel.cha									
CHA_NUMB	CHA_NAME	CHA_INI	CHA_HYD	CHA_SED	CHA_NUT	CHA_PST	CHA_LS_LNK	A_AQU_LNK	
1	cha1	cha_ini1	cha_hyd1	cha_sed1	cha_nut1	cha_pst1	null	null	
2	cha2	cha_ini2	cha_hyd2	cha_sed2	cha_nut2	cha_pst2	null	null	
3	cha3	cha_ini3	cha_hyd3	cha_sed3	cha_nut3	cha_pst3	null	null	
4	cha4	cha_ini4	cha_hyd4	cha_sed4	cha_nut4	cha_pst4	null	null	
5	cha5	cha_ini5	cha_hyd5	cha_sed5	cha_nut5	cha_pst5	null	null	
6	cha6	cha_ini6	cha_hyd6	cha_sed6	cha_nut6	cha_pst6	null	null	
7	cha7	cha_ini7	cha_hyd7	cha_sed7	cha_nut7	cha_pst7	null	null	

Variable name	Definition
TITLE	Description of the channel file
HEADER	The header information for the channel file
NUMB	Number of the channel
NAME	Name of the channel
INIT	Initial data (points to initial.cha)
HYD	Channel hydrology inputs (points to hydrology.cha)
SED	Channel sediment inputs (points to sediment.cha)
NUT	Channel nutrient inputs (points to nutrients.cha)
PST	Channel pesticide inputs (points to pesticide.cha)
LS_LNK	Landscape linkage (points to chan-surf.lin)
AQU_LNK	Aquifer linkage (points to chan-aqu.lin)

HYDROLOGY.CHA

The HYDROLOGY.CHA file contains the input variables for the hydrology inputs of a channel. Below is a sample HYDROLOGY.CHA file:

hydrology.cha									
NAME	W	D	S	L	N	K	WDR	ALPHA_BNK	SIDE
cha_hyd1	3.45	0.3556	0.009	0.1116	0.014	0.01	9.7	0.1	2

Variable name	Definition
HEADER	Description of the channel hydrology file
NAME	The header information for the channel hydrology file
W	Name of the channel hydrology
D	Average width of the main channel (m)
S	Average depth of the main channel (m)
L	Average slope of the main channel (m/m)
N	Main channel length (km)
K	Manning's "n" value for the main channel
WDR	Effective hydraulic conductivity of main channel alluvium (mm/hr)
ALPHA_BNK	Channel width to depth ratio (m/m)
SIDE	Alpha factor for bank storage recession curve (days)
	Change in horizontal distance per unit

SEDIMENT.CHA

The SEDIMENT.CHA file contains the input variables for the sediment inputs of a channel. Below is a sample SEDIMENT.CHA file:

sediment.cha														
NAME	EQN	COV1	COV2	BNK_BD	BED_BD	BNK_KD	BED_KD	BNK_D50	BED_D50	TC_BNK	TC_BED	EROD1	...EROD12	
cha_sed1	0	0.5	0.5	1.5	1.5	0.5	0.5	1.5	1.5	0.05	0.05	1	1	

Variable name	Definition
TITLE	Description of the sediment channel file
HEADER	The header information for the sediment channel file
NAME	Name of the sediment channel
EQN	Sediment routine methods: 0 = original SWAT method; 1 Bagnold's 2 Kodatie 3 Molinas WU 4 Yang
COV1	Channel erodibility factor (0.0-1.0)
COV2	Channel cover factor (0.0-1.0)
BNK_BD	Bulk density of channel bank sediment (g/cc)
BED_BD	Bulk density of channel bed sediment (g/cc)
BNK_KD	Erodibility of channel bank sediment by jet test
BED_KD	Erodibility of channel bed by jet test
BNK_D50	D50 (median) particle size diameter of channel bank
BED_D50	D50 (median) particle size diameter of channel bed
TC_BNK	Critical shear stress of channel bank (N/m^2)
TC_BED	Critical shear stress of channel bed (N/m^2)
EROD1-12	Value of 0.0 indicates a non-erosive channel while a value of 1.0 indicates no resistance to erosion

NUTRIENTS.CHA

The NUTRIENTS.CHA file contains the input variables for the nutrients of a channel. Below is a sample partial NUTRIENTS.CHA file:

NAME	ONCO	OPCO	RS1	RS2	RS3	RS4	RS5	RS6	RS7	RK1	RK2	RK3	RK4	RK5	RK6	BC1	BC2	BC3	BC4	LAO	IGROPT	A10	A12	A13	A14	A15	A16	MUMAX	RHOQ	TFACT	K_J	K_N	K_P	LAMBDAD	LAMDA1	LAMDA2	P_N
nut_cha1	0	0	1	0.05	0.5	0.05	0.05	2.5	2.5	1.71	1	2	0	1.71	1.71	0.55	1.1	0.21	0.35	2	2	A11	0.08	0.01	1.6	2	3.5	1.07	2	2.5	0.4	0.75	0.02	0.025	1	0.03	0.054

Variable name	Definition
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank. Optional.
HEADER	Headers for the nutrients.cha file.
NAME	Name of the nutrients channel
ONCO	Channel organic N concentration (ppm)
OPCO	Channel organic P concentration (ppm)
RS1	Local algal settling rate in the reach at 20° C (m/day). If routing is performed on an hourly time step (see IEVENT in .bsn file), the units of RS1 are converted to m/hr by the model. Values for RS1 should fall in the range 0.15 to 1.82 m/day. If no value for RS1 is entered, the model sets RS1 = 1.0 m/day. Required if in-stream nutrient cycling is being modeled.
RS2	Benthic (sediment) source rate for dissolved phosphorus in the reach at 20° C (mg dissolved P/(m ² ·day)). If routing is performed on an hourly time step (see IEVENT in .bsn file), the units of RS2 are converted to mg dissolved P/(m ² ·hr) by the model. If no value for RS2 is entered, the model sets RS2 = 0.05 mg dissolved P/(m ² ·day). Required if in-stream nutrient cycling is being modeled.
RS3	Benthic source rate for NH ₄ -N in the reach at 20° C (mg NH ₄ -N/(m ² ·day)). If routing is performed on an hourly time step (see IEVENT in .bsn file), the units of RS3 are converted to mg NH ₄ -N/(m ² ·hr) by the model. If no value for RS3 is entered, the model sets RS3 = 0.5 mg NH ₄ -N/(m ² ·day). Required if in-stream nutrient cycling is being modeled.

Variable name	Definition
RS4	<p>Rate coefficient for organic N settling in the reach at 20° C (day⁻¹).</p> <p>If routing is performed on an hourly time step (see IEVENT in .bsn file), the units of RS4 are converted to hr⁻¹ by the model. Values for RS4 should fall in the range 0.001 to 0.10 day⁻¹. If no value for RS4 is entered, the model sets RS4 = 0.05 day⁻¹.</p> <p><i>Required if in-stream nutrient cycling is being modeled.</i></p>
RS5	<p>Organic phosphorus settling rate in the reach at 20° C (day⁻¹).</p> <p>If routing is performed on an hourly time step (see IEVENT in .bsn file), the units of RS5 are converted to hr⁻¹ by the model. Values for RS5 should fall in the range 0.001 to 0.1 day⁻¹. If no value for RS5 is entered, the model sets RS5 = 0.05 day⁻¹.</p> <p><i>Required if in-stream nutrient cycling is being modeled.</i></p>
RS6	<p>Rate coefficient for settling of arbitrary non-conservative constituent in the reach at 20° C (day⁻¹).</p> <p>If no value for RS6 is entered, the model sets RS6 = 2.5.</p> <p><i>Not currently used by the model.</i></p>
RS7	<p>Benthic source rate for arbitrary non-conservative constituent in the reach at 20° C (mg ANC/(m²·day)).</p> <p>If no value for RS7 is entered, the model sets RS7 = 2.5.</p> <p><i>Not currently used by the model.</i></p>
RK1	<p>Carbonaceous biological oxygen demand deoxygenation rate coefficient in the reach at 20° C (day⁻¹).</p> <p>If routing is performed on an hourly time step (see IEVENT in .bsn file), the units of RK1 are converted to hr⁻¹ by the model. Values for RK1 should fall in the range 0.02 to 3.4 day⁻¹. If no value for RK1 is entered, the model sets RK1 = 1.71 day⁻¹.</p> <p><i>Required if in-stream nutrient cycling is being modeled.</i></p>

Variable name	Definition
RK2	<p>Oxygen reaeration rate in accordance with Fickian diffusion in the reach at 20° C (day⁻¹).</p> <p>Numerous methods have been developed to calculate the reaeration rate at 20°C, $\kappa_{2,20}$. A few of the methods are listed below. Brown and Barnwell (1987) provide additional methods.</p> <p>Using field measurements, Churchill, Elmore and Buckingham (1962) derived the relationship:</p> $\kappa_{2,20} = 5.03 \cdot v_c^{0.969} \cdot depth^{-1.673}$ <p>where $\kappa_{2,20}$ is the reaeration rate at 20°C (day⁻¹), v_c is the average stream velocity (m/s), and depth is the average stream depth (m).</p> <p>O'Connor and Dobbins (1958) incorporated stream turbulence characteristics into the equations they developed. For streams with low velocities and isotropic conditions,</p> $\kappa_{2,20} = 294 \cdot \frac{(D_m \cdot v_c)^{0.5}}{depth^{1.5}}$ <p>where $\kappa_{2,20}$ is the reaeration rate at 20°C (day⁻¹), D_m is the molecular diffusion coefficient (m²/day), v_c is the average stream velocity (m/s), and <i>depth</i> is the average stream depth (m). For streams with high velocities and nonisotropic conditions,</p> $\kappa_{2,20} = 2703 \cdot \frac{D_m^{0.5} \cdot slp^{0.25}}{depth^{1.25}}$ <p>where $\kappa_{2,20}$ is the reaeration rate at 20°C (day⁻¹), D_m is the molecular diffusion coefficient (m²/day), <i>slp</i> is the slope of the streambed (m/m), and <i>depth</i> is the average stream depth (m). The molecular diffusion coefficient is calculated</p> $D_m = 177 \cdot 1.037^{\bar{T}_{water}-20}$ <p>where D_m is the molecular diffusion coefficient (m²/day), and \bar{T}_{water} is the average water temperature (°C).</p>

Variable name	Definition
RK2, cont.	<p>Owens et al. (1964) developed an equation to determine the reaeration rate for shallow, fast moving streams where the stream depth is 0.1 to 3.4 m and the velocity is 0.03 to 1.5 m/s.</p> $\kappa_{2,20} = 5.34 \cdot \frac{v_c^{0.67}}{\text{depth}^{1.85}}$ <p>where $\kappa_{2,20}$ is the reaeration rate at 20°C (day⁻¹), v_c is the average stream velocity (m/s), and depth is the average stream depth (m).</p> <p>If routing is performed on an hourly time step (see IEVENT in .bsn file), the units of RK2 are converted to hr⁻¹ by the model. Values for RK2 should fall in the range 0.01 to 100.0 day⁻¹. If no value for RK2 is entered, the model sets RK2 = 50.0 day⁻¹.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
RK3	<p>Rate of loss of carbonaceous biological oxygen demand due to settling in the reach at 20° C (day⁻¹).</p> <p>Values for RK3 should fall in the range -0.36 to 0.36 day⁻¹. The recommended default for RK3 is 0.36 day⁻¹ (not set by model).</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
RK4	<p>Benthic oxygen demand rate in the reach at 20° C (mg O₂/(m²·day)).</p> <p>If routing is performed on an hourly time step (see IEVENT in .bsn file), the units of RK4 are converted to (mg O₂/(m²·hr)) by the model. If no value for RK4 is entered, the model sets RK4 = 2.0 mg O₂/(m²·day).</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
RK5	<p>Coliform die-off rate in the reach at 20° C (day⁻¹).</p> <p>Values for RK5 should fall in the range 0.05 to 4.0. If no value for RK5 is entered, the model sets RK5 = 2.0.</p> <p><i>Not currently used by the model.</i></p>
RK6	<p>Decay rate for arbitrary non-conservative constituent in the reach at 20° C (day⁻¹).</p> <p>If no value for RK6 is entered, the model sets RK6 = 1.71.</p> <p><i>Not currently used by the model.</i></p>

Variable name	Definition
BC1	<p>Rate constant for biological oxidation of NH₄ to NO₂ in the reach at 20° C in well-aerated conditions (day⁻¹).</p> <p>If routing is performed on an hourly time step (see IEVENT in .bsn file), the units of BC1 are converted to hr⁻¹ by the model. Values for BC1 should fall in the range 0.1 to 1.0 day⁻¹. If no value for BC1 is entered, the model sets BC1 = 0.55 day⁻¹.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
BC2	<p>Rate constant for biological oxidation of NO₂ to NO₃ in the reach at 20° C in well-aerated conditions (day⁻¹).</p> <p>If routing is performed on an hourly time step (see IEVENT in .bsn file), the units of BC2 are converted to hr⁻¹ by the model. Values for BC2 should fall in the range 0.2 to 2.0 day⁻¹. If no value for BC2 is entered, the model sets BC2 = 1.1 day⁻¹.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
BC3	<p>Rate constant for hydrolysis of organic N to NH₄ in the reach at 20° C (day⁻¹).</p> <p>If routing is performed on an hourly time step (see IEVENT in .bsn file), the units of BC3 are converted to hr⁻¹ by the model. Values for BC3 should fall in the range 0.2 to 0.4 day⁻¹. If no value for BC3 is entered, the model sets BC3 = 0.21 day⁻¹.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
BC4	<p>Rate constant for mineralization of organic P to dissolved P in the reach at 20° C (day⁻¹).</p> <p>If routing is performed on an hourly time step (see IEVENT in .bsn file), the units of BC4 are converted to hr⁻¹ by the model. Values for BC4 should fall in the range 0.01 to 0.70 day⁻¹. If no value for BC4 is entered, the model sets BC4 = 0.35 day⁻¹.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>

LAO

Qual2E light averaging option. Qual2E defines four light averaging options.

- 1 Depth-averaged algal growth attenuation factor for light (FL) is computed from one daylight average solar radiation value calculated in the steady state temperature heat balance.
- 2 FL is computed from one daylight average solar radiation value supplied by the user.
- 3 FL is obtained by averaging the hourly daylight values of FL computed from the hourly daylight values of solar radiation calculated in the steady state temperature heat balance.
- 4 FL is obtained by averaging the hourly daylight values of FL computed from the hourly daylight values of solar radiation calculated from a single value of total daily, photosynthetically active, solar radiation and an assumed cosine function.

The only option currently active in SWAT is 2.

Required if in-stream nutrient cycling is being modeled.

IGROPT

Qual2E algal specific growth rate option. Qual2E provides three different options for computing the algal growth rate.

- 1 Multiplicative: the effects of nitrogen, phosphorus and light are multiplied together to calculate the net effect on the local algal growth rate
 - 2 Limiting nutrient: the local algal growth rate is limited by light and one of the nutrients (nitrogen or phosphorus)
 - 3 Harmonic mean: the local algal growth rate is limited by light and the harmonic mean of the nutrient interactions
-

Variable name	Definition
IGROPT, cont.	<p>The multiplicative option multiplies the growth factors for light, nitrogen and phosphorus together to determine their net effect on the local algal growth rate. This option has its biological basis in the mutiplicative effects of enzymatic processes involved in photosynthesis.</p> <p>The limiting nutrient option calculates the local algal growth rate as limited by light and either nitrogen or phosphorus. The nutrient/light effects are multiplicative, but the nutrient/nutrient effects are alternate. The algal growth rate is controlled by the nutrient with the smaller growth limitation factor. This approach mimics Liebig's law of the minimum.</p> <p>The harmonic mean is mathematically analogous to the total resistance of two resistors in parallel and can be considered a compromise between the multiplicative and limiting nutrient options. The algal growth rate is controlled by a multiplicative relation between light and nutrients, while the nutrient/nutrient interactions are represented by a harmonic mean.</p> <p>The default option is the limiting nutrient option (2).</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
AI0	<p>Ratio of chlorophyll-a to algal biomass ($\mu\text{g-chla}/\text{mg algae}$).</p> <p>Values for AI0 should fall in the range 10-100. If no value for AI0 is entered, the model will set AI0 = 50.0.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
AI1	<p>Fraction of algal biomass that is nitrogen ($\text{mg N}/\text{mg alg}$).</p> <p>Values for AI1 should fall in the range 0.07-0.09. If no value for AI1 is entered, the model will set AI1 = 0.08.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
AI2	<p>Fraction of algal biomass that is phosphorus ($\text{mg P}/\text{mg alg}$).</p> <p>Values for AI2 should fall in the range 0.01-0.02. If no value for AI2 is entered, the model will set AI2 = 0.015.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
AI3	<p>The rate of oxygen production per unit of algal photosynthesis ($\text{mg O}_2/\text{mg alg}$).</p> <p>Values for AI3 should fall in the range 1.4-1.8. If no value for AI3 is entered, the model will set AI3 = 1.6.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>

Variable name	Definition
AI4	<p>The rate of oxygen uptake per unit of algal respiration (mg O₂/mg alg).</p> <p>Values for AI4 should fall in the range 1.6-2.3. If no value for AI4 is entered, the model will set AI4 = 2.0.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
AI5	<p>The rate of oxygen uptake per unit of NH₃-N oxidation (mg O₂/mg NH₃-N).</p> <p>Values for AI5 should fall in the range 3.0-4.0. If no value for AI5 is entered, the model will set AI5 = 3.5.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
AI6	<p>The rate of oxygen uptake per unit of NO₂-N oxidation (mg O₂/mg NO₂-N).</p> <p>Values for AI6 should fall in the range 1.00-1.14. If no value for AI6 is entered, the model will set AI6 = 1.07.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
MUMAX	<p>Maximum specific algal growth rate at 20° C (day⁻¹).</p> <p>If routing is performed on an hourly time step (see IEVENT in .bsn file), MUMAX is converted to (hr⁻¹) by the model. Values for MUMAX should fall in the range 1.0-3.0. If no value for MUMAX is entered, the model will set MUMAX = 2.0.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
RHOQ	<p>Algal respiration rate at 20° C (day⁻¹).</p> <p>If routing is performed on an hourly time step (see IEVENT in .bsn file), RHOQ is converted to (hr⁻¹) by the model. Values for RHOQ should fall in the range 0.05-0.50. If no value for RHOQ is entered, the model will set RHOQ = 0.30.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
TFACT	<p>Fraction of solar radiation computed in the temperature heat balance that is photosynthetically active.</p> <p>Values for TFACT should fall in the range 0.01-1.0. If no value for TFACT is entered, the model will set TFACT = 0.3.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>

Variable name	Definition
K_L	<p>Half-saturation coefficient for light (kJ/(m²·min)).</p> <p>Values for K_L should fall in the range 0.2227-1.135. If no value for K_L is entered, the model will set K_L = 0.75.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
K_N	<p>Michaelis-Menton half-saturation constant for nitrogen (mg N/L).</p> <p>The Michaelis-Menton half-saturation constant for nitrogen and phosphorus define the concentration of N or P at which algal growth is limited to 50% of the maximum growth rate.</p> <p>Typical values for K_N range from 0.01 to 0.30 mg N/L. Values for K_N should fall in the range 0.01-0.30. If no value for K_N is entered, the model will set K_N = 0.02.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
K_P	<p>Michaelis-Menton half-saturation constant for phosphorus (mg P/L).</p> <p>The Michaelis-Menton half-saturation constant for nitrogen and phosphorus define the concentration of N or P at which algal growth is limited to 50% of the maximum growth rate.</p> <p>Typical values for K_P will range from 0.001 to 0.05 mg P/L. If no value for K_P is entered, the model will set K_P = 0.025.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
LAMBDA0	<p>Non-algal portion of the light extinction coefficient (m⁻¹).</p> <p>The light extinction coefficient, k_ℓ, is calculated as a function of the algal density using the nonlinear equation:</p> $k_\ell = k_{\ell,0} + k_{\ell,1} \cdot \alpha_0 \cdot algae + k_{\ell,2} \cdot (\alpha_0 \cdot algae)^{2/3}$ <p>where $k_{\ell,0}$ is the non-algal portion of the light extinction coefficient (m⁻¹), $k_{\ell,1}$ is the linear algal self shading coefficient (m⁻¹ (μg-chla/L)⁻¹), $k_{\ell,2}$ is the nonlinear algal self shading coefficient (m⁻¹ (μg-chla/L)^{-2/3}), α_0 is the ratio of chlorophyll <i>a</i> to algal biomass (μg chla/mg alg), and <i>algae</i> is the algal biomass concentration (mg alg/L).</p>

Variable name	Definition
LAMBDA0, cont.	<p>This equation allows a variety of algal, self-shading, light extinction relationships to be modeled. When $k_{\ell,1} = k_{\ell,2} = 0$, no algal self-shading is simulated. When $k_{\ell,1} \neq 0$ and $k_{\ell,2} = 0$, linear algal self-shading is modeled. When $k_{\ell,1}$ and $k_{\ell,2}$ are set to a value other than 0, non-linear algal self-shading is modeled. The Riley equation (Bowie et al., 1985) defines $k_{\ell,1} = 0.0088 \text{ m}^{-1} (\mu\text{g - chla/L})^{-1}$ and $k_{\ell,2} = 0.054 \text{ m}^{-1} (\mu\text{g - chla/L})^{-2/3}$.</p> <p>If no value for LAMBDA0 is entered, the model will set LAMBDA0 = 1.0.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
LAMBDA1	<p>Linear algal self-shading coefficient ($\text{m}^{-1} \cdot (\mu\text{g chla/L})^{-1}$).</p> <p>See explanation for LAMBDA0 for more information on this variable.</p> <p>Values for LAMBDA1 should fall in the range 0.0065-0.065. If no value for LAMBDA1 is entered, the model will set LAMBDA1 = 0.03.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
LAMBDA2	<p>Nonlinear algal self-shading coefficient ($\text{m}^{-1} \cdot (\mu\text{g chla/L})^{-2/3}$).</p> <p>See explanation for LAMBDA0 for more information on this variable.</p> <p>The recommended value for LAMBDA2 is 0.0541. If no value for LAMBDA2 is entered, the model will set LAMBDA2 = 0.054.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>
P_N	<p>Algal preference factor for ammonia.</p> <p>Values for P_N should fall in the range 0.01-1.0. If no value for P_N is entered, the model will set P_N = 0.5.</p> <p>Required if in-stream nutrient cycling is being modeled.</p>

PATHOGENS.CHA

The PATHOGENS.CHA file contains the input variables for the nutrients of a channel. Below is a sample partial PATHOGENS.CHA file: (no file included in this revision)

Variable name	Definition
TITLE	This line is reserved for the pesticide section title. This line is not processed by the model and may be left blank.
HEADER	Headings
NAME	Name of the pathogens channel

METALS.CHA

The METALS.CHA file contains the input variables for the nutrients of a channel. Below is a sample partial METALS.CHA file: (no file included in this revision)

Variable name	Definition
TITLE	This line is reserved for the pesticide section title. This line is not processed by the model and may be left blank.
HEADER	Headings
NAME	Name of the metals channel

SALT,CHA

The SALT.CHA file contains the input variables for the nutrients of a channel. Below is a sample partial SALT.CHA file: (no file included in this revision)

Variable name	Definition
TITLE	This line is reserved for the pesticide section title. This line is not processed by the model and may be left blank.
HEADER	Headings
NAME	Name of the salt channel

CHANNEL-LTE.CHA

The CHANNEL-LTE.CHA file contains the input variables for the nutrients of a channel. Below is a sample CHANNEL-LTE.CHA file:

Variable name	Definition
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank.
	Optional.
HEADER	Headers for the channel-lte file.
NAME	Name of the nutrients channel lte
CHA_INI	Channel lte initial file (points to initial.cha file)
CHA_HYD	Channel lte hydrology file (points to hyd-sed-lte.cha file)
CHA_SED	Channel lte sediment file (points to hyd-sed-lte.cha file)
CHA_NUT	Channel lte nutrient file (points to nutrient.cha file)
CHA_PST	Channel lte pesticide file (points to pesticide.cha file)
CHA_PATH	Channel lte pathogen file (points to pathogen.cha file)
CHA_HMET	Channel lte heavy metals file (points to hmet.cha file)
CHA_SALT	Channel lte salt file (points to salt.cha file)
CH_TEMP	Channel lte temperature file (points to temperature.cha file)

HYD-SED-LTE.CHA

The HYD-SED-LTE.CHA file contains the input variables for the nutrients of a channel. Below is a sample HYD-SED-LTE.CHA file:

NAME	ORDER	RTE_DB	CHW	CHD	CHS	CHL	CHN	CHK	CHEROD	CHCOV	HC_COV	CHSEQ	D50	CLAY	CARBON	BD	CHSS	BEDLD	TC	SHEAR_BN	HC_KH	HC_HGT	HC_INI	
1st_stage	ditch	nut1		4	0.5	0.005	0.6	0.1	1	0.01	0.005	0.005	0.001	12	30	0.04	1.5	0.5	0.5	120	0.75	0.2	0	0
Gully_hru2	gully	nut1		5.5	0.71	0.007	8	0.05	1	0.01	0.005	0.005	0.001	12	30	0.04	1.5	0.5	0.5	120	0.75	0.2	0.4	0
First_Ord1	first	nut1		6.5	0.71	0.007	8	0.05	1	0.01	0.005	0.005	0.001	12	30	0.04	1.5	0.5	0.5	120	0.75	0.05	0.5	0

Variable name	Definition
TITLE	Description of the time.sim file (may be blank)
HEADER	Headers for variables
NAME	Channel lte name
ORDER	Stream order
RTE_NUT	Pointer to routing nutrient data in nutrients.cha file
CHW	Channel lte width (m)
CHD	Channel lte depth (m)
CHS	Channel lte slope (m/m)
CHL	Channel lte length (km)
CHN	Channel lte Manning's N
CHK	Channel lte bottom conductivity (mm/h)

CHEROD	Channel lte erodibility factor (0=non-erosive channel; 1=no resistance to erosion)
CHCOV	Channel lte cover factor (0=channel is completely protected from erosion; 1=no vegetative cover on channel)
HC_COV	Heat cut cover factor (0-1)
CHSEQ	Channel lte equilibrium channel slope (m/m)
D50	Channel lte median sediment size (%)
CLAY	Channel lte clay percent of bank and bed (%)
CARBON	Carbon percent of bank and bed (%)
BD	Channel lte dry bulk density (t/m3)
CHSS	Channel lte side slope
BED_LOAD	Percent of sediment entering the channel lte that is bed material (%)
TC	Channel lte time of concentration
SHEAR_BNK	Channel lte bank shear coefficient – fraction of bottom shape
HC_KH	Channel lte headcut erodibility
HC_HGT	Channel lte headcut height (m)
HC_INI	Initial channel lte length for gullies

TEMPERATURE.CHA

The TEMPERATURE.CHA file contains the input variables for the nutrients of a channel. Below is a sample TEMPERATURE.CHA file:

temperature.cha					
NAME	SNO_MLT	GW	SUR_LAT	BULK_CO	AIR_LAG
CHA1	1.0	0.97	1.0	0.0025	6.0

Variable name	Definition
TITLE	Description of the time.sim file (may be blank)
HEADER	Headers for variables
NAME	Channel lte name
SNO_MLT	Coefficient influencing snowmelt temperature contributions
GW	Coefficient influencing groundwater temperature contributions
SUR_LAT	Coefficient influencing surface and lateral flow temperature contributions
BULK_CO	Bulk coefficient of heat transfer (1/hour)

AIR_LAG Average air temperature lag (days)

RESERVOIR – The RESERVOIR section of file.cio contains the filenames for simulation of a reservoirs in the model. Reservoirs are impoundments located on the main channel network of the watershed. Reservoirs receive loadings from all upstream subbasins. The reservoir input file (.res) contains input data to simulate water and sediment processes.

INITIAL.RES

The INITIAL.RES file contains the input variables for the initialization of a channel. Below is a sample partial INITIAL.RES file: (this file will change in Rev54)

initial.res: Reservoir data file - asdf;lj														
NAME	VOL	SED	ORGN	NO3	NO2	NH3	ORGP	SOLP	SECI	SAN	SIL	CLA	SAG	LAG
reservoir001	0.90	200.00	10.00	2.00	0.20	0.10	1.00	0.10	1.00	0.00	1.00	9.00	0.00	0.00

Variable name	Definition
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank. Optional.
HEADER	Headers for the initial_res file.
NAME	Initial name of the reservoir
VOL	Initial reservoir volume. If the reservoir is in existence at the beginning of the simulation period, the initial reservoir volume is the volume on the first day of simulation. If the reservoir begins operation in the midst of a SWAT simulation, the initial reservoir volume is the volume of the reservoir the day the reservoir becomes operational (10^4 m^3).
SED	Initial sediment concentration in the reservoir (mg/L). If the reservoir is in existence at the beginning of the simulation period, the initial sediment concentration is the concentration on the first day of simulation. If the reservoir begins operation in the midst of a SWAT simulation, the initial sediment concentration is the concentration the day the reservoir becomes operational (mg/L).
ORGN	Amount of organic N in reservoir
NO3	Initial concentration of NO ₃ -N in reservoir (mg N/L).
NO2	Initial concentration of NO ₂ -N in reservoir (mg N/L).
NH3	Initial concentration of NH ₃ -N (ammonia) in reservoir (mg N/L).

ORGP

Initial concentration of organic P in reservoir (mg P/L).

We recommend using a 1 year equilibration period for the model where the watershed simulation is set to start 1 year prior to the period of interest. This allows the model to get the water cycling properly before any comparisons between measured and simulated data are made. When an equilibration period is incorporated, the value for ORGP is not going to be important if the reservoir is in operation at the beginning of the simulation. However, if the reservoir starts operation in the middle of a simulation, this value needs to be reasonably accurate.

SOLP

Amount of soluble phosphorus in the reservoir
(read in as mg/L and converted to kg/L)

See comment for ORGP.

SECI

Secchi-disk depth(m)

SAN

Amount of sand in the reservoir

(read in as mg/L and converted to kg/L)

SIL

Amount of silt in the reservoir

(read in as mg/L and converted to kg/L)

CLA

Amount of clay in the reservoir

(read in as mg/L and converted to kg/L)

SAG

Amount of small aggregates in the reservoir

(read in as mg/L and converted to kg/L)

LAG

Amount of large aggregates in the reservoir

(read in as mg/L and converted to kg/L)

GRA

Amount of gravel in the reservoir

(read in as mg/L and converted to kg/L)

CHLA

Amount of chlorophyll-s in the reservoir

(read in as mg/L and converted to kg/L)

RESERVOIR.RES

The reservoir input file (.res) contains input data to simulate water and sediment processes while the lake water quality file (.lwq) contains input data to simulate nutrient and pesticide cycling in the water body.

Below is a sample RESERVOIR.RES file:

reservoir.res

RES_NUMB	RES_NAME	RES_INI	RES_HYD	RELEASE	RES_SED	RES_NUT	RES_PST
1	pnd1	res001	pnd1	lrew_sm_res	res001	res001	res001
2	pnd2	res001	pnd2	lrew_sm_res	res001	res001	res001
3	pnd3	res001	pnd3	lrew_sm_res	res001	res001	res001
4	pnd4	res001	pnd4	lrew_sm_res	res001	res001	res001
5	pnd5	res001	pnd5	lrew_sm_res	res001	res001	res001
6	pnd6	res001	pnd6	lrew_sm_res	res001	res001	res001
7	pnd7	res001	pnd7	lrew_sm_res	res001	res001	res001

Variable name	Definition
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank. <u>Optional.</u>
HEADER	Headers for the reservoir.res file.
NUMB	The number of the reservoir
NAME	The name of the reservoir
VARIABLE NAME	The initial data points to 'initial.res' file.
INIT	The initial data (points to initial.res file)
HYD	Hydraulic conductivity of the reservoir bottom (mm/hr). If seepage occurs in the water body, the hydraulic conductivity must be set to a value other than 0. (points to hydrology.res file)
RELEASE	Average daily principal spillway release rate (m^3/s). The name for this variable is slightly misleading. SWAT uses this variable when the volume of water in the reservoir is between the principal and emergency spillway volumes. If the amount of water exceeding the principal spillway volume can be released at a rate \leq REL, than all of the water volume in excess of the principal spillway volume is released. Otherwise the release rate, REL is used. (points to release.res file)
SED	Initial sediment concentration in the reservoir (mg/L). If the reservoir is in existence at the beginning of the simulation period, the initial sediment concentration is the concentration on the first day of simulation. If the reservoir begins operation in the midst of a SWAT simulation, the initial sediment concentration is the concentration the day the reservoir becomes operational (mg/L). (points to sediment.res file)
NUT	Nutrient inputs (points to nutrients.res file)
PST	Pesticide inputs (points to pesticide.res file)

HYDROLOGY.RES

Reservoirs are impoundments located on the main channel network of the watershed. Reservoirs receive loadings from all upstream subbasins. The reservoir input file (.res) contains input data to simulate water and sediment processes while the lake water quality file (.lwq) contains input data to simulate nutrient and pesticide cycling in the water body.

Below is a sample HYDROLOGY.RES file:

hydrology.res											
RES_HYD_NAM	YR_OP	MON_OP	AREA_PS	VOL_PS	AREA_ES	VOL_ES	RES_K	EVAP_CO	SHP_CO_1	SHP_CO_2	
pnd1	0	0	4.95	12.375	5.445	13.613	0	1	0	0	
pnd2	0	0	4.41	11.025	4.851	12.128	0	1	0	0	
pnd3	0	0	3.06	7.65	3.366	8.415	0	1	0	0	
pnd4	0	0	8.55	21.375	9.405	23.513	0	1	0	0	
pnd5	0	0	2.16	5.4	2.376	5.94	0	1	0	0	
pnd6	0	0	2.52	6.3	2.772	6.93	0	1	0	0	
pnd7	0	0	0.63	1.575	0.693	1.733	0	1	0	0	
pnd8	0	0	5.76	14.4	6.336	15.84	0	1	0	0	

Variable name **Definition**

TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank.
	Optional.
HEADER	Headers for the hydrology.res file.
NAME	The name of the reservoir
IYRES	Year the reservoir became operational (eg 1980).
	If 0 is input for MORES and IYRES, the model assumes the reservoir is in operation at the beginning of the simulation.
	Required.
MORES	Month the reservoir became operational (0-12).
	If 0 is input for MORES and IYRES, the model assumes the reservoir is in operation at the beginning of the simulation.
	Required.
PSA	Reservoir surface area when the reservoir is filled to the principal spillway (ha).
	See comment for ESA.
	Required.
PVOL	Volume of water needed to fill the reservoir to the principal spillway (10^4 m^3).
	See comment for RES_ESA.
	Required.

ESA Reservoir surface area when the reservoir is filled to the emergency spillway (ha).

For SWAT to calculate the reservoir surface area each day the surface area at two different water volumes must be defined. Variables referring to the principal spillway can be thought of as variables referring to the normal reservoir storage volume while variables referring to the emergency spillway can be thought of as variables referring to maximum reservoir storage volume.

Required.

EVOL Volume of water needed to fill the reservoir to the emergency spillway (10^4 m^3).

See comment for RES_ESA.

Required.

K Hydraulic conductivity of the reservoir bottom (mm/hr).

If seepage occurs in the water body, the hydraulic conductivity must be set to a value other than 0.

Required.

EVRSV Lake evaporation coefficient.

Default = 0.6

Required.

BR1 Vol_surface area coefficient for reservoirs (model estimates if zero)

BR2 Vol_surface area coefficient for reservoirs (model estimates if zero)

NUTRIENTS.RES

While water quality is a broad subject, the primary areas of concern are nutrients, organic chemicals—both agricultural (pesticide) and industrial, heavy metals, bacteria and sediment levels in streams and large water bodies. SWAT is able to model processes affecting nutrient, pesticide and sediment levels in the main channels and reservoirs.

Below is a sample partial NUTRIENTS.RES file:

nutrients.res:	RES_NUT_NAM	MID_BEG	MID_END	MID_N_STL	N_STL	MID_P_STL	P_STL	CHLA_CO	SECCI_CO	THETA_N	THETA_P	CONC_NMIN	CONC_PMIN
res001		4	10	0.5	2	1	0.5	1	1	1	1	0.1	0.01

Variable name	Definition
---------------	------------

TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank.
	Optional.
HEADER	Headers for the nutrients.res file.
NAME	The name of the reservoir
IRES1	Beginning month of mid-year nutrient settling period. The model allows the user to define two settling rates for each nutrient and the time of the year during which each settling rate is used. A variation in settling rates is allowed so that impact of temperature and other seasonal factors may be accounted for in the modeling of nutrient settling. To use only one settling rate for the entire year, both variables for the nutrient may be set to the same value. Setting all variables to zero will cause the model to ignore settling of nutrients in the water body.
	Required.
IRES2	Ending month of mid-year nutrient settling period. See comment for IRES1.
	Required.

NSETLR1 Nitrogen settling rate in reservoir for months IRES1 through IRES2 (m/year).

See explanation for PSETLR1 for more information about this parameter.

Required if nutrient cycling is being modeled.

NSETLR2 Nitrogen settling rate in reservoir for months other than IRES1-IRES2 (m/year).

See explanation for PSETLR1 for more information about this parameter.

Required if nutrient cycling is being modeled.

PSETLR1 Phosphorus settling rate in reservoir for months IRES1 through IRES2 (m/year).

The apparent settling velocity is most commonly reported in units of m/year and this is how the values are input to the model. For natural lakes, measured phosphorus settling velocities most frequently fall in the range of 5 to 20 m/year although values less than 1 m/year to over 200 m/year have been reported (Chapra, 1997). Panuska and Robertson (1999) noted that the range in apparent settling velocity values for man-made reservoirs tends to be significantly greater than for natural lakes. Higgins and Kim (1981) reported phosphorus apparent settling velocity values from -90 to 269 m/year for 18 reservoirs in Tennessee with a median value of 42.2 m/year. For 27 Midwestern reservoirs, Walker and Kiihner (1978) reported phosphorus apparent settling velocities ranging from -1 to 125 m/year with an average value of 12.7 m/year. A negative settling rate indicates that the reservoir sediments are a source of N or P; a positive settling rate indicates that the reservoir sediments are a sink for N or P.

Table 30-1 summarizes typical ranges in phosphorus settling velocity for different systems.

Required if nutrient cycling is being modeled.

Table 30-1: Recommended apparent settling velocity values for phosphorus (Panuska and Robertson, 1999)

Nutrient Dynamics	Range in settling velocity values (m/year)
Shallow water bodies with high net internal phosphorus flux	$v \leq 0$
Water bodies with moderate net internal phosphorus flux	$1 < v <$
Water bodies with minimal net internal phosphorus flux	$5 < v <$
Water bodies with high net internal phosphorus removal	$v > 10$

PSETLR2	Phosphorus settling rate in reservoir for months other than IRES1-IRES2 (m/year). See explanation for PSETLR1 for more information about this parameter. Required if nutrient cycling is being modeled.
---------	---

Variable name	Definition
CHLAR	Chlorophyll <i>a</i> production coefficient for reservoir. Chlorophyll <i>a</i> concentration in the reservoir is calculated from the total phosphorus concentration. The equation assumes the system is phosphorus limited. The chlorophyll <i>a</i> coefficient was added to the equation to allow the user to adjust results to account for other factors not taken into account by the basic equation such as nitrogen limitations. The default value for CHLAR is 1.00, which uses the original equation. Required if nutrient cycling is being modeled.
SECCIR	Water clarity coefficient for the reservoir. The clarity of the reservoir is expressed by the secci-disk depth (m) which is calculated as a function of chlorophyll <i>a</i> . Because suspended sediment also can affect water clarity, the water clarity coefficient has been added to the equation to allow users to adjust for the impact of factors other than chlorophyll <i>a</i> on water clarity. The default value for SECCIR is 1.00, which uses the original equation. Required if nutrient cycling is being modeled.
THETA_N	Temperature adjustment for nitrogen loss (settling)
THETA_P	Temperature adjustment for phosphorus loss (settling)
CONC_NMIN	Minimum nitrogen concentration for settling (ppm)
CONC_PMIN	Minimum phosphorus concentration for settling (ppm)

PATHOGENS.RES

The PATHOGENS.RES file contains the input variables for the nutrients of a channel. Below is a sample partial PATHOGENS.RES file:

Variable name	Definition
TITLE	This line is reserved for the pesticide section title. This line is not processed by the model and may be left blank.
HEADER	Headings
NAME	Name of the pathogens reservoir

METALS.RES

The METALS.CHA file contains the input variables for the nutrients of a channel. Below is a sample partial METALS.CHA file:

Variable name	Definition
TITLE	This line is reserved for the pesticide section title. This line is not processed by the model and may be left blank.
HEADER	Headings
NAME	Name of the metals reservoir

SALT.RES

The SALT.RES file contains the input variables for the nutrients of a channel. Below is a sample partial SALT.RES file:

Variable name	Definition
TITLE	This line is reserved for the pesticide section title. This line is not processed by the model and may be left blank.
HEADER	Headings
NAME	Name of the salt reservoir

SEDIMENT.RES

Reservoirs are impoundments located on the main channel network of the watershed. Reservoirs receive loadings from all upstream subbasins. The reservoir input file (.res) contains input data to simulate water and sediment processes while the lake water quality file (.lwq) contains input data to simulate nutrient and pesticide cycling in the water body. Below is a sample SEDIMENT.RES file:

sediment.res						
NAME	NSED	D50	CARBON	BULK_DENS	SED_SETLR	VELSETLR
sw_us_med	100	20	0.04	0.8	0.15	0.0002

Variable name	Definition
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank. Optional.
HEADER	Headers for the sediment.res file.
NAME	The name of the reservoir
NSED	Equilibrium sediment concentration in the reservoir (mg/L). The amount of suspended solid settling that occurs in the water body on a given day is calculated as a function of concentration. Settling occurs only when the sediment concentration in the water body exceeds the equilibrium sediment concentration specified by the user. Required.

D50

Median particle diameter of sediment (μm).

Sediment Class	Size (μm)	Approx. Size
Boulders	> 256,000	> Volley ball
Cobbles	> 64,000	> Tennis ball
Pebbles	> 2,000	> Match Head
Sand		
V. Course	1,500	
Medim	375	
V. Fine	94	
Silt		
V. Coarse	47	
Medium	11.7	No longer visible to the human eye
V. Fine	4.9	
Clay	1.95	

SWAT calculates the median sediment particle diameter for impoundments located within a subbasin using the equation:

$$d_{50} = \exp\left(0.41 \cdot \frac{m_c}{100} + 2.71 \cdot \frac{m_{silt}}{100} + 5.7 \cdot \frac{m_s}{100}\right)$$

where d_{50} is the median particle size of the sediment (μm), m_c is percent clay in the surface soil layer, m_{silt} is the percent silt in the surface soil layer, m_s is the percent sand in the surface soil layer.

Because reservoirs are located on the main channel network and receive sediment from the entire area upstream, defaulting the sand, silt, and clay fractions to those of a single subbasin or HRU in the upstream area is not appropriate. Instead the user is allowed to set the median particle size diameter to a representative value.

If no value is defined for the median particle diameter, the model will set RES_D50 = 10 μm .

Required.

CARBON

Organic carbon in suspended and benthic sediment (%)

BD

Bulk density of benthic sediment (t/m^3)

SED_STLR

Sediment settling rate

VELSETLR

Sediment settling velocity (m/d)

WEIR.RES

Below is a sample WEIR.RES file:

weir.res:							
WEIR_NAME	NUM_STEPS	C	K	W	BCOEF	CCOEF	
shape001	24		1	15000	2	1.75	1

Variable name	Definition
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank. Optional.
HEADER	Headers for the weir.res file.
NAME	The name of the reservoir
NUM_STEPS	The number of time steps in day for weir routing
C	Weir discharge coefficient
K	Energy coefficient (broad_crested=147,000' sharp crested=153,000)
W	The width of the weir (m)
BCOEF	Velocity exponent coefficient for bedding material
CCOEF	Depth exponent coefficient for bedding material

WETLAND.WET

Below is a sample WETLAND.WET file:

wetland.wet								
NUMB	NAME	INIT	HYD	RELEASE	SED	NUT	PST	
1	wetland1	wetland001	pnd1	null	res001	res001	res001	
2	wetland2	wetland001	pnd1	null	res001	res001	res001	
3	wetland3	wetland001	pnd1	null	res001	res001	res001	
4	wetland4	wetland001	pnd1	null	res001	res001	res001	
5	wetland5	wetland001	pnd1	null	res001	res001	res001	
6	wetland6	wetland001	pnd1	null	res001	res001	res001	
7	wetland7	wetland001	pnd1	null	res001	res001	res001	
8	wetland8	wetland001	pnd1	null	res001	res001	res001	
9	wetland9	wetland001	pnd1	null	res001	res001	res001	
10	wetland10	wetland001	pnd1	null	res001	res001	res001	

Variable name	Definition
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank. Optional.
HEADER	Headers for the wetland.wet file.
NAME	The name of the wetland
INIT	Initial data (points to initial.res)
HYD	Hydrology inputs (points to hydrology.res)
RELEASE	0 = simulated; 1 = measured outflow
SED	Sediment inputs (points to sediment.res)
NUT	Nutrient inputs (points to nutrient.res)

HYDROLOGY.WET

Below is a sample HYDROLOGY.WET file:

hydrology.wet											
NAME	PSA	PVOL	ESA	EVOL	K	EVRSV	ACOEF	BCOEF	CCOEF	FRAC	
pnd1	0.5	12.25125	0.9	14.82401	0.02	0.6	0	0	0	1	0.5

<u>Variable name</u>	<u>Definition</u>
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank.
	Optional.
HEADER	Headers for the hydrology.wet file.
NAME	The name of the hydrology
PSA	Fraction of hru area at principal spillway (ie: when surface inlet riser flow starts) (frac)
PVOL	Average depth of water at principal spillway (mm)
ESA	Fraction of hru area at emergency spillway (ie: when starts to spill into ditch)
EVOL	Average depth of water at emergency spillway (mm)
K	Hydraulic conductivity of the res bottom (mm/hr)
EVRSV	Lake evap coeff
ACOEF	Vol-surface area coefficient for hru impoundment
BCOEF	Vol-depth coefficient for hru impoundment
CCOEF	Vol-depth coefficient for hru impoundment
FRAC	Fraction of hru that drains into impoundment

ROUTING UNIT

A routing unit is a collection of hydrographs that can be routed to any spatial object. The routing unit can be configured as a subbasin, then total flow (surface, lateral and tile flow) from the routing unit can be sent to a channel and all recharge from the routing unit sent to an aquifer. This is analogous to the current approach in SWAT. However, SWAT+ gives us much more flexibility in configuring a routing unit. For example, in CEAP, we are routing each HRU (field) through a small channel (gully or grass waterway) before it reaches the main channel. In this case, the routing unit is a collection of flow from the small channels. We also envision simulating multiple representative hillslopes to define a routing unit. Also, we are setting up scenarios that define a routing unit using tile flow from multiple fields and sending that flow to a wetland.

The routing unit is the spatial unit SWAT+ that allows us to lump outputs and route the outputs to any other spatial object. It gives us considerably more flexibility than the old subbasin lumping approach in SWAT, and will continue to be a convenient way of spatial lumping until we can simulate individual fields or cells in each basin.

ROUT_UNIT.DEF

The rout_unit.def file contains data that defines HRU's in the subbasin.

Below is a sample rout_unit.def file:

rout_unit.def	RTU_NUMB	RTU_NAME	ELEM_TOT	ELEM1	ELEM2
	1	sub1	2	1	-21
	2	sub2	2	22	-28
	3	sub3	2	29	-39
	4	sub4	2	40	-42
	5	sub5	2	43	-62
	6	sub6	2	63	-67

Variable name	Definition
TITLE	The title of the rout_unit.def file
HEADER	Headers for the rout_unit.def file.
NUMB	Routing unit number
NAME	The name of the routing unit
ELEM_TOT	Total number of total elements to follow
ELEM_CNT1	Starting routing unit
ELEM_CNT2	Ending routing unit

ROUT_UNIT.ELE

Below is a sample ROUT_UNIT.ELE file:

rout_unit.ele	NUMB	NAME	OBTYP	OBTYPNO	FRAC	DR
	1	hru1	hru	1	0.5	0.00
	2	hru2	hru	2	0.5	0.00

Variable name	Definition
TITLE	The title of the rout_unit.ele file
HEADER	Headers for the rout_unit.ele file.
NUMB	The number of the connect (routing) unit
NAME	The name of the connect (routing) unit
OBTYP	Outflow object type (1=hru;2=hru_lte,3=subbasin;5=aquifer;6=channel; 11=export coefficients; 12=delivery ratios; outlet=15)
OBTYPNO	Number of HRU_LTE's or 1 st HRU lte command. Points to the exco_connect.dat object.
FRAC	Fraction of element in the subbasin (expansion factor -1.0 = 100%)

IDR

Delivery ratio through the aquifer. The subsurface flow that is delivered through the aquifer. Points to del_ratio.dat file.

ROUT_UNIT.RTU

Below is a sample ROUT_UNIT.RTU file:

rout_unit.rtu	RTU_NUMB	RTU_NAME	RTU_DEFINE	ELEM_DR	SUBTOPO	FIELD
1	sub1	sub1		null	top1	fld1
2	sub2	sub2		null	top2	fld2
3	sub3	sub3		null	top3	fld3
4	sub4	sub4		null	top4	fld4
5	sub5	sub5		null	top5	fld5
6	sub6	sub6		null	top6	fld6
7	sub7	sub7		null	top7	fld7

Variable name**Definition**

TITLE	The title of the rout_unit.rtu file
HEADER	Headers for the rout_unit.rtu file.
NUMB	Number of the subbasin
NAME	The name of the parm unit
RTU_DEFINE	Points to define.sub
ELEM_DR	Delivery ratio definition
SUBTOOP	Topography link
FIELD	Field database definition

ROUT_UNIT.DR

Below is a partial sample ROUT_UNIT.DR file:

rout_unit.dr	flo	sed	orgn	sedp	no3	solp	chl a	nh3	no2	cbod	dox	san	sil	cla	sag	lag	grv	temp
	0.8	0.7	0.6	0.5	0.4	3	0	0.1	0.2	0.3	0	0	0	0	0	0	0	0
	0.8	0.7	0.6	0.5	0.4	3	0	0.1	0.2	0.3	0	0	0	0	0	0	0	0

Variable name**Definition**

TITLE	The title of the rout_unit.dr file
HEADER	Headers for the rout_unit.dr file.
FLO	Volume of water (m^3)
SED	sediment (metric tons)
ORGN	Organic N (kg N)
SEDP	Organic P (kg P)
NO3	NO3-N (kg N)
SOLP	Mineral (soluble P) (kg P)
CHLA	Chlorophyll-a (kg)

NH3	NH3 (kg N)
NO2	NO2 (kg N)
CBOD	Carbonaceous biological oxygen demand (kg)
DOX	Dissolved oxygen (kg)
SAN	Detached sand (tons)
SIL	Detached silt (tons)
CLA	Detached clay (tons)
SAG	Detached small ag (tons)
LAG	Detached large ag (tons)
GRV	gravel (tons)
TEMP	Temperature (deg c)

HRU – HRU's are now defined by weather, topography, soil, landuse, operational management, potholes, subsurface drainage, structural operations, septic systems, plant community, initial soil chemistry, pesticides, bacteria, impoundments, snow and atmospheric deposition. Each HRU points to objects in each of the associated data files. HRU's consist of plants and soils on the landscape and now are not associated with aquifers and ponds and wetlands. HRUs are defined as contiguous areas (ie fields or grid cells) and a delivery from edge-of-field to subbasin outlet is computed in the subbasin module. This is not necessary when landscape units or grid cells are used. Several inputs for each HRU are required in addition to pointing to data files, including drainage area. These variables may be moved to a calibration file.

HRU-DATA.HRU

Below is a sample HRU-DATA.HRU file:

hru-data.hru:										
NUMB	NAME	TOPO	HYD	SOIL	LAND_USE_MGT	DIL_NUTR_INIT	SURF_STOR	SNOW	FIELD	SCHED_UPD
1	hru0010104	hru00101	hru0010104	IN025	agriculture	low_init	null	snow001	null	null
2	hru0010104	hru00101	hru0010104	IN025	agriculture	no_init	null	snow001	null	null

Variable name

Definition

TITLE

The first line is reserved for user comments. This line is not processed by the model and may be left blank.

Optional.

HEADER

Headers for the hru-data.hru file.

NUMB

HRU Number

NAME

Name of the HRU

TOPO

Topographic data (points to topography.hyd)

HYD

Hydrologic data (points to hydrology.hyd)

SOIL

Soil name (points to soils.sol)

LAND_USE_MGT

Landuse database name (points to landuse.lum)

SOIL_NUTR_INIT

Initial soil chemical properties name (points to nutrients.sol)

SURF_STOR

Pothole database name (points to ??)

SNOW

Snow database name (points to snow.sno)

FIELD

Field database name (points to field.fld)

HRU-LTE.HRU

Below is a sample HRU-LTE.HRU file:

hru-lte.hru		DAKM2	CN2	TC	SOLDEP	DEP_IMP	SLOPE	SLOPELEN	ETCO	SY	ABF	REVAPC	PERCC	SW	GW	GWFLOW	GWDEEP	SNOW	XLAT	ITEXT	TROPICAL	IGROW1	IGROW2	IPLANT	IPET	IRR	IRRSC	TDRAIN	USLEK	USLEC	USLEP	USLELS
1	N6289890	36.741	79	1200	760	6000	0.063	75	1	0.003	0.048	0.02	0.05	0.8	1000	0.1	1000	0	36.96	4	0	60	201 rmge	2	0	2	0	0.29	0.003	1	1.18	
2	N6289890	18.717	70	1200	760	6000	0.0824	45	1	0.003	0.048	0.02	0.05	0.8	1000	0.1	1000	0	36.96	4	0	60	201 frsb	2	0	2	0	0.29	0.001	1	1.74	
3	N6289890	11.785	74	1200	760	6000	0.0482	75	1	0.003	0.048	0.02	0.05	0.8	1000	0.1	1000	0	36.96	4	0	60	201 rmb	2	0	2	0	0.29	0.003	1	0.942	
4	N6289890	1.386	92	1200	760	6000	0.0114	90	1	0.003	0.048	0.02	0.05	0.8	1000	0.1	1000	0	36.96	4	0	60	201 watr	2	0	2	0	0.29	0	1	0.184	
5	N6289900	45.296	79	1200	760	6000	0.0549	75	1	0.003	0.048	0.02	0.05	0.8	1000	0.1	1000	0	36.96	4	0	60	201 rmge	2	0	2	0	0.29	0.003	1	0.926	

Variable name**Definition**

TITLE

The first line is reserved for user comments. This line is not processed by the model and may be left blank.

Optional.

HEADER

Headers for the hru-lte.hru file.

NUMB

Number

NAME

Name of the SWAT-DEG hru file

DAKM2

Drainage area (km^2)

CN2

Condition II curve number

CN3_SWF

Soil water factor for cn3 (used in calibration) 0 =fc; 1=saturation (porosity)

TC

Time of concentration (min)

SOILDEP

Soil profile depth (mm)

SLOPE

Land surface slope (m/m)

SLOPELEN

Land surface slope length (m)

SY

Specific yld of the shallow aquifer

ABF

Alpha factor groundwater

REVAPC

Revap coefficient-amt of et from shallow aquifer

PERCC

Percolation coeff from shallow to deep

SW

Initial soil water (frac of awc) (fraction)

GW

Initial shallow aquifer storage (mm)

GWFLOW

Initial shallow aquifer flow (mm)

GWDEEP

Initial deep aquifer flow (mm)

SNOW

Initial snow water equivalent (mm)

XLAT

Latitude

TEXT

Soil texture (character):

sand; loamy_sand; sandy_loam; loam; silt_loam; silt;
silty_clay; clay_loam; sandy_clay_loam; sandy_clay;
silty_clay; clay;

TROPICAL

Tropics (character):

'non_trop' = non-tropical

'trop' = tropical

IGROW1	Start of growing season (character – from dtable.dtl file): ‘pl_grow_sum’ ‘pl_end_sum’ ‘pl_grow_win’ ‘pl_end_win’
IGROW2	End of growing season ‘pl_grow_sum’ ‘pl_end_sum’ ‘pl_grow_win’ ‘pl_end_win’
PLANT	Plant type (as listed in plant.plt)
STRESS	Plant stress – pest, root restriction, soil quality, nutrient, (non water, temp)
IPET	Potential evapotranspiration (PET) method (character): ‘harg’ = Hargreaves method ‘p_t’ = Priestley-Taylor method Numerous methods exist to calculate potential evapotranspiration. Three of the most popular or widely-used are included in SWAT. However, if a method other than Priestley-Taylor, Penman/Monteith, or Hargreaves is recommended for the area in which the watershed is located, the user can calculate daily PET values with the recommended method and import them into SWAT. A discussion of Priestley-Taylor, Penman-Monteith and Hargreaves PET methods is found in Chapter 2:2 of the theoretical documentation. Required.

IRR

Irrigation code (character):

- ‘no_irr’ = no irrigation
- ‘irr’ = irrigation

Water applied to an HRU is obtained from one of five types of water sources: a reach, a reservoir, a shallow aquifer, a deep aquifer, or a source outside the watershed. In addition to the type of water source, the model must know the location of the water source (unless the source is outside the watershed). For the reach, shallow aquifer or deep aquifer, SWAT needs to know the subbasin number in which the source is located. If a reservoir is used to supply water, SWAT must know the reservoir number.

This variable, along with IRRNO, specifies the source of irrigation water applied in the HRU. Irrigation water may be diverted from anywhere in the watershed or outside the watershed. IRRSC tells the model what type of water body the irrigation water is being diverted from.

The options are:

- 0 no irrigation
- 1 divert water from reach
- 2 divert water from reservoir
- 3 divert water from shallow aquifer
- 4 divert water from deep aquifer
- divert water from unlimited source outside watershed

IRRSRC

Irrigation source (character):

- ‘outside_bsn’ = outside basin
- ‘shal_aqu’ = shallow aquifer
- ‘deep_aqu’ = deep aquifer

Irrigation source location.

Water applied to an HRU is obtained from one of five types of water sources: a reach, a reservoir, a shallow aquifer, a deep aquifer, or a source outside the watershed. In addition to the type of water source, the model must know the location of the water source (unless the source is outside the watershed). For the reach, shallow aquifer or deep aquifer, SWAT needs to know the subbasin number in which the source is located. If a reservoir is used to supply water, SWAT must know the reservoir number

	The definition of this variable depends on the setting of IRR. IRR = 1: IRRSRC is the number of the reach that water is removed from. IRR = 2: IRRSRC is the number of the reservoir that water is removed from. IRR = 3 or 4: IRRSRC is the number of the subbasin that water is removed from. IRR = 0 or 5: this variable is not used. Required if $1 \leq \text{IRR} \leq 4$
TDRAIN	Design subsurface tile drain time (hr)
USLEK	USLE equation soil erodibility (K) factor (units: 0.013 (metric ton m ² hr)/(m ³ -metric ton cm)). Some soils erode more easily than others even when all other factors are the same. This difference is termed soil erodibility and is caused by the properties of the soil itself. Wischmeier and Smith (1978) define the soil erodibility factor as the soil loss rate per erosion index unit for a specified soil as measured on a unit plot. A unit plot is 22.1-m (72.6-ft) long, with a uniform length-wise slope of
USLEK, cont.	9-percent, in continuous fallow, tilled up and down the slope. Continuous fallow is defined as land that has been tilled and kept free of vegetation for more than 2 years. The units for the USLE soil erodibility factor in MUSLE are numerically equivalent to the traditional English units of 0.01 (ton acre hr)/(acre ft-ton inch). Wischmeier and Smith (1978) noted that a soil type usually becomes less erodible with decrease in silt fraction, regardless of whether the corresponding increase is in the sand fraction or clay fraction. Direct measurement of the erodibility factor is time consuming and costly. Wischmeier et al. (1971) developed a general equation to calculate the soil erodibility factor when the silt and very fine sand content makes up less than 70% of the soil particle size distribution.
USLEK, cont.	$K_{\text{USLE}} = \frac{0.00021 \cdot M^{1.14} \cdot (12 - OM) + 3.25 \cdot (c_{\text{soilstr}} - 2) + 2.5 \cdot (c_{\text{perm}} - 3)}{100}$

USLEK, cont.

where KUSLE is the soil erodibility factor, M is the particle-size parameter, OM is the percent organic matter (%), csoilstr is the soil structure code used in soil classification, and cperm is the profile permeability class.

The particle-size parameter, M, is calculated

$$M = (m_{silt} + m_{vfs}) \cdot (100 - m_c)$$

where msilt is the percent silt content (0.002-0.05 mm diameter particles), mvfs is the percent very fine sand content (0.05-0.10 mm diameter particles), and mc is the percent clay content (< 0.002 mm diameter particles).

The percent organic matter content, OM, of a layer can be calculated:

$$OM = 1.72 \cdot orgC$$

where orgC is the percent organic carbon content of the layer (%).

USLEK, cont.

Soil structure refers to the aggregation of primary soil particles into compound particles which are separated from adjoining aggregates by surfaces of weakness. An individual natural soil aggregate is called a ped. Field description of soil structure notes the shape and arrangement of peds, the size of peds, and the distinctness and durability of visible peds. USDA Soil Survey terminology for structure consists of separate sets of terms defining each of these three qualities. Shape and arrangement of peds are designated as type of soil structure; size of peds as class; and degree of distinctness as grade.

Angular Blocky: bounded by planes intersecting at relatively sharp angles

Subangular Blocky: having mixed rounded and plane faces with vertices mostly rounded

The soil-structure codes for the equation are defined by the type and class of soil structure present in the layer. There are four primary types of structure, several of which are further broken down into subtypes:

-Platy, with particles arranged around a plane, generally horizontal

-Prismlike, with particles arranged around a verticle line and bounded by relatively flat vertical surfaces

Prismatic: without rounded upper ends

Columnar: with rounded caps

-Blocklike or polyhedral, with particles arranged around a point and bounded by flat or rounded surfaces which are casts of the molds formed by the faces of surrounding peds

-Spheroidal or polyhedral, with particles arranged around a point and bounded by curved or very irregular surfaces that are not accomodated to the adjoining aggregates

Granular: relatively non-porous

Crumb: very porous

The size criteria for the class will vary by type of structure and are summarized in Table 22-2.

USLEK, cont.

Definition

Table 22-2: Size classes of soil structure

Size Classes	Shape of structure			
	Platy	Columnar	Blocky	Granular
Very fine	< 1 mm	< 10 mm	< 5 mm	< 1 mm
Fine	1-2 mm	10-20 mm	5-10 mm	1-2 mm
Medium	2-5 mm	20-50 mm	10-20 mm	2-5 mm
Coarse	5-10 mm	50-100 mm	20-50 mm	5-10 mm
Very coarse	> 10 mm	> 100 mm	> 50 mm	> 10 mm

USLEK, cont.

The codes assigned to $c_{soilstr}$ are:

- 1 very fine granular
- 2 fine granular
- 3 medium or coarse granular
- 4 blocky, platy, prismslike or massive

Permeability is defined as the capacity of the soil to transmit water and air through the most restricted horizon (layer) when moist. The profile permeability classes are based on the lowest saturated hydraulic conductivity in the profile. The codes assigned to c_{perm} are:

- 1 rapid (> 150 mm/hr)
- 2 moderate to rapid (50-150 mm/hr)
- 3 moderate (15-50 mm hr)
- 4 slow to moderate (5-15 mm hr)
- 5 slow (1-5 mm hr)
- 6 very slow (< 1 mm hr)

Williams (1995) proposed an alternative equation:

$$K_{USLE} = f_{csand} \cdot f_{cl-si} \cdot f_{orgc} \cdot f_{hisand}$$

where f_{csand} is a factor that gives low soil erodibility factors for soils with high coarse-sand contents and high values for soils with little sand, f_{cl-si} is a factor that gives low soil erodibility factors for soils with high clay to silt ratios, f_{orgc} is a factor that reduces soil erodibility for soils with high organic carbon content, and f_{hisand} is a factor that reduces soil erodibility for soils with extremely high sand contents.

The factors are calculated:

$$f_{csand} = \left(0.2 + 0.3 \cdot \exp \left[-0.256 \cdot m_s \cdot \left(1 - \frac{m_{silt}}{100} \right) \right] \right)$$

$$f_{cl-si} = \left(\frac{m_{silt}}{m_c + m_{silt}} \right)^{0.3}$$

USLEK, cont.

USLEK, cont.

$$f_{orgc} = \left(1 - \frac{0.0256 \cdot orgC}{orgC + \exp[3.72 - 2.95 \cdot ol]} \right)$$

$$f_{hisand} = \left(1 - \frac{0.7 \cdot \left(1 - \frac{l}{100} \right)}{\left(1 - \frac{m_s}{100} \right) + \exp[-5.51 - 0.001 \cdot l]} \right)$$

where m_s is the percent sand content (0.05-2.00 mm diameter particles), m_{silt} is the percent silt content (0.002-0.05 mm diameter particles), m_c is the percent clay content (< 0.002 mm diameter particles), and $orgC$ is the percent organic carbon content of the layer (%).

Required.

USLEC

USLE cover factor

USLEP

USLE equation support practice factor.

The support practice factor, P_{USLE} , is defined as the ratio of soil loss with a specific support practice to the corresponding loss with up-and-down slope culture. Support practices include contour tillage, stripcropping on the contour, and terrace systems. Stabilized waterways for the disposal of excess rainfall are a necessary part of each of these practices.

Contour tillage and planting provides almost complete protection against erosion from storms of low to moderate intensity, but little or no protection against occasional severe storms that cause extensive breakovers of contoured rows. Contouring is most effective on slopes of 3 to 8 percent. Values for P_{USLE} and slope-length limits for contour support practices are given in Table 20-4.

USLEP, cont.

Table 20-4: P factor values and slope-length limits for contouring (Wischmeier and Smith, 1978).

Land slope (%)	P_{USLE}
1 to 2	0.60
3 to 5	0.50
6 to 8	0.50
9 to 12	0.60
13 to 16	0.70
17 to 20	0.80
21 to 25	0.90

Stripcropping is a practice in which contoured strips of sod are alternated with equal-width strips of row crop or small grain. Recommended values for contour stripcropping are given in Table 20-5.

USLEP, cont.

Table 20-5: P factor values, maximum strip width and slope-length limits for contour stripcropping (Wischmeier and Smith, 1978).

Land slope (%)	P_{USLE} values ¹		
	A	B	C
1 to 2	0.30	0.45	0.60
3 to 5	0.25	0.38	0.50
6 to 8	0.25	0.38	0.50
9 to 12	0.30	0.45	0.60
13 to 16	0.35	0.52	0.70
17 to 20	0.40	0.60	0.80
21 to 25	0.45	0.68	0.90

¹P values:

A: For 4-year rotation of row crop, small grain with meadow seeding, and 2 years of meadow. A second row crop can replace the small grain if meadow is established in it.

B: For 4-year rotation of 2 years row crop, winter grain with meadow seeding, and 1-year meadow.

C: For alternate strips of row crop and winter grain

USLEP, cont.

Terraces are a series of horizontal ridges made in a hillside. There are several types of terraces. Broadbase terraces are constructed on gently sloping land and the channel and ridge are cropped the same as the interterrace area. The steep backslope terrace, where the backslope is in sod, is most common on steeper land. Impoundment terraces are terraces with underground outlets.

USLEP, cont.

Terraces divide the slope of the hill into segments equal to the horizontal terrace interval. With terracing, the slope length is the terrace interval. For broadbase terraces, the horizontal terrace interval is the distance from the center of the ridge to the center of the channel for the terrace below. The horizontal terrace interval for steep backslope terraces is the distance from the point where cultivation begins at the base of the ridge to the base of the frontslope of the terrace below.

Values for P_{USLE} for contour farming terraced fields are listed in Table 20-6. These values apply to broadbase, steep backslope and level terraces. Keep in mind that the values given in Table 20-6 do not account for all erosion control benefits of terraces. The shorter slope-length used in the calculation of the length-slope factor will produce additional reduction.

Required.

Table 20-6: P factor values for contour-farmed terraced fields¹

Land slope (%)	Farm planning		Con chan sod ou
	Contour P factor ²	Stripcrop P factor	
1 to 2	0.60	0.30	0.1
3 to 8	0.50	0.25	0.1
9 to 12	0.60	0.30	0.1
13 to 16	0.70	0.35	0.1
17 to 20	0.80	0.40	0.1
21 to 25	0.90	0.45	0.1

¹Slope length is the horizontal terrace interval. The listed values are for contour farming. No additional contouring factor is used in the computation.

² Use these values for control of interterrace erosion within specified soil loss tolerances.

³ These values include entrapment efficiency and are used for control of offsite sediment within limits and for estimating the field's contribution to watershed sediment yield.

USLELS

USLE equation length slope (LS) factor

EXCO – Export Coefficient

EXCO.EXC

The EXCO.EXC file contains the input variables for the nutrients of a channel. Below is a sample EXCO.EXC file:

exco.exc					
NAME	OM	PEST	PATH	HMET	SALT
exco1	exco_om1	exco_pest1	exco_path1	exco_hmet1	exco_salt1
exco2	exco_om2	exco_pest2	exco_path2	exco_hmet2	exco_salt2

Variable name	Definition
TITLE	The title of the exco.exc file
HEADER	Headers for the exco.exc file
NAME	Name of the export coefficient (points to exco.con file)
OM_NAME	Name of the organic matter (points to exco.om.exc file)
PEST_NAME	Name of the pesticides (points to exco_pest.exc file)
PATH_NAME	Name of the pathogens (points to exco_path.exc file)
SALT_NAME	Name of the salt (points to exco_salt.exc file)

EXCO OM EXC

The EXCO_OM_EXC file contains the input variables for the nutrients of a channel. Below is a sample EXCO_OM.EXC file:

exco_om	flo	sed	orgn	sedp	no3	solp	chl	nh3	no2	cbod	dox	san	sil	cla	sag	lag	grv	temp
exco_om1	12.5	100	90	80	70	60	30	20	10	9	8	2	1	100	90	80	70	60
exco_om2	22.5	110	99	88	77	66	33	22	11	19	28	82	91	190	98	87	76	65

Variable name	Definition
TITLE	The title of the exco_om.exc file
HEADER	Headers for the exco_om.exc file
NAME	Name of the organic matter (exco.exc file)

FLO	Volume of water (m^3)
SED	sediment (metric tons)
ORGN	Organic N (kg N)
SEDP	Organic P (kg P)
NO3	NO3-N (kg N)
SOLP	Mineral (soluble P) (kg P)
CHLA	Chlorophyll-a (kg)
NH3	NH3 (kg N)
NO2	NO2 (kg N)
CBOD	Carbonaceous biological oxygen demand (kg)
DOX	Dissolved oxygen (kg)
SAN	Detached sand (tons)
SIL	Detached silt (tons)
CLA	Detached clay (tons)
SAG	Detached small ag (tons)
LAG	Detached large ag (tons)
GRV	gravel (tons)
TEMP	Temperature (deg c)

EXCO_PEST.EXC

exco_pest.exc	aatrex_sol	aatrex_sor	banvel_sol	banvel_sor	prowl_sol	prowl_sor	roundup_sol	roundup_sor
exco_pest1	12.5	100	90	80	70	60	50	40
exco_pest2	22.5	110	99	88	77	66	55	44

The EXCO_PEST.EXC file contains the input variables for the nutrients of a channel. Below is a sample EXCO_PEST.EXC file:

Variable name	Definition
TITLE	The title of the exco_pest.exc file
HEADER	Headers for the exco_pest.exc file
NAME	Name of the pesticide (exco.exc file)
EXCO_PEST_SOL	Pesticide soluble constituent mass
EXCO_PEST_SOR	Pesticide sorbed constituent mass

EXCO_PATH.EXC

The EXCO_PATH.EXC file contains the input variables for the nutrients of a channel. Below is a sample EXCO_PATH.EXC file:

exco_path.exc	fecals_sol	fecals_sor	e_coli_sol	e_coli_sor
exco_path1	12.5	100	90	80
exco_path2	22.5	110	99	88

Variable name	Definition
TITLE	The title of the exco_path.exc file
HEADER	Headers for the exco_path.exc file
NAME	Name of the pathogens (exco.exc file)
EXCO_PATH_SOL	Pathogen soluble constituent mass
EXCO_PATH_SOR	Pathogen sorbed constituent mass

EXCO_HMET.EXC

The EXCO_HMET.EXC file contains the input variables for the nutrients of a channel. Below is a sample EXCO_HMET.EXC file:

exco_hmet.exc	mercury_sol	mercury_sor
exco_hmet1	12.5	100
exco_hmet2	22.5	110

Variable name	Definition
TITLE	The title of the exco_hmet.exc file
HEADER	Headers for the exco_hmet.exc file
NAME	Name of the heavy metals (exco.exc file)
EXCO_HMET_SOL	Heavy metal soluble constituent mass
EXCO_HMET_SOR	Heavy metal sorbed constituent mass

EXCO_SALT.EXC

The EXCO_SALT.EXC file contains the input variables for the nutrients of a channel. Below is a sample EXCO_SALT.EXC file:

exco_salt.exc	sodium_sol	sodium_sor	magnesium_sol	magnesium_sor
exco_salt1	12.5	100	90	80
exco_salt2	22.5	110	99	88

Variable name	Definition
TITLE	The title of the exco_salt.exc file
HEADER	Headers for the exco_salt.exc file
NAME	Name of salt (exco.exc file)
EXCO_HMET_SOL	Salt soluble constituent mass
EXCO_HMET_SOL	Salt sorbed constituent mass

RECALL

The recall data can be read in day(1), monthly(2) or yearly(3) timesteps. The recall.rec file reads in the filename of the recall data.

RECALL.REC

The RECALL.REC file contains the input variables for the nutrients of a channel. Below is a sample RECALL.REC file:

recall.rec			
NUMB	NAME	TYP	FILENAME
1	daily	1	recall_day.rec

Variable name	Definition
TITLE	This line is reserved for the recall record title. This line is not processed by the model and may be left blank.
HEADER	Headers
NUMB	Sequential number of recall
NAME	Daily, monthly, annual
TYP	1==daily; 2=monthly; 3=annual;
FILENAME	Name of recall file to be read

EXAMPLE RECALL DAY.REC FILE:

Variable name	Definition
TITLE	This line is reserved for the recall daily, monthly or annual title. This line is not processed by the model and may be left blank.
NBYR	Number of years of recall data
IYR	Current year of input data
ISTEP	Current day of input data
FLO	Volume of water (m ³)
SED	sediment (metric tons)
ORGN	Organic N (kg N)
SEDP	Organic P (kg P)
NO3	NO3-N (kg N)
SOLP	Mineral (soluble P) (kg P)
CHLA	Chlorophyll-a (kg)
NH3	NH3 (kg N)
NO2	NO2 (kg N)
CBOD	Carbonaceous biological oxygen demand (kg)
DOX	Dissolved oxygen (kg)
SAN	Detached sand (tons)
SIL	Detached silt (tons)
CLA	Detached clay (tons)
SAG	Detached small ag (tons)
LAG	Detached large ag (tons)
GRV	gravel (tons)
TEMP	Temperature (deg c)

DR –Delivery Ratio

DELRATIO.DEL

The DELRATIO.DEL file contains the input variables for the nutrients of a channel. Below is a sample DELRATIO.DEL file:

delratio.del					
NAME	OM_FILE	PEST_FILE	PATH_FILE	HMET_FILE	SALTS_FILE
dr01	dr_om.del	dr_pest.del	dr_path.del	dr_hmet.del	dr_salt.del

Variable name	Definition
TITLE	The title of the delratio.del file
HEADER	Headers for the delratio.del file
NAME	Name of the export coefficient (points to delratio.con)
OM_NAME	Name of the organic matter (points to dr_om.del)
PEST_NAME	Name of the pesticides (points to dr_pest.del)
PATH_NAME	Name of the pathogens (points to dr_path.del)
SALT_NAME	Name of the salt (points to dr_salt.del)

DR_OM.DEL

The DR_OM.DEL file contains the input variables for the nutrients of a channel. Below is a sample DR_OM.DEL file:

dr_om.del	flo	sed	orgn	sedp	no3	solp	chl	nh3	no2	cbod	dox	san	sil	cla	sag	lag	grv	temp
dr_om1	0.125	0.9	0.9	0.8	0.7	0.6	0.3	0.2	0.1	0.9	0.8	0.2	1	0.1	0.9	0.8	0.7	0.6
dr_om2	0.225	0.11	0.99	0.88	0.77	0.66	0.33	0.22	0.11	0.19	0.28	0.82	0.91	0.19	0.98	0.87	0.76	0.65

Variable name	Definition
TITLE	The title of the dr_om.del file
HEADER	Headers for the dr_om.del file
NAME	Name of the organic matter (delratio.del file)

FLO	Volume of water (m^3)
SED	sediment (metric tons)
ORGN	Organic N (kg N)
SEDP	Organic P (kg P)
NO3	NO3-N (kg N)
SOLP	Mineral (soluble P) (kg P)
CHLA	Chlorophyll-a (kg)
NH3	NH3 (kg N)
NO2	NO2 (kg N)
CBOD	Carbonaceous biological oxygen demand (kg)
DOX	Dissolved oxygen (kg)
SAN	Detached sand (tons)
SIL	Detached silt (tons)
CLA	Detached clay (tons)
SAG	Detached small ag (tons)
LAG	Detached large ag (tons)
GRV	gravel (tons)
TEMP	Temperature (deg c)

DR_PEST.DEL

The DR_PEST.DEL file contains the input variables for the nutrients of a channel. Below is a sample DR_PEST.DEL file:

dr_pest.del	aatrex_sol	aatrex_sor	banvel_sol	banvel_sor	prowl_sol	prowl_sor	roundup_sol	roundup_sor
dr_pest1	0.125	0.1	0.9	0.8	0.7	0.6	0.5	0.4
dr_pest2	0.225	0.11	0.99	0.88	0.77	0.66	0.55	0.44

The DR_PEST.DEL file contains the input variables for the nutrients of a channel. Below is a sample partial DR_PEST_DEL file:

Variable name	Definition
TITLE	The title of the DR_PEST.DEL file
HEADER	Headers for the DR_PEST.DEL file
NAME	Name of the pesticide
DR_PEST_SOL	Pesticide soluble constituent mass
DR_PEST_SOR	Pesticide sorbed constituent mass

DR_PATH.DEL

The DR_PATH.DEL file contains the input variables for the nutrients of a channel. Below is a sample DR_PATH.DEL file:

dr_path.del				
	fecals_sol	fecals_sor	e_coli_sol	e_coli_sor
dr_path1	0.125	0.1	0.9	0.8
dr_path2	0.225	0.11	0.99	0.88

Variable name	Definition
TITLE	The title of the dr_path.del file
HEADER	Headers for the dr_path.del file
NAME	Name of the pathogens (delratio.del file)
DR_PATH_SOL	Pathogen soluble constituent mass
DR_PATH_SOR	Pathogen sorbed constituent mass

DR_HMET.DEL

The DR_HMET.DEL file contains the input variables for the nutrients of a channel. Below is a sample DR_HMET.DEL file:

dr_hmet.del		
	mercury_sol	mercury_sor
dr_hmet1	0.125	0.1
dr_hmet2	0.225	0.11

Variable name	Definition
TITLE	The title of the dr_hmet.exc file
HEADER	Headers for the dr_hmet.exc file
NAME	Name of the heavy metals (delratio.del file)
DR_HMET_SOL	Heavy metal soluble constituent mass
DR_HMET_SOL	Heavy metal sorbed constituent mass

DR_SALT.DEL

The DR_SALT.DEL file contains the input variables for the nutrients of a channel. Below is a sample EXCO_DR_SALT.DEL file:

dr_salt.del	sodium_sol	sodium_sor	magnesium_sol	magnesium_sor
dr_salt1	0.125	0.1	0.9	0.8
dr_salt2	0.225	0.11	0.99	0.88

Variable name	Definition
TITLE	The title of the dr_salt.del file
HEADER	Headers for the dr_salt.del file
NAME	Name of salt (delratio.del file)
DR_HMET_SOL	Salt soluble constituent mass
DR_HMET_SOL	Salt sorbed constituent mass

AQUIFER**INITIAL.AQU**

initial.aqu	ORG-MIN	PESTICIDES	PATHOGENS	HEAVY_METALS	SALTS
NAME	low_init	no_ini	no_ini	null	null
high_init	high_init	low_ini	low_ini	null	null

Variable name	Definition
TITLE	Title of the initial aquifer file
HEADER	The header information for the initial aquifer file
NAME	Name of the initial aquifer
ORG-MIN	Organic mineral in aquifer (points to OM_WATER.INI file)

PESTICIDES	Pesticides initialization in aquifer (points to PEST_WATER.INI file)
PATHOGENS	Pathogens initialization in aquifer (points to PATH_WATER.INI file)
HEAVY METALS	Heavy metals initialization in aquifer (points to HMET_WATER.INI file)
SALTS	Salts initialization in aquifer (points to SALT_WATER.INI file)

AQUIFER.AQU

Below is a sample AQUIFER.AQU file:

aquifer.aqu	QU_NAME	FLO	DEP_BOT	DEP_WT	NO3	MINP	ORGN	ORGP	FLO_MAX	ALPHA	REVAP_CO	SEEP	SPYLD	HLIFE_N	FLO_MIN	REVAP_MIN
AQU_NUMB																
1	aqu1	10	5	1	0	0	0	0	1	1	0.02	0.06	0.05	0	50	1000
2	aqu2	10	5	1	0	0	0	0	1	1	0.02	0.06	0.05	0	50	1000
3	aqu3	10	5	1	0	0	0	0	1	1	0.02	0.06	0.05	0	50	1000
4	aqu4	10	5	1	0	0	0	0	1	1	0.02	0.06	0.05	0	50	1000
5	aqu5	10	5	1	0	0	0	0	1	1	0.02	0.06	0.05	0	50	1000

Variable name

Definition

TITLE

The first line is reserved for user comments. This line is not processed by the model and may be left blank.

Optional.

HEADER

Headings for the aquifer.aqu file.

NUMB

Number

AQUNM

Name

FLO

Initial depth of water in the shallow aquifer (mm H₂O).

We recommend using a 1 year equilibration period for the model where the watershed simulation is set to start 1 year prior to the period of interest. This allows the model to get the water cycling properly before any comparisons between measured and simulated data are made. When an equilibration period is incorporated, the value for FLO is not that important.

DEP_BOT

Depth to the bottom - mid-slope surface to bottom of aquifer (m)

DEP_WT

Depth – mid-slope surface to water water table (initial) (m).

NO3	Initial concentration of nitrate in shallow aquifer. (mg N/L or ppm).
	Nitrate levels in the shallow aquifer are modeled, allowing for variation in nitrate concentration and groundwater loadings of nitrate contributed to streamflow in the subbasin.
	Optional.
MINP	Concentration of soluble phosphorus in groundwater contribution to streamflow from subbasin (mg P/L or ppm).
	This is a fixed concentration used throughout the entire period of simulation.
	Optional.
ORGN	Organic N in the base flow (mg/L) (range 0.0 – 200.0)
	default = 0.0
	Optional.
ORGP	Organic P in the base flow (mg/L) (range 0.0 – 200.0) default = 0.0
	Optional.
FLO_MAX	Baseflow rate when the entire area is contributing to baseflow (mm) default = 1.00
ALPHA	Baseflow alpha factor (1/days).
	The baseflow recession constant, α_{gw} , is a direct index of groundwater flow response to changes in recharge (Smedema and Rycroft, 1983). Values vary from 0.1-0.3 for land with slow response to recharge to 0.9-1.0 for land with a rapid response. Although the baseflow recession constant may be calculated, the best estimates are obtained by analyzing measured streamflow during periods of no recharge in the watershed.
	It is common to find the baseflow days reported for a stream gage or watershed. This is the number of days for base flow recession to decline through one log cycle. When baseflow days are known, the alpha factor can be calculated:
	$\alpha_{gw} = \frac{1}{N} \cdot \ln\left[\frac{Q_{gw,N}}{Q_{gw,0}}\right] = \frac{1}{BFD} \cdot \ln[10] = \frac{2.3}{BFD}$
	where α_{gw} is the baseflow recession constant, and BFD is the number of baseflow days for the watershed.
	Required.

REVAP

Groundwater "revap" coefficient.

Water may move from the shallow aquifer into the overlying unsaturated zone. In periods when the material overlying the aquifer is dry, water in the capillary fringe that separates the saturated and unsaturated zones will evaporate and diffuse upward. As water is removed from the capillary fringe by evaporation, it is replaced by water from the underlying aquifer. Water may also be removed from the aquifer by deep-rooted plants which are able to uptake water directly from the aquifer.

This process is significant in watersheds where the saturated zone is not very far below the surface or where deep-rooted plants are growing. Because the type of plant cover will affect the importance of revap in the water balance, the parameters governing revap can be varied by land use.

As REVAP approaches 0, movement of water from the shallow aquifer to the root zone is restricted. As REVAP approaches 1, the rate of transfer from the shallow aquifer to the root zone approaches the rate of potential evapotranspiration. The value for REVAP should be between 0.02 and 0.20.

This variable, along with REVAPMN, is the reason a different groundwater file is created for each HRU rather than each subbasin.

Required.

Deep aquifer percolation fraction.

SEEP

The fraction of percolation from the root zone which recharges the deep aquifer. The value for RCHRG_DP should be between 0.0 and 1.0.

Required.

SPYLD

Specific yield of the shallow aquifer (m^3/m^3).

Specific yield is defined as the ratio of the volume of water that drains by gravity to the total volume of rock.

Specific yield is required to calculate groundwater height fluctuations.

This variable is not active

HLIFE_N

Half-life of nitrate in the shallow aquifer (days).

Nitrate in the shallow aquifer may be removed by uptake by bacteria present in the aquifer or by chemical conversion to other compounds in regions of the aquifer that are depleted in oxygen (reduced environment). The half-life, as for half-life values reported for pesticides, is the time period required for the concentration of nitrate to drop to one-half its original value. The reduction is a net reduction by all processes occurring in the shallow aquifer.

Optional.

FLO_MIN

Minimum aquifer storage to allow return flow [m]

REVAP_MIN

Threshold depth of water in the shallow aquifer for “revap” or percolation to the deep aquifer to occur (mm H₂O).

Movement of water from the shallow aquifer to the unsaturated zone is allowed only if the volume of water in the shallow aquifer is equal to or greater than REVAPMN.

This variable, along with GW_REVAP, is the reason a different groundwater file is created for each HRU rather than each subbasin.

Required.

HERD –**ANIMAL.HRD**

Below is a sample ANIMAL.HRD FILE:

HERD.HRD

Below is a sample HERD.HRD FILE:

RANCH.HRD

Below is a sample RANCH.HRD FILE:

WATER RIGHTS –**DEFINE.WRO**

Below is a sample DEFINE.WRO FILE:

ELEMENT.WRO

Below is a sample ELEMENT.WRO FILE

WATER RIGHTS.WRO

Below is a sample WATER_RIGHTS.WRO FILE:

LINK -**CHAN-SURF.LIN**

Below is a sample CHAN_SURF.LIN FILE:

chan-surf.							
NUMB	NAME	NSPU	OBTYP	OBTYP_NO	OBTYP	OBTYP_NO	
1	chan1	1	hru	1			
2	chan2	1	sub	1			
8	chan3	2	sub	3	sub	4	
9	chan4	2	hru	5	hru	6	

Variable name	Definition
TITLE	The title line for the chan-surf.lin file (optional)
MCHA_SP	Total number of channel links in file
HEADER	Headings for the chan-surf.lin file
NUMB	The sequential number of the channel links
NAME	The unique name of the channel link
NUM	The total objects following
OBTYP	The object type (1=hru; 2=hru_lte; 11=export coeff;
OBTYPNO	Number of hru_lte's or 1 st hru_lte command

CHAN-AQU.LIN

Below is a sample CHAN-AQU.LIN FILE:

CHAN-AQU.LIN					
NUMB	NAME	NSPU	AQU1	AQU2	AQU3
4					
1	CHAN1	3	1	2	3
2	CHAN2	1	4		
8	CHAN3	2	5	6	
9	CHAN4	2	8	9	

Variable name	Definition
TITLE	The title line for the chan-aqu.lin file (may be blank)
MCHA_SP	Total number of channel aquifer links in file
NUMB	The sequential number of the channel aquifer links
NAME	The unique name of the channel link
NUM	The total objects following
AQU_NO	The aquifer number

HYDROLOGY –

HYDROLOGY.HYD

Data contained in the hydrology.dat data file can be grouped into the following categories: topographic characteristics, water flow, erosion, land cover, and depressional storage areas.

Below is a partial sample HYDROLOGY.HYD FILE:

hydrology.hyd															
NAME	LAT_TIME	LAT_SED	CANMX	ESCO	EPCO	ERORGN	ERORGP	CN3_SWF	BIOMIX	PERCO	LAT_ORGN	LAT_ORGP	HARG_PET	CNCOEF	
hru0010104	0	0	0	0.95	1	0	0	0	0.2	1	0	0	0.0023	0.3	
HRU0010105	0	0	0	0.95	1	0	0	0	0.2	1	0	0	0.0023	0.3	
HRU0010108	0	0	0	0.95	1	0	0	0	0.2	1	0	0	0.0023	0.3	
HRU0010109	0	0	0	0.95	1	0	0	0.5	0.2	1	0	0	0.0023	0.3	
HRU0010110	0	0	0	0.95	1	0	0	0.5	0.2	1	0	0	0.0023	0.3	
HRU0010112	0	0	0	0.95	1	0	0	0.5	0.2	1	0	0	0.0023	0.3	

Variable name	Definition
NAME	Name
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank.
	Optional.
HEADER	Headers for the nutrients.res file.
NAME	Name
LAT_TTIME	Lateral flow travel time (days).
	Setting LAT_TTIME = 0.0 will allow the model to calculate the travel time based on soil hydraulic properties. This variable should be set to a specific value only by hydrologists familiar with the base flow characteristics of the watershed.
	Required.

LAT_SED

Sediment concentration in lateral and groundwater flow (mg/L).

Sediment concentration in lateral and groundwater flow is usually very low and does not contribute significantly to total sediment yields unless return flow is very high.

Optional.

CANMX

Maximum canopy storage (mm H₂O).

The plant canopy can significantly affect infiltration, surface runoff and evapotranspiration. As rain falls, canopy interception reduces the erosive energy of droplets and traps a portion of the rainfall within the canopy. The influence the canopy exerts on these processes is a function of the density of plant cover and the morphology of the plant species.

When calculating surface runoff, the SCS curve number method lumps canopy interception in the term for initial abstractions. This variable also includes surface storage and infiltration prior to runoff and is estimated as 20% of the retention parameter value for a given day (see Chapter 2:1). When the Green and Ampt infiltration equation is used to calculate infiltration, the interception of rainfall by the canopy must be calculated separately.

SWAT allows the maximum amount of water that can be held in canopy storage to vary from day to day as a function of the leaf area index. CANMX is the maximum amount of water that can be trapped in the canopy when the canopy is fully developed (mm H₂O).

Required.

ESCO

Soil evaporation compensation factor.

This coefficient has been incorporated to allow the user to modify the depth distribution used to meet the soil evaporative demand to account for the effect of capillary action, crusting and cracks. ESCO must be between 0.01 and 1.0. As the value for ESCO is reduced, the model is able to extract more of the evaporative demand from lower levels.

The change in depth distribution resulting from different values of *esco* are graphed in Figure 19-1.

If no value for ESCO is entered, the model will set ESCO = 0.95. The value for ESCO may be set at the watershed or HRU level (ESCO in .bsn, see Chapter 4).

Required.




Figure 19-1: Soil evaporative demand distribution with depth

EPCO**Plant uptake compensation factor.**

The amount of water uptake that occurs on a given day is a function of the amount of water required by the plant for transpiration, E_t , and the amount of water available in the soil, SW . If upper layers in the soil profile do not contain enough water to meet the potential water uptake, users may allow lower layers to compensate. The plant uptake compensation factor can range from 0.01 to 1.00. As *epco* approaches 1.0, the model allows more of the water uptake demand to be met by lower layers in the soil. As *epco* approaches 0.0, the model allows less variation from the original depth distribution to take place.

If no value for EPCO is entered, the model will set EPCO = 1.0. The value for EPCO may be set at the watershed or HRU level (EPCO in .bsn, see Chapter 4).

Required.

ERORGN**Organic N enrichment ratio for loading with sediment.**

As surface runoff flows over the soil surface, part of the water's energy is used to pick up and transport soil particles. The smaller particles weigh less and are more easily transported than coarser particles. When the particle size distribution of the transported sediment is compared to that of the soil surface layer, the sediment load to the main channel has a greater proportion of clay sized particles. In other words, the sediment load is enriched in clay particles. Organic nitrogen in the soil is attached primarily to colloidal (clay) particles, so the sediment load will also contain a greater proportion or concentration of organic N than that found in the soil surface layer.

The enrichment ratio is defined as the ratio of the concentration of organic nitrogen transported with the sediment to the concentration in the soil surface layer. SWAT will calculate an enrichment ratio for each storm event, or allow the user to define a particular enrichment ratio for organic nitrogen that is used for all storms during the simulation. To calculate the enrichment ratio, the value for ERORGN is set to zero. The default option is to allow the model to calculate the enrichment ratio.

Required.

ERORGP	Phosphorus enrichment ratio for loading with sediment.
	The enrichment ratio is defined as the ratio of the concentration of phosphorus transported with the sediment to the concentration of phosphorus in the soil surface layer. SWAT will calculate an enrichment ratio for each storm event, or allow the user to define a particular enrichment ratio for phosphorus attached to sediment that is used for all storms during the simulation.
	If the value for ERORGP is set to zero, the model will calculate an enrichment ratio for every storm event. The default option is to allow the model to calculate the enrichment ratio.
	Required.
CN3_SWF	Pothole evaporation coefficient
BIOMIX	Biological mixing efficiency.
	Biological mixing is the redistribution of soil constituents as a result of the activity of biota in the soil (e.g. earthworms, etc.). Studies have shown that biological mixing can be significant in systems where the soil is only infrequently disturbed. In general, as a management system shifts from conventional tillage to conservation tillage to no-till there will be an increase in biological mixing. SWAT allows biological mixing to occur to a depth of 300 mm (or the bottom of the soil profile if it is shallower than 300 mm).
	The efficiency of biological mixing is defined by the user and is conceptually the same as the mixing efficiency of a tillage implement. The redistribution of nutrients by biological mixing is calculated using the same methodology as that used for a tillage operation. Biological mixing is performed at the end of every calendar year.
	If no value for BIOMIX is entered, the model will set BIOMIX = 0.20.
	Optional.
PERCO	Percolation coefficient - adjusts soil moisture for perc to occur (1.0 = fc)
LAT_ORGP	Organic P in the base flow (mg/L) (range 0.0 – 200.0) default = 0.0
HARG_PET	Optional. Coefficient related to radiation used in Hargreaves equation

CNCOEF

Plant ET curve number coefficient.

ET weighting coefficient used to calculate the retention coefficient for daily curve number calculations dependent on plant evapotranspiration.

This value can vary between 0.5 and 2.0. If no value is entered for CNCOEF, the model will set CNCOEF = 1.0.

Required if ICN = 1.

TOPOGRAPHY.HYD

Data contained in the topo.dat data file can be grouped into the following categories: topographic characteristics, water flow, erosion, land cover, and depressional storage areas.

Below is a sample TOPOGRAPHY.HYD FILE:

topography.hyd						
HRU	SLP	SLP_LEN	LAT_LEN	DIS_STREAM	DEP_CO	
top1	0.047	50	50	100	1	
top2	0.035	50	50	100	1	
top3	0.148	50	50	100	1	
top4	0.033	50	50	100	1	
top5	0.118	50	50	100	1	
top6	0.064	50	50	100	1	

Variable name	Definition
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank. Optional.
HEADER	Headers for the topography.hyd file.
NAME	Sequential number of topo in file
SLOPE	Average slope steepness in HRU (m/m)
SLOPE_LEN	Average slope length for erosion (m)
LAT_LEN	Slope length for lateral subsurface flow (m)
DIS_STREAM	Average distance to stream (m)
DEP_CO	Deposition coefficient

FIELD.FLD

Below is a sample FIELD.FLD FILE:

field.fld			
NAME	LENGTH	WIDTH	ANGLE
fld1	600	20	30
fld2	600	20	30
fld3	600	20	30
fld4	600	20	30
fld5	600	20	30
fld6	600	20	30

Variable name	Definition
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank. Optional.
HEADER	Headers for the field.fld file.
NAME	Name of the field
LENGTH	Field length for wind erosion (m)
WID	Field width for wind erosion (m)
ANG	Field angle for wind erosion (m)

STRUCTURAL -

TILEDRAIN.STR

Tile drains remove excess water for an area to optimize plant growth. Drains may be added at the beginning of the simulation in the .mgt file. To account for the installation of tile drains mid-simulation, the option was included as a schedulable operation.

Below is a sample TILEDRAIN.STR FILE:

tiledrain.str									
NAME	DEPTH	TIME	LAG	RADIUS	DIST	DRAIN_CO	PUMPCAP	LATKSAT	
mw24_1000	1000	24	96	100	30	10	1	2	

Variable name

Variable name	Definition
TITLE	The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for variables

NAME	Name
DEPTH	Depth of drain tube from the soil surface
TIME	Time to drain soil to field capacity
LAG	Drain tile lag time
RADIUS	Effective radius of drains (mm) Range (3.0 – 40.0 mm)
DIST	Distance between two drain tubes or tiles (mm) Range (7600 – 30000 mm)
DRAIN_CO	Daily drainage coefficient (mm day^{-1}). Tile drainage routines flag/code: 1 = DRAINMOD tile equations (Subroutine DRAINS) Range (10-51 mm day^{-1})
PUMPCAP	Pump capacity (mm h^{-1}) Default value = 1.042 mm h^{-1} or 22 mm day^{-1}
LATKSAT	Multiplication factor to determine lateral ksat (conk(j1,j)) from SWAT ksat input value (sol_k(j1,j)) for HRU Range (0.01 - 4.00)

SEPTIC.STR

The Onsite Wastewater Systems (OWSs) input file contains information related to a diversity of features of OWSs within the subbasin. Data contained in the septic.dat data file are: type of septic system, geometry of biozone, characteristics of biomass, and bio-physical reaction coefficients occurring in the biozone (Adapted from Siegrist et al., 2005).

Below is a partial sample SEPTIC.STR FILE:

septic.str	TYP	YR	OPT	CAP	AREA	TFAIL	DEPTH	THK	TRM_DIST	DENSITY	BD	BOD_DC_OO_CONV	FC1	FC2	FECAL	PLQ	MRT	RSP	SLG1	SLG2	NITR	DENITR	PDISTRB	SORBMAX	SOLPSLP	SOLPINTC	DESC
NAME	1	0	0	2.5	100	70	500	50	0.5	1.5	1000	0.5	0.32	30	0.8	1.3	0.1	0.5	0.16	0.3	0.5	1.5	0.32	128	850	0.04	3.1 Standard_system
standard	1	0	0	2.5	100	1	500	50	0.5	1.5	1000	0.5	0.32	30	0.8	1.3	0.1	0.5	0.16	0.3	0.5	1.5	0.32	128	850	0.04	3.1 Failing_system

Variable name

TITLE

Definition

The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.

HEADER

Headings for variables

NAME

Name

TYP

The type of septic system

Type	Definition
1	Generic type conventional system
2	Generic type advanced system
3	Septic tank with conventional drainfield
4	Septic tank with SAS ^a type 1
5	Septic tank with SAS type 2
6	Septic tank with in-tank N removal and SAS
7	Septic tank with effluent N removal recycle
8	Septic tank with corrugated plastic trickling Filter
9	Septic tank with open-cell form trickling filter
10	Single pass sand filter 1
11	Single pass sand filter 2
12	Single pass sand filter 3
13	Single pass sand filter 4
14	At grade recirculating sand filter
15	Maryland style RSF ^b
16	RSF
17	Septic tank w/ constructed wetland and surface water discharge
18	Municipal wastewater w/ constructed wetland and surface water discharge 1
19	Municipal wastewater w/ constructed wetland and surface water discharge 2
20	Municipal wastewater w/ constructed wetland
21	Municipal wastewater w/ lagoon and constructed wetland
22	Waterloo biofilter (plastic media) 1
23	Waterloo biofilter (plastic media) 2
24	Peat biofilter
25	Recirculating textile filter
26	Foam or textile filter effluent
27	Septic, recirculating gravel filter, UV disinfection
28	Untreated Effluent - Texas A&M reference

YR

Year the septic system became operational (eg 1980).

If 0 is input for *isep_iyr*, the model assumes the septic system is in operation at the beginning of the simulation

Required.

OPT	Initial septic HRU operational condition. User can define the default condition of a septic HRU as either active (<i>sep_opt</i> =1), failing (<i>sep_opt</i> =2), or non-septic (<i>sep_opt</i> =0). An active system automatically becomes failing as biozone layer gets clogged over time. A failing system turns to an active system after user specified “number of days for rehabilitation” defined by <i>isep_tfail</i> .
	Required.
CAP	Number of permanent residents in the house. SEP_cap for a typical US residence is 2.5 and ranges 1~10000.
	Required.
AREA	Average area of drainfield of individual septic systems (m ²).
	Typically recommended drainfield area per person is about 40 to 70 (m ²). This varies from state to state in the United States. For a household with 2.5 people, generally a drainfield area of 100 (m ²) is recommended. User can modify the bz_area based on the number of people in a household. The bz_area and sep_cap may be modified appropriately to study the effects of larger population size using septic systems.
	Required
TFAIL	Time until failing systems gets fixed (days). An active system becomes failing as the biozone gets clogged and hydraulic failure occurs. A failing system automatically turns active during the simulation and septic parameters are re-initialized to default values after the user specified number of days (days assigned for <i>isep_tfail</i>) for rehabilitation. The default value for <i>isep_tfail</i> is 70 days but it can range between 10~100000 days. For testing long term failure, <i>isep_tfail</i> can be increased as per the failing duration. <i>isep_opt</i> should be set at 2 for simulating failing conditions..
	Required.
Z	Depth to the top of biozone layer from the ground surface (mm). The thickness includes top soil layer and septic tank effluent (STE) distribution chamber including perforated pipe. The default is 500mm and the depth typically ranges between 10-10000mm.
	Required.

THK	Thickness of the biozone layer (mm). The biozone layer is thin soil layer underneath the STE distribution chamber where pollutants are degraded by naturally existing live biomass bacteria. The default thickness is 50mm and ranges 5~100mm.
	Required.
STRM_DIST	Distance to the stream from the septic HRU (km)
	Currently not available.
DENSITY	Number of septic systems per square kilometer.
	Currently not available.
BD	Density of biomass (kg/m^3), typically in the range of 900~1100 kg/m^3 . The default is 1000 kg/m^3 .
	Required.
BOD_DC	BOD decay rate coefficient. Biozone BOD coefficient is normalized by the volume of biomass in the formula. The default value is 0.5 and the value ranges 0.1~ 5.
	Required.
BOD_CONV	A conversion factor representing the proportion of mass bacterial growth and mass BOD degraded in the STE. The default value is 0.32 and the value ranges 0.1~ 0.5.
	Required.
FC1	Linear coefficient for calculation of field capacity in the biozone. The default value is 30 and the value ranges 0~ 50.
	Required.
FC2	Exponential coefficient for calculation of field capacity in the biozone. The default value is 0.8 and the value ranges 0.5~ 1.
	Required.
FECAL	Fecal coliform bacteria decay rate coefficient. Biozone fecal coliform coefficient is normalized by the volume of biomass in the formula. The default value is 1.3 and the value ranges 0.5~ 2.
	Required.

PLQ	Conversion factor for plaque from total dissolved solids. The default value is 0.1 and the value ranges 0.08~ 0.95.
	Required.
MRT	Mortality rate coefficient. The default value is 0.5 and the value ranges 0.01~ 1.
	Required.
RSP	Respiration rate coefficient. The default value is 0.16 and the value ranges 0.01~ 1.
	Required.
SLG1	Linear coefficient for calculating the rate of biomass sloughing. The default value is 0.3 and the value ranges 0.01~ 0.5.
	Required.
SLG2	Exponential coefficient for calculating the rate of biomass sloughing. The default value is 0.5 and the value ranges 0.1~ 2.5.
	Required.
NITR	Nitrification rate coefficient. Biozone nitrification rate coefficient is normalized by the volume of biomass in the formula. The default value is 1.5 and the value ranges 0.1~ 300.
	Required.
DENITR	Denitrification rate coefficient. Biozone denitrification rate coefficient is normalized by the volume of biomass in the formula. The default value is 0.32 and the value ranges 0.1~50.
	Required.
PDISTRB	Linear P sorption distribution coefficient (L/kg). The default value is 128 and the value ranges 1.4~478.
	Required.
PSORPMAX	Maximum P sorption capacity (mg P/kg Soil). The default value is 850 and the value ranges 0~17600.
	Required.

SOLPSLP Slope of the linear effluent soluble P equation. The default value is 0.04 and the value ranges 0~0.3.

Required.

SOLPINTC Intercept of the linear effluent soluble P equation. The default value is 3.1 and the value ranges 0~10.

Required.

FILTERSTRIP.STR

A filter strip is a strip of dense vegetation located to intercept runoff from upslope pollutant sources and filter it. Filter strips remove contaminants by reducing overland flow velocity which results in the deposition of particulates. The filter strip area also acts as an area of increased infiltration, reducing both the runoff volume and non-particulate contaminants. The filter strip used algorithm used in SWAT was derived from White and Arnold (2009). Filter strips reduce sediment, nutrients, bacteria, and pesticides, but do not affect surface runoff in SWAT. The variables which may be entered on the pesticide application line are listed and described below.

Below is a sample FILTERSTRIP.STR FILE:

filterstrip.str							
NAME	VFSRATIO	VFSCON	VFSCH				
field_border	0.1	0.003	0.2	Field_border			
high_engineered	0.1	0.001	0.05	Highly_engineered_low_channelized			

Variable name

Definition

TITLE

The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.

HEADER

Headings for variables

NAME

Name

VFSI

Flag for the simulation of filter strips (VFSI = 1/0 active/inactive).

VFSRATIO

Ratio of field area to filter strip area (unitless). Ranges from 0 to 300 with values from 30-60 being most common. Default value is 40

VFSCON

Fraction of the HRU which drains to the most concentrated ten percent of the filters strip area. Runoff generated upslope a filter strip is not uniformly distributed across the entire length of the strip. Ten percent of the filter strip can receive between 0.25 and 0.75 of the runoff from the entire filed. Default value is 0.5.

VFSCH

Fraction of the flow within the most concentrated ten percent of the filter strip which is fully channelized (dimensionless). Flow which is fully channelized is not subject to filtering or infiltration effects. Default value is 0.0

GRASSEDWW.STR

Grassed waterways are vegetated channels which transport runoff from a field. Vegetation within the waterways reduces flow velocities, and protects the waterway from the scouring potential of concentrated flow. These are generally broad and shallow channels; the channel simulated in SWAT has a side slope of 8:1. Grasses waterways trap sediment and other contaminants by reducing flow velocities which increases deposition of particulate contaminates.

Below is a sample GRASSEDWW.STR FILE:

grassedww.str								
NAME	MAN_N	SPCON	DEPTH	WIDTH	LENGTH	SLOPE	DESC	
grwway_high	0.05	0.02	1	4	0.5	0.1	Slope_>8	
grwway_med	0.05	0.02	0.75	3	0.75	0.035	Slope_2-5	
grwway_low	0.05	0.02	0.5	2	1	0.01	Slope_0-2	

Variable name**Definition**

TITLE

The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.

HEADER

Headings for variables

NAME

Name

GRWAT_I

On/off Flag for waterway simulation

GRWAT_N

Mannings's n for grassed waterway

GRWAT_SPCON

sediment transport coefficient defined by user

GRWAT_D

depth of Grassed waterway (m)

GRWAT_W

width of grass waterway

GRWAT_L

length of Grass Waterway (km)

GRWAT_S

slope of grass waterway (m/m)

BMPUSER.STR

There are many conservation practices for which approximate removal efficiencies have been established which are unsupported by SWAT or any other existing model. To allow these practices to be included, this generic conservation practice operation allows fixed removal efficiencies to be specified by constituent.

Below is a sample BMPUSER.STR FILE:

bmpuser.str - Little River Experimental Watershed							
NAME	BMP_FLAG	BMP_SED	BMP_PP	BMP_SP	BMP_PN	BMP_SN	BMP_BAC
bmpusr1	1	0.2	0.2	0.2	0.2	0.2	0.2

Variable name	Definition
TITLE	The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for variables
NAME	User BMP Name
BMP_FLAG	Code to turn on/off user BMP (range 0-1)(mgt1i)
BMP_SED	Sediment removal by BMP (%) (range 0-100)
BMP_PP	Particulate (Organic) phosphorous removal by BMP (%) (range 0-100)
BMP_SP	Soluble phosphorous removal by BMP (%) (range 0-100)
BMP_PN	Particulate (Organic) nitrogen removal by BMP (%) (range 0-100)
BMP_SN	Soluble nitrogen removal by BMP (%) (range 0-100)
BMP_BAC	Bacteria removed by BMP (%) (range 0-100)

HRU PARM DB– The parameters database files are supplied with the model containing Input parameters for most of the common plants, fertilizers, pesticides, urban, are included in the database files with the option for the user to add new parameters to each file.

PLANTS.PLT

HEAT UNITS TO MATURITY

We took the PHU program and incorporated it directly into SWAT+ (currently in subroutine plants_init). Only one input change was required. In the plants.plt file, we changed the heat units to maturity (phu_mat) to days to maturity (days_mat). The concept of heat units to maturity was developed for annual crops and we use heat units for the entire growing season for native perennials and native annuals. By inputting days to maturity, we can include different crop varieties as defined by length of growing season (for example, corn varieties for 120, 110, 100 and 90 day varieties). The heat units to maturity calculation in the model first computes base zero heat units for the entire year and assumes a planting date when heat units exceed 0.15*base zero. Then, the model calculates heat units from planting date through the days to maturity, using the crops base temperature as input in plants.plt. If the maximum days for a crop are input (120 days for corn) and the growing season is less than 120 days, the model essentially sums heat units for the entire growing season which represents (and estimates) the maximum days to maturity. This is the exact procedure used in the phu program.

The algorithm currently uses monthly weather generator parameters but could be modified to alternatively use daily temperature inputs. The model provides heat unit estimates in both the northern and southern hemispheres.

There are several advantages to incorporating the heat unit program into SWAT+ including:

1) Eliminates the need for running on external program when developing inputs, 2) allows input of a commonly understood variable (days) instead of a variable that is not commonly known at every location (heat units), 3) allows the model to calculate heat units for native perennials and annual that are location dependent, 4) a database (plants.plt) can be maintained and supported that include different crop seasonal varieties, and 5) by inputting the maximum growing season for a crop, the model will calculate appropriate heat units for that crop anywhere in the northern or southern hemisphere.

Information required to simulate plant growth is stored by plant species in the plant growth database file. This database file is supplied with the model. The plant growth database distributed with SWAT includes parameters for most of the common plant species. If a user needs to model a land use or plant not included in the database, please feel free to contact the SWAT development team for assistance in determining plant parameters. Appendix A documents the source of parameter values in the distributed database file. Below is a partial sample PLANTS.PLT file (see plants.plt in example input dataset directory for complete file):

plants.plt:													
name	plnt_typ	plnt_hu	bm_e	harv_idx	lai_pot	frac_hu1	lai_max1	frac_hu2	lai_max2	hu_lai_deccan_ht_m:	can_ht_m:	rt_dp_max	
agrl	warm_ann	2000	33.5	0.45	3	0.15	0.05	0.5	0.95	0.64	1	2	
agrr	warm_ann	2000	39	0.5	3	0.15	0.05	0.5	0.95	0.7	2.5	2	
agrc	cold_annu	2000	30	0.4	4	0.05	0.05	0.45	0.95	0.5	0.9	1.3	
orcd	trees	2000	15	0.1	4	0.1	0.15	0.5	0.75	0.99	3.5	2	
hay	perennial	2000	35	0.9	4	0.05	0.05	0.49	0.95	0.99	0.5	2	
frst	trees	2000	15	0.76	5	0.05	0.05	0.4	0.95	0.99	6	3.5	
frsd	trees	2000	15	0.76	5	0.05	0.05	0.4	0.95	0.99	6	3.5	
frse	trees	2000	15	0.76	5	0.15	0.7	0.25	0.99	0.99	10	3.5	
wetl	perennial	2000	47	0.9	6	0.1	0.2	0.2	0.95	0.7	2.5	2.2	
wetf	trees	2000	15	0.76	5	0.05	0.05	0.4	0.95	0.99	6	3.5	
wetn	perennial	2000	47	0.9	6	0.1	0.2	0.2	0.95	0.7	2.5	2.2	

Variable name	Definition
TITLE	The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for variables
PLANTNM	A four character code to represent the land cover/plant name. The 4-letter codes in the plant growth and urban databases are used by the GIS interfaces to link land use/land cover maps to SWAT plant types. This code is printed to the output files. When adding a new plant species or land cover category, the four letter code for the new plant must be unique. Required.

PLNT_TYP Land cover/plant classification (read in as character):

perennial
warm_annual
cold_annual

fall-planted land covers will go dormant when daylength
is less than the threshold daylength

NFIX_CO N fixation coefficient (0.5 =legume; 0=non-legume)

Variable name	Definition
PHU	Total number of heat units to bring crop to maturity
BIO_E	Radiation-use efficiency or biomass-energy ratio ((kg/ha)/(MJ/m ²)). Radiation-use efficiency (RUE) is the amount of dry biomass produced per unit intercepted solar radiation. The radiation-use efficiency is assumed to be independent of the plant's growth stage. BIO_E represents the potential or unstressed growth rate (including roots) per unit of intercepted photosynthetically active radiation.

Variable name	Definition
BIO_E, cont.	<p>Determination of RUE is commonly performed and a literature review will provide those setting up experiments with numerous examples. The following overview of the methodology used to measure RUE was summarized from Kiniry et al (1998) and Kiniry et al (1999).</p> <p>To calculate RUE, the amount of photosynthetically active radiation (PAR) intercepted and the mass of aboveground biomass is measured several times throughout a plant's growing season. The frequency of the measurements taken will vary but in general 4 to 7 measurements per growing season are considered to be adequate. As with leaf area determinations, the measurements should be performed on non-stressed plants.</p> <p>Intercepted radiation is measured with a light meter. Whole spectrum and PAR sensors are available and calculations of RUE will be performed differently depending on the sensor used. A brief discussion of the difference between whole spectrum and PAR sensors and the difference in calculations is given in Kiniry (1999). The use of a PAR sensor in RUE studies is strongly encouraged.</p> <p>When measuring radiation, three to five sets of measurements are taken rapidly for each plant plot. A set of measurements consists of 10 measurements above the leaf canopy, 10 below, and 10 more above. The light measurements should be taken between 10:00 am and 2:00 pm local time.</p> <p>The measurements above and below the leaf canopy are averaged and the fraction of intercepted PAR is calculated for the day from the two values. Daily estimates of the fraction of intercepted PAR are determined by linearly interpolating the measured values.</p>

Variable name	Definition
BIO_E, cont.	<p>The <i>fraction</i> of intercepted PAR is converted to an <i>amount</i> of intercepted PAR using daily values of incident total solar radiation measured with a standard weather station. To convert total incident radiation to total incident PAR, the daily solar radiation values are multiplied by the percent of total radiation that has a wavelength between 400 and 700 nm. This percent usually falls in the range 45 to 55% and is a function of cloud cover. 50% is considered to be a default value.</p> <p>Once daily intercepted PAR values are determined, the total amount of PAR intercepted by the plant is calculated for each date on which biomass was harvested. This is calculated by summing daily intercepted PAR values from the date of seedling emergence to the date of biomass harvest.</p> <p>To determine biomass production, aboveground biomass is harvested from a known area of land within the plot. The plant material should be dried at least 2 days at 65°C and then weighed.</p> <p>RUE is determined by fitting a linear regression for aboveground biomass as a function of intercepted PAR. The slope of the line is the RUE. Figure 14-1 shows the plots of aboveground biomass and summed intercepted photosynthetically active radiation for Eastern gamagrass. (Note that the units for RUE values in the graph, as well as values typically reported in literature, are different from those used by SWAT. To obtain the value used in SWAT, multiply by 10.)</p> <p>This parameter can greatly change the rate of growth, incidence of stress during the season and the resultant yield. This parameter should be one of the last to be adjusted. Adjustments should be based on research results. Care should be taken to make adjustments based only on data with no drought, nutrient or temperature stress.</p> <p>Required.</p>

Variable name	Definition
---------------	------------




Figure 14-1: Aboveground biomass and summed intercepted photosynthetically active radiation for Eastern gamagrass (after Kiniry et al., 1999).

HVSTI

Harvest index for optimal growing conditions.

The harvest index defines the fraction of the aboveground biomass that is removed in a harvest operation. This value defines the fraction of plant biomass that is “lost” from the system and unavailable for conversion to residue and subsequent decomposition. For crops where the harvested portion of the plant is aboveground, the harvest index is always a fraction less than 1. For crops where the harvested portion is belowground, the harvest index may be greater than 1. Two harvest indices are provided in the database, the harvest index for optimal growing conditions (HVSTI) and the harvest index under highly stressed growing conditions (WSYF).

Variable name	Definition
HVSTI, cont.	<p>To determine the harvest index, the plant biomass removed during the harvest operation is dried at least 2 days at 65°C and weighed. The total aboveground plant biomass in the field should also be dried and weighed. The harvest index is then calculated by dividing the weight of the harvested portion of the plant biomass by the weight of the total aboveground plant biomass. Plants will need to be grown in two different plots where optimal climatic conditions and stressed conditions are produced to obtain values for both harvest indices.</p> <p>Required.</p>
BLAI	<p>Maximum potential leaf area index.</p> <p>BLAI is one of six parameters used to quantify leaf area development of a plant species during the growing season. Figure 14-2 illustrates the relationship of the database parameters to the leaf area development modeled by SWAT.</p>




Figure 14-2: Leaf area index as a function of fraction of growing season for Alamo switchgrass

Variable name	Definition
BLAI, cont.	<p>To identify the leaf area development parameters, record the leaf area index and number of accumulated heat units for the plant species throughout the growing season and then plot the results. For best results, several years worth of field data should be collected. At the very minimum, data for two years is recommended. It is important that the plants undergo no water or nutrient stress during the years in which data is collected.</p> <p>The leaf area index incorporates information about the plant density, so field experiments should either be set up to reproduce actual plant densities or the maximum LAI value for the plant determined from field experiments should be adjusted to reflect plant densities desired in the simulation. Maximum LAI values in the default database correspond to plant densities associated with rainfed agriculture.</p> <p>The leaf area index is calculated by dividing the green leaf area by the land area. Because the entire plant must be harvested to determine the leaf area, the field experiment needs to be designed to include enough plants to accommodate all leaf area measurements made during the year.</p> <p>Although measuring leaf area can be laborious for large samples, there is no intrinsic difficulty in the process. The most common method is to obtain an electronic scanner and feed the harvested green leaves and stems into the scanner. Older methods for estimating leaf area include tracing of the leaves (or weighed subsamples) onto paper, the use of planimeters, the punch disk method of Watson (1958) and the linear dimension method of Duncan and Hesketh (1968).</p> <p>Chapter 5:1 in the Theoretical Documentation reviews the methodology used to calculate accumulated heat units for a plant at different times of the year as well as determination of the fraction of total, or potential, heat units that is required for the plant database.</p>

Variable name	Definition
BLAI, cont.	<p>The values for BLAI in the plant growth database are based on average plant densities in dryland (rainfed) agriculture. BLAI may need to be adjusted for drought-prone regions where planting densities are much smaller or irrigated conditions where densities are much greater.</p> <p>Required.</p>
FRGRW1	<p>Fraction of the plant growing season or fraction of total potential heat units corresponding to the 1st point on the optimal leaf area development curve.</p> <p>Please see Figure 14-2 and the explanation given for parameter BLAI to obtain additional information about this parameter and methods used to measure it.</p> <p>Required.</p>
LAIMX1	<p>Fraction of the maximum leaf area index corresponding to the 1st point on the optimal leaf area development curve.</p> <p>Please see Figure 14-2 and the explanation given for parameter BLAI to obtain additional information about this parameter and methods used to measure it.</p> <p>Required.</p>
FRGRW2	<p>Fraction of the plant growing season or fraction of total potential heat units corresponding to the 2nd point on the optimal leaf area development curve.</p> <p>Please see Figure 14-2 and the explanation given for parameter BLAI to obtain additional information about this parameter and methods used to measure it.</p> <p>Required.</p>
LAIMX2	<p>Fraction of the maximum leaf area index corresponding to the 2nd point on the optimal leaf area development curve.</p> <p>Please see Figure 14-2 and the explanation given for parameter BLAI to obtain additional information about this parameter and methods used to measure it.</p> <p>Required.</p>

Variable name	Definition
DLAI	<p>Fraction of growing season when leaf area begins to decline.</p> <p>Please see Figure 14-2 and the explanation given for parameter BLAI to obtain additional information about this parameter and methods used to measure it.</p> <p>Required.</p>
CHTMX	<p>Maximum canopy height (m).</p> <p>Maximum canopy height is a straightforward measurement. The canopy height of non-stressed plants should be recorded at intervals throughout the growing season. The maximum value recorded is used in the database.</p> <p>Required.</p>
RDMX	<p>Maximum root depth (m).</p> <p>To determine maximum rooting depth, plant samples need to be grown on soils without an impermeable layer. Once the plants have reached maturity, soil cores are taken for the entire depth of the soil. Each 0.25 meter increment is washed and the live plant material collected. Live roots can be differentiated from dead roots by the fact that live roots are whiter and more elastic and have an intact cortex. The deepest increment of the soil core in which live roots are found defines the maximum rooting depth.</p> <p>Required.</p>
T_OPT	<p>Optimal temperature for plant growth (°C).</p> <p>Both optimal and base temperatures are very stable for cultivars within a species.</p> <p>Optimal temperature for plant growth is difficult to measure directly. Looking at Figure 14-3, one might be tempted to select the temperature corresponding to the peak of the plot as the optimal temperature. This would not be correct.</p>

Variable name	Definition
T_OPT, cont.	<p>The peak of the plot defines the optimal temperature for leaf development—not for plant growth.</p> <p>If an optimal temperature cannot be obtained through a review of literature, use the optimal temperature listed for a plant already in the database with similar growth habits.</p> <p>Review of temperatures for many different plants have provided generic values for base and optimal temperatures as a function of growing season. In situations, where temperature information is unavailable, these values may be used. For warm season plants, the generic base temperature is ~8°C and the generic optimal temperature is ~25°C. For cool season plants, the generic base temperature is ~0°C and the generic optimal temperature is ~13°C.</p> <p>Required.</p>
T_BASE	<p>Minimum (base) temperature for plant growth (°C).</p> <p>SWAT uses the base temperature to calculate the number of heat units accrued every day. The minimum or base temperature for plant growth varies with growth stage of the plant. However, this variation is ignored by the model—SWAT uses the same base temperature throughout the growing season.</p> <p>Base temperature is measured by growing plants in growth chambers at several different temperatures. The rate of leaf tip appearance as a function of temperature is plotted. Extrapolating the line to the leaf tip appearance rate of 0.0 leaves/day gives the base or minimum temperature for plant growth. Figure 14-3 plots data for corn. (Note that the line intersects the x-axis at 8°C.)</p> <p>Required.</p>

Variable name	Definition
T_BASE, cont.	




Figure 14-3: Rate of leaf tip appearance as a function of temperature for corn (after Kiniry et al, 1991)

CNYLD Normal fraction of nitrogen in yield (kg N/kg yield).

In addition to the amount of plant biomass removed in the yield, SWAT needs to know the amount of nitrogen and phosphorus removed in the yield. The harvested portion of the plant biomass is sent to a testing laboratory to determine the fraction of nitrogen and phosphorus in the biomass.

This value is estimated on a dry weight basis.

Required.

CPYLD Normal fraction of phosphorus in yield (kg P/kg yield).

In addition to the amount of plant biomass removed in the yield, SWAT needs to know the amount of nitrogen and phosphorus removed in the yield. The harvested portion of the plant biomass is sent to a testing laboratory to determine the fraction of nitrogen and phosphorus in the biomass.

This value is estimated on a dry weight basis.

Required.

Variable name	Definition
PLTNFR1	<p>Nitrogen uptake parameter #1: normal fraction of nitrogen in plant biomass at emergence (kg N/kg biomass)</p> <p>In order to calculate the plant nutrient demand throughout a plant's growing cycle, SWAT needs to know the fraction of nutrient in the total plant biomass (on a dry weight basis) at different stages of crop growth. Six variables in the plant database provide this information: PLTNFR(1), PLTNFR(2), PLTNFR(3), PLTPFR(1), PLTPFR(2), and PLTPFR(3). Plant samples are analyzed for nitrogen and phosphorus content at three times during the growing season: shortly after emergence, near the middle of the season, and at maturity. The plant samples can be sent to testing laboratories to obtain the fraction of nitrogen and phosphorus in the biomass.</p> <p>Ideally, the plant samples tested for nutrient content should include the roots as well as the aboveground biomass. Differences in partitioning of nutrients to roots and shoots can cause erroneous conclusions when comparing productivity among species if only the aboveground biomass is measured.</p> <p>Required.</p>
PLTNFR2	<p>Nitrogen uptake parameter #2: normal fraction of nitrogen in plant biomass at 50% maturity (kg N/kg biomass)</p> <p>Please read the explanation for parameter PLTNFR(1) to obtain additional information about this parameter and methods used to measure it.</p> <p>Required.</p>
PLTNFR3	<p>Nitrogen uptake parameter #3: normal fraction of nitrogen in plant biomass at maturity (kg N/kg biomass)</p> <p>Please read the explanation for parameter PLTNFR(1) to obtain additional information about this parameter and methods used to measure it.</p> <p>Required.</p>

Variable name	Definition
PLTPFR1	<p>Phosphorus uptake parameter #1: normal fraction of phosphorus in plant biomass at emergence (kg P/kg biomass)</p> <p>Please read the explanation for parameter PLTNFR(1) to obtain additional information about this parameter and methods used to measure it.</p> <p>Required.</p>
PLTPFR2	<p>Phosphorus uptake parameter #2: normal fraction of phosphorus in plant biomass at 50% maturity (kg P/kg biomass)</p> <p>Please read the explanation for parameter PLTNFR(1) to obtain additional information about this parameter and methods used to measure it.</p> <p>Required.</p>
PLTPFR3	<p>Phosphorus uptake parameter #3: normal fraction of phosphorus in plant biomass at maturity (kg P/kg biomass)</p> <p>Please read the explanation for parameter PLTNFR(1) to obtain additional information about this parameter and methods used to measure it.</p> <p>Required.</p>
WSYF	<p>Lower limit of harvest index ((kg/ha)/(kg/ha)).</p> <p>The value between 0.0 and HVSTI which represents the lowest harvest index expected due to water stress.</p> <p>Please read the explanation for parameter HVSTI to obtain additional information about this parameter and methods used to measure it.</p> <p>Required.</p>

Variable name	Definition
USLE_C	<p>Minimum value of USLE C factor for water erosion applicable to the land cover/plant.</p> <p>The minimum C factor can be estimated from a known average annual C factor using the following equation (Arnold and Williams, 1995):</p> $C_{USLE,mn} = 1.463 \ln[C_{USLE,aa}] + 0.1034$ <p>where $C_{USLE,mn}$ is the minimum C factor for the land cover and $C_{USLE,aa}$ is the average annual C factor for the land cover.</p> <p>Required.</p>
GSI	<p>Maximum stomatal conductance at high solar radiation and low vapor pressure deficit ($\text{m}\cdot\text{s}^{-1}$).</p> <p>Stomatal conductance of water vapor is used in the Penman-Monteith calculations of maximum plant evapotranspiration. The plant database contains three variables pertaining to stomatal conductance that are required only if the Penman-Monteith equations are chosen to model evapotranspiration: maximum stomatal conductance (GSI), and two variables that define the impact of vapor pressure deficit on stomatal conductance (FRGMAX, VPDFR).</p> <p>Körner et al (1979) defines maximum leaf diffusive conductance as the largest value of conductance observed in fully developed leaves of well-watered plants under optimal climatic conditions, natural outdoor CO₂ concentrations and sufficient nutrient supply. Leaf diffusive conductance of water vapor cannot be measured directly but can be calculated from measurements of transpiration under known climatic conditions. A number of different methods are used to determine diffusive conductance: transpiration measurements in photosynthesis cuvettes, energy balance measurements or weighing experiments, ventilated diffusion porometers and non-ventilated porometers. Körner (1977) measured diffusive conductance using a ventilated diffusion porometer.</p>

Variable name	Definition
GSI, cont.	<p>To obtain maximum leaf conductance values, leaf conductance is determined between sunrise and late morning until a clear decline or no further increase is observed. Depending on phenology, measurements are taken on at least three bright days in late spring and summer, preferably just after a rainy period. The means of maximum leaf conductance of 5 to 10 samples each day are averaged, yielding the maximum diffusive conductance for the species. Due to the variation of the location of stomata on plant leaves for different plant species, conductance values should be calculated for the total leaf surface area.</p> <p>Required.</p>
VPDFR	<p>Vapor pressure deficit (kPa) corresponding to the second point on the stomatal conductance curve.</p> <p>(The first point on the stomatal conductance curve is comprised of a vapor pressure deficit of 1 kPa and the fraction of maximum stomatal conductance equal to 1.00.)</p> <p>As with radiation-use efficiency, stomatal conductance is sensitive to vapor pressure deficit. Stockle et al (1992) compiled a short list of stomatal conductance response to vapor pressure deficit for a few plant species. Due to the paucity of data, default values for the second point on the stomatal conductance vs. vapor pressure deficit curve are used for all plant species in the database. The fraction of maximum stomatal conductance (FRGMAX) is set to 0.75 and the vapor pressure deficit corresponding to the fraction given by FRGMAX (VPDFR) is set to 4.00 kPa. If the user has actual data, they should use those values, otherwise the default values are adequate.</p> <p>Required.</p>

Variable name	Definition
GMAXFR	<p>Fraction of maximum stomatal conductance corresponding to the second point on the stomatal conductance curve.</p> <p>(The first point on the stomatal conductance curve is comprised of a vapor pressure deficit of 1 kPa and the fraction of maximum stomatal conductance equal to 1.00.)</p>
WAVP	<p>Please read the explanation for parameter VPDFR to obtain additional information about this parameter and methods used to measure it.</p> <p>Required.</p> <p>Rate of decline in radiation use efficiency per unit increase in vapor pressure deficit.</p> <p>Stockle and Kiniry (1990) first noticed a relationship between RUE and vapor pressure deficit and were able to explain a large portion of within-species variability in RUE values for sorghum and corn by plotting RUE values as a function of average daily vapor pressure deficit values. Since this first article, a number of other studies have been conducted that support the dependence of RUE on vapor pressure deficit. However, there is still some debate in the scientific community on the validity of this relationship. If the user does not wish to simulate a change in RUE with vapor pressure deficit, the variable WAVP can be set to 0.0 for the plant.</p> <p>To define the impact of vapor pressure deficit on RUE, vapor pressure deficit values must be recorded during the growing seasons that RUE determinations are being made. It is important that the plants are exposed to no other stress than vapor pressure deficit, i.e. plant growth should not be limited by lack of soil water and nutrients.</p> <p>Vapor pressure deficits can be calculated from relative humidity (see Chapter 1:2 in Theoretical Documentation) or from daily maximum and minimum temperatures using the technique of Diaz and Campbell (1988) as described by Stockle and Kiniry (1990). The change in RUE with vapor pressure deficit is determined by fitting a linear regression for RUE as a function of vapor pressure deficit. Figure 14-4 shows a plot of RUE as a function of vapor pressure deficit for grain sorghum.</p>

Variable name	Definition
WAVP, cont.	




Figure 14-4: Response of radiation-use efficiency to mean daily vapor pressure deficit for grain sorghum (after Kiniry, 1999).

From Figure 14-4, the rate of decline in radiation-use efficiency per unit increase in vapor pressure deficit, $\Delta r_{ue_{del}}$, for sorghum is $8.4 \times 10^{-1} \text{ g} \cdot \text{MJ}^{-1} \cdot \text{kPa}^{-1}$. When RUE is adjusted for vapor pressure deficit, the model assumes the RUE value reported for BIO_E is the radiation-use efficiency at a vapor pressure deficit of 1 kPa.

The value of WAVP varies among species, but a value of 6 to 8 is suggested as an approximation for most plants.

Required.

CO2HI
Elevated CO₂ atmospheric concentration (μL CO₂/L air) corresponding the 2nd point on the radiation use efficiency curve.

(The 1st point on the radiation use efficiency curve is comprised of the ambient CO₂ concentration, 330 μL CO₂/L air, and the biomass-energy ratio reported for BIO_E)

Variable name	Definition
CO2HI, cont.	<p>In order to assess the impact of climate change on agricultural productivity, SWAT incorporates equations that adjust RUE for elevated atmospheric CO₂ concentrations. Values must be entered for CO2HI and BIOEHI in the plant database whether or not the user plans to simulate climate change.</p> <p>For simulations in which elevated CO₂ levels are not modeled, CO2HI should be set to some number greater than 330 ppmv and BIOEHI should be set to some number greater than BIO_E.</p> <p>To obtain radiation-use efficiency values at elevated CO₂ levels for plant species not currently in the database, plants should be established in growth chambers set up in the field or laboratory where CO₂ levels can be controlled. RUE values are determined using the same methodology described in the explanation of BIO_E.</p> <p>Required.</p>
BIOEHI	<p>Biomass-energy ratio corresponding to the 2nd point on the radiation use efficiency curve.</p> <p>(The 1st point on the radiation use efficiency curve is comprised of the ambient CO₂ concentration, 330 µL CO₂/L air, and the biomass-energy ratio reported for BIO_E.)</p> <p>Please read the explanation for parameter CO2HI and BIO_E to obtain additional information about this parameter and methods used to measure it.</p> <p>Required.</p>
RSDCO_PL	<p>Plant residue decomposition coefficient.</p> <p>The plant residue decomposition coefficient is the fraction of residue that will decompose in a day assuming optimal moisture, temperature, C:N ratio, and C:P ratio.</p> <p>This variable was originally in the basin input file (.bsn), but was added to the crop database so that users could vary decomposition by plant species. A default value of 0.05 is used for all plant species in the database.</p> <p>Required.</p>

Variable name	Definition
ALAI_MIN	<p>Minimum leaf area index for plant during dormant period (m^2/m^2).</p> <p>This variable pertains to perennials and trees only. (The value is never used for other types of plants.) In versions of SWAT prior to SWAT2012, the minimum leaf area index for plants during the dormant period was always set to 0.75. Because this value was not ideal for all plants (trees in particular), users are now allowed to vary the minimum LAI for dormancy.</p> <p>Please see the explanation given for parameter BLAI to obtain additional information about this parameter and methods used to measure it.</p> <p>Required.</p>
LAIXCO_TREE	<p>Fraction of tree biomass accumulated each year that is converted to residue during dormancy.</p> <p>This variable pertains to trees only. (The value is never used for other types of plants.) BIO_LEAF governs the amount of biomass that falls off the tree and is converted to residue when the plant goes dormant in the winter. In versions of SWAT prior to SWAT2012, the fraction of biomass converted to residue at the beginning of dormancy was always defined as 0.30.</p> <p>Required if land cover is classified as a tree (see IDC).</p>
MAT_YRS	<p>Number of years required for tree species to reach full development (years).</p> <p>This variable pertains to trees only. (The value is never used for other types of plants.)</p> <p>Required if land cover is classified as a tree (see IDC).</p>
BMX_PEREN	<p>Maximum biomass for a forest (metric tons/ha).</p> <p>This variable pertains to trees only. (The value is never used for other types of plants.)</p> <p>The maximum biomass for a mature forest stand generally falls in the range of 30-50 metric tons/ha.</p> <p>Required if land cover is classified as a tree (see IDC).</p>
EXT_COEF	<p>Light extinction coefficient.</p> <p>This coefficient is used to calculate the amount of intercepted photosynthetically active radiation. In versions of SWAT prior to SWAT2012, the light extinction coefficient was always defined as 0.65.</p>

**EXT_COEF
(CONT)**

Differences in canopy structure for a species are described by the number of leaves present (leaf area index) and the leaf orientation. Leaf orientation has a significant impact on light interception and consequently on radiation-use efficiency. More erect leaf types spread the incoming light over a greater leaf area, decreasing the average light intensity intercepted by individual leaves (Figure 14-5). A reduction in light intensity interception by an individual leaf favors a more complete conversion of total canopy-intercepted light energy into biomass.




Figure 14-5: Light intensity interception as a function of leaf orientation. The vertically oriented leaf intercepts 4 units of light while a horizontally oriented leaf of the same length intercepts 6 units of light.

Using the light extinction coefficient value (k_ℓ) in the Beer-Lambert formula (equation 5.2.1.1) to quantify efficiency of light interception per unit leaf area index, more erect leaf types have a smaller k_ℓ .

To calculate the light extinction coefficient, the amount of photosynthetically active radiation (PAR) intercepted and the mass of aboveground biomass (LAI) is measured several times throughout a plant's growing season using the methodology described in the previous sections. The light extinction coefficient is then calculated using the Beer-Lambert equation:

$$\frac{TPAR}{PAR} = (1 - \exp(-k_\ell \cdot LAI)) \text{ or } k_\ell = -\ln\left(\frac{TPAR}{PAR}\right) \cdot \frac{1}{LAI}$$

where $TPAR$ is the transmitted photosynthetically active radiation, and PAR is the incoming photosynthetically active radiation.

LEAF_TOV_MIN

Perennial leaf turnover rate with minimum stress (months)

LEAF_TOV_MAX

Perennial leaf turnover rate with maximum stress (months)

BM_DIEOFF	Biomass dieoff fraction. This coefficient is the fraction above ground biomass that dies off at dormancy. Default value = 0.10.
RSR1	Initial root to shoot ration at the beginning of the growing season. Default = 0.40.
RSR2	Root to shoot ration at the end of the growing season. Default = 0.20.
POP1	Plant population corresponding to the 1st point on the population lai curve (plants/m^2)
FRLAI1	Frac of max leaf area index corresponding to the 1st point on the leaf area development curve (frac)
POP2	Plant population corresponding to the 2nd point on the population lai curve (plants/m^2)
FRLAI2	Frac of max leaf area index corresponding to the 2nd point on the leaf area development curve (frac)
FRSW_GRO	Frac of field capacity to initiate growth of tropical plants during monsoon season - pcom()%plcur()%iseason (frac)
WIND_STL	Wind erosion factor for standing live biomass
WIND_STD	Wind erosion factor for standing dead residue
WIND_FLAT	Wind erosion factor for flat residue

FERTILIZER.FRT

The fertilizer database summarizes the relative fractions of nitrogen and phosphorus pools in the different fertilizers. Information on levels of bacteria in manure is also stored in this file. Appendix A documents the source of parameter values in the database file provided with the model. Below is a partial listing of the fertilizer.frt file.

fertilizer.frt						
FERTNM	FMINN	FMINP	FORGN	FORGP	FNH3N	Pathogens Description
elem_n	1	0	0	0	0 null	ElementalNitrogen
elem_p	0	1	0	0	0 null	ElementalPhosphorous
anh_nh3	0.82	0	0	0	1 null	AnhydrousAmmonia
urea	0.46	0	0	0	1 null	Urea
46_00_00	0.46	0	0	0	0 null	46_00_00
33_00_00	0.33	0	0	0	0 null	33_00_00
31_13_00	0.31	0.057	0	0	0 null	31_13_00

Variable name	Definition
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank. Optional.
HEADER	Headers for the fertilizer.frt file.
FERTNM	Name of fertilizer/manure (up to 8 characters allowed). Required.
FMINN	Fraction of mineral N (NO_3 and NH_4) in fertilizer (kg min-N/kg fertilizer). Value should be between 0.0 and 1.0. Required.
FMINP	Fraction of mineral P in fertilizer (kg min-P/kg fertilizer). Value should be between 0.0 and 1.0. Required.
FORGN	Fraction of organic N in fertilizer (kg org-N/kg fertilizer). Value should be between 0.0 and 1.0. Required.
FORGP	Fraction of organic P in fertilizer (kg org-P/kg fertilizer). Value should be between 0.0 and 1.0. Required.
FNH3N	Fraction of mineral N in fertilizer applied as ammonia (kg $\text{NH}_3\text{-N}$ /kg min-N). Value should be between 0.0 and 1.0. Required.
PATHOGENS	

TILLAGE.TIL

Tillage operations redistribute nutrients, pesticide and residue in the soil profile. Appendix A documents the source of parameter values in the database file provided with the model. Below is a partial listing of the tillage.til file.

tillage.til:										
TILLNM	EFFMIX	DEPTHL	RANRNS	RIDGE_HT	RIDGE_SP		Description			
fallplow	0.95	150	75	0	0		genericfallplowingoperation			
sprgplow	0.5	125	50	0	0		genericspringplowingoperation			
constill	0.25	100	40	0	0		genericconservationtillage			
zerotill	0.05	25	10	0	0		genericno-tillmixing			
duckftc	0.55	100	15	0	0		duckfootcultivator			
fldcult	0.3	100	20	0	0		fieldcultivator			
furowout	0.75	25	15	0	0		furrow-outcultivator			
marker	0.45	100	15	0	0		marker(cultivator)			
rollcult	0.5	25	15	0	0		rollingcultivator			
rowcult	0.25	25	15	0	0		rowcultivator			
discovat	0.5	25	15	0	0		discovator			
leveler	0.5	25	15	0	0		leveler			

Variable name	Definition
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank. Optional.
HEADER	Headers for the tillage.til.res file.
TILLNM	Name of fertilizer/manure (up to 8 characters allowed). Required.
EFFMIX	Mixing efficiency of tillage operation. The mixing efficiency specifies the fraction of materials (residue, nutrients and pesticides) on the soil surface which are mixed uniformly throughout the soil depth specified by DEPTIL. The remaining fraction of residue and nutrients is left in the original location (soil surface or layer). Required.
DEPTIL	Depth of mixing caused by the tillage operation (mm). Required.
RANRNS	Random roughness (mm) Required.
RIDGE_HT	Ridge height (mm) Required.
RIDGE_SP	Ridge interval (mm) Required.

PESTICIDE.PST

The pesticide database contains parameters that govern pesticide fate and transport in the HRUs. Appendix A documents the source of parameter values in the database file provided with the model. Below is a partial listing of the pesticide.pst file:

pesticide.pst	KOC	WASHOFF	FOLIAR_HI	SOIL_HL	SOLUB	AQ_REAC	AQ_VOLA	AQ_MW	AQ_RESUS	AQ_SETL	BEN_ACT	BEN_BUR	BEN_REAC	Description
245-tp	2600	0.4	5	20	2.5	0.007	0.00001	0.1	0.002	0.5	0.3	0.002	0.05	Silvex_Amine
2plus2	20	0.95	10	21	660000	0.007	0.00001	0.1	0.002	0.5	0.3	0.002	0.05	Mecoprop
aatrex	171	0.45	5	60	33	0.007	0.00001	0.1	0.002	0.5	0.3	0.002	0.05	Atrazine
abate	100000	0.65	5	30	0	0.007	0.00001	0.1	0.002	0.5	0.3	0.002	0.05	Abate
acaraben	2000	0.05	10	20	13	0.007	0.00001	0.1	0.002	0.5	0.3	0.002	0.05	Chlorobenzilate_Salt
accelera	20	0.9	7	7	100000	0.007	0.00001	0.1	0.002	0.5	0.3	0.002	0.05	Endothall
acclaim	9490	0.2	5	9	0.8	0.007	0.00001	0.1	0.002	0.5	0.3	0.002	0.05	Fenoxyprop-Ethyl_Sodium_Salt
alanap	20	0.95	7	14	231000	0.007	0.00001	0.1	0.002	0.5	0.3	0.002	0.05	Naptalam
alar	10	0.95	4	7	100000	0.007	0.00001	0.1	0.002	0.5	0.3	0.002	0.05	Daminozide
aldrin	300	0.05	2	28	0.1	0.007	0.00001	0.1	0.002	0.5	0.3	0.002	0.05	Aldrin
aliette	20	0.95	0.1	0.1	120000	0.007	0.00001	0.1	0.002	0.5	0.3	0.002	0.05	Fosetyl-Aluminum
ally	35	0.8	30	120	9500	0.007	0.00001	0.1	0.002	0.5	0.3	0.002	0.05	Metsulfuron-Methyl_Salts

<u>Variable name</u>	<u>Definition</u>
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank. Optional.
HEADER	Headers for the pesticide.pst file.
PESTNM	Name of pesticide/toxin. (up to 17 characters allowed) Required.
SKOC	Soil adsorption coefficient normalized for soil organic carbon content (mg/kg)/(mg/L). Pesticide in the soil environment can be transported in solution or attached to sediment. The partitioning of a pesticide between the solution and soil phases is defined by the soil adsorption coefficient for the pesticide. The soil adsorption coefficient is the ratio of the pesticide concentration in the soil or solid phase to the pesticide concentration in the solution or liquid phase: $K_p = \frac{C_{solidphase}}{C_{solution}}$ where K_p is the soil adsorption coefficient ((mg/kg)/(mg/L) or m ³ /ton), $C_{solidphase}$ is the concentration of the pesticide sorbed to the solid phase (mg chemical/kg solid material or g/ton), and $C_{solution}$ is the concentration of the pesticide in solution (mg chemical/L solution or g/ton). The definition of the soil adsorption coefficient in this equation assumes that the pesticide sorption process is linear with concentration and instantaneously reversible. Because the partitioning of pesticide is dependent upon the amount of organic material in the soil, the soil adsorption coefficient input to the model is normalized for soil organic carbon content. The relationship between the soil adsorption coefficient and the soil adsorption coefficient normalized for soil organic carbon content is: $K_p = K_{oc} \cdot \frac{orgC}{100}$

Variable name	Definition
SKOC, cont.	<p>where K_p is the soil adsorption coefficient ((mg/kg)/(mg/L)), K_{oc} is the soil adsorption coefficient normalized for soil organic carbon content ((mg/kg)/(mg/L) or m³/ton), and $orgC$ is the percent organic carbon present in the soil.</p>
	Required.
PST_WOF	Wash-off fraction.
	<p>The wash-off fraction quantifies the fraction of pesticide on the plant canopy that may be dislodged. The wash-off fraction is a function of the nature of the leaf surface, plant morphology, pesticide solubility, polarity of the pesticide molecule, formulation of the commercial product and timing and volume of the rainfall event.</p>
	Required.
HLIFE_F	<p>Degradation half-life of the chemical on the foliage (days).</p>
	<p>The half-life for a pesticide defines the number of days required for a given pesticide concentration to be reduced by one-half. The half-life entered for a pesticide is a lumped parameter that includes the net effect of volatilization, photolysis, hydrolysis, biological degradation and chemical reactions.</p>
	<p>For most pesticides, the foliar half-life is much less than the soil half-life due to enhanced volatilization and photodecomposition. If the foliar half-life is available for the pesticide this value should be used. If the foliar half-life is not available, the foliar half-life can be estimated using the following rules:</p>
	<ol style="list-style-type: none"> 1) Foliar half-life is assumed to be less than the soil half-life by a factor of 0.5 to 0.25, depending on vapor pressure and sensitivity to photodegradation. 2) Foliar half-life is adjusted downward for pesticides with vapor pressures less than 10⁻⁵ mm Hg. 3) The maximum foliar half-life assigned is 30 days.
	Required.

Variable name	Definition
HLIFE_S	Degradation half-life of the chemical in the soil (days). The half-life for a pesticide defines the number of days required for a given pesticide concentration to be reduced by one-half. The soil half-life entered for a pesticide is a lumped parameter that includes the net effect of volatilization, photolysis, hydrolysis, biological degradation and chemical reactions. Required.
PST_WSOL	Solubility of the chemical in water (mg/L or ppm) The water solubility value defines the highest concentration of pesticide that can be reached in the runoff and soil pore water. While this is an important characteristic, researchers have found that the soil adsorption coefficient, K_{oc} , tends to limit the amount of pesticide entering solution so that the maximum possible concentration of pesticide in solution is seldom reached. Reported solubility values are determined under laboratory conditions at a constant temperature, typically between 20°C and 30°C. Required.
AQ_REAC	Aquatic pesticide reaction coefficient (1/day)
AQ_VOLAT	Aquatic volatilization coefficient (m/day)
MOL_WT	Molecular weight to calculate mixing velocity
AQ_RESUS	Aquatic resuspension velocity for pesticide sorbed to sediment (m/day)
AQ_SETTLE	Aquatic settling velocity for pesticide sorbed to sediment (m/day)
BEN_ACT_DEP	Depth of active benthic sediment (m)
BEN_BURY	Burial velocity in benthic sediment (m/day)
BEN_REAC	Reaction coefficient in benthic sediment (1/day)

PATHOGENS.PTH

Below is a sample partial PATHOGENS.PTH:

pathogens.pth	BACTNM	DO_SOLN	GR_SOLN	DO_SORB	GR_SORB	KD	T_ADJ	WASHOFF	DO_PLNT	GR_PLNT_MANURE	PERCOT_THRSHD	STREAM1_STREAM	DO_RES	GR_RES	SWFONC_MIN
Example		10	5	12	6	0.05	1.05	0.1	100	1	0.9	10	100	0	0

Variable name	Definition
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank. Optional.
HEADER	Headers for the bacteria.bac file.
BACTNM	Name of bacteria
DO_SOLN	Die-off factor for persistent bacteria in soil solution at 20°C. (1/day) SWAT allows two different bacteria types to be modeled in a given simulation. In the input/output files these two types are referred to as ‘persistent’ and ‘less persistent’. These terms are purely descriptive and are used solely to differentiate between the two types. The bacteria input variables in the .bsn file govern the actual persistence of the two bacteria types. The user may choose to model no, one, or two types of bacteria. Required if bacteria processes are of interest.
GR_SOLN	Growth factor for persistent bacteria in soil solution at 20°C. (1/day) Required if bacteria processes are of interest.
DO_SORB	Die-off factor for persistent bacteria adsorbed to soil particles at 20°C. (1/day) Required if bacteria processes are of interest.
GR_SORB	Growth factor for persistent bacteria adsorbed to soil particles at 20°C. (1/day) Required if bacteria processes are of interest.
KD	Bact part coeff bet sol and sorbed phase in surf runoff
T_ADJ	Temperature adjustment factor for bacteria die-off/growth. If no value for THBACT is entered, the model will set THBACT = 1.07. Required if bacteria processes are of interest.
WASHOFF	Wash-off fraction for persistent bacteria. Fraction of persistent bacteria on foliage that washes off during a rainfall event. Required if bacteria processes are of interest.
DO_PLNT	Die-off factor for persistent bacteria on foliage at 20°C. (1/day) Required if bacteria processes are of interest.
GR_PLNT	Growth factor for persistent bacteria on foliage at 20°C. (1/day) Required if bacteria processes are of interest.

FR_MANURE	Fraction of manure applied to land areas that has active colony forming units. If no value for SWF is specified, the model will set SWF = 0.15. Required if bacteria processes are of interest.
PERCO	Bacteria percolation coefficient ($10 \text{ m}^3/\text{Mg}$). The bacteria percolation coefficient is the ratio of the solution bacteria concentration in the surface 10 mm of soil to the concentration of bacteria in percolate.
	The value of BACTMIX can range from 7.0 to 20.0. If no value for BACTMIX is entered, the model will set BACTMIX = 10.0. Required if bacteria processes are of interest.
DET_THRSHD	Threshold detection level for less persistent bac when bacteria levels drop to this amount the model considers bacteria in the soil to be insignificant and sets the levels to zero
DO_STREAM	Die-off factor for persistent bacteria in streams (moving water) at 20°C. (1/day) Required if bacteria processes are of interest.
GR_STREAM	growth factor for persistent bacteria in streams
DO_RES	Die-off factor for less persistent bacteria in streams (moving water) at 20°C. (1/day) Required if bacteria processes are of interest.
GR_RES	growth factor for less persistent bacteria in reservoirs
SWF	fraction of manure containing active colony forming units
CONC_MIN	

METALS.MTL

SALTS.STL

URBAN.URB

The urban database summarizes parameters used by the model to simulate different types of urban areas. Appendix A documents the source of parameter values in the database file provided with the model. Below is a listing of the urban.urb file:

urban.urb:											
urbnm	fimp	fcimp	curbden	urbcoef	dirtmx	thalf	tnconc	tpconc	tno3conc	urbcn2	Description
residen_high_den	0.6	0.44	0.24	0.18	225	0.75	550	223	7.2	98	Residential Density
residen_med_den	0.38	0.3	0.24	0.18	225	0.75	550	223	7.2	98	Residential Density
residen_ml_den	0.2	0.17	0.24	0.18	225	0.75	460	196	6	98	Residential Density
residen_low_den	0.12	0.1	0.24	0.18	225	0.75	460	196	6	98	Residential Density
commercial	0.67	0.62	0.28	0.18	200	1.6	420	240	5.5	98	Commercial
industrial	0.84	0.79	0.14	0.18	400	2.35	430	104	5.6	98	Industrial
transportation	0.98	0.95	0.12	0.18	340	3.9	480	212	6.3	98	Transportation
institutional	0.51	0.47	0.12	0.18	340	3.9	480	212	6.3	98	Institutional
residential	0.38	0.3	0.24	0.18	225	0.75	550	223	7.2	98	Residential

Variable name **Definition**

TITLE The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.

HEADER Headings for the variables

URBNM 4-character code for urban land type.

The 4-letter codes in the plant growth and urban databases are used by the GIS interfaces to link land use/land cover maps to SWAT plant types. This code is printed to the output files.

When adding a new urban category, the four letter code for the new urban land type must be unique.

Required.

FIMP Fraction total impervious area in urban land type. This includes directly and indirectly connected impervious areas.

Urban areas differ from rural areas in the fraction of total area that is impervious. Construction of buildings, parking lots and paved roads increases the impervious cover in a watershed and reduces infiltration. With development, the spatial flow pattern of water is altered and the hydraulic efficiency of flow is increased through artificial channels, curbing, and storm drainage and collection systems.

Required.

FCIMP Fraction directly connected impervious area in urban land type.

Variable name	Definition
FCIMP, cont.	<p>Impervious areas can be differentiated into two groups—the area that is hydraulically connected to the drainage system and the area that is not directly connected. As an example, assume there is a house surrounded by a yard where runoff from the roof flows into the yard and is able to infiltrate into the soil. The rooftop is impervious but it is not hydraulically connected to the drainage system. In contrast, a parking lot whose runoff enters a storm water drain is hydraulically connected.</p> <p>When modeling urban areas the connectedness of the drainage system must be quantified. The best methods for determining the fraction total and directly connected impervious areas is to conduct a field survey or analyze aerial photographs.</p> <p>Required.</p>
CURBDEN	<p>Curb length density in urban land type (km/ha).</p> <p>Curb length may be measured directly by scaling the total length of streets off of maps and multiplying by two. To calculate the density, the curb length is divided by the area represented by the map.</p> <p>Required.</p>
URBCOEF	<p>Wash-off coefficient for removal of constituents from impervious area (mm^{-1}).</p> <p>Wash off is the process of erosion or solution of constituents from an impervious surface during a runoff event. The original default value for urb_{coef} was calculated as 0.18 mm^{-1} by assuming that 13 mm of total runoff in one hour would wash off 90% of the initial surface load (Huber and Heaney, 1982). Using sediment transport theory, Sonnen (1980) estimated values for the wash-off coefficient ranging from $0.002\text{--}0.26 \text{ mm}^{-1}$. Huber and Dickinson (1988) noted that values between 0.039 and 0.390 mm^{-1} for the wash-off coefficient give sediment concentrations in the range of most observed values. This variable is used to calibrate the model to observed data.</p> <p>Required.</p>
DIRTMX	<p>Maximum amount of solids allowed to build up on impervious areas (kg/curb km).</p> <p>Required.</p>

Variable name	Definition
THALF	Number of days for amount of solids on impervious areas to build up from 0 kg/curb km to half the maximum allowed, i.e. 1/2 DIRTMX (days). Required.
TNCONC	Concentration of total nitrogen in suspended solid load from impervious areas (mg N/kg sed). Required.
TPCONC	Concentration of total phosphorus in suspended solid load from impervious areas (mg P/kg sed). Required.
TNO3CONC	Concentration of nitrate in suspended solid load from impervious areas (mg NO ₃ -N/kg sed). Required.
URBCN2	Curve number for moisture condition II in impervious areas of urban land type. Required.

SEPTIC.SEP

Information of water quality or effluent characteristics required to simulate different types of Onsite Wastewater Systems (OWSs) is stored in the septic water quality database. The database file distributed with SWAT includes water quality data for most of conventional, advanced, and failing septic systems. Information contained in the septic water quality database is septic tank effluent flow rate for per capita and effluent characteristics of various septic systems. The database is developed based on the field data summarized by Siegrist et al. (2005), McCray et al. (2005) and OWTS 201 (2005). Below is a partial listing of the septic.sep file:

septic.sep											
SEPNM	QS	BODCONC	TSSCONCS	NH4CONC	NO3CONC	NO2CONC	ORGNCN	MINPS	ORGPS	FCOLIS	
GCON	0.227	170	75	42.4	0	0	10	6	1	10000000	
GADV	0.227	22	14	18.9	9.6	0	3	5.1	0.9	543	
COND	0.227	170	75	58	0.2	0	14	9	1	10000000	
SAS1	0.227	170	75	60	0	0	10	8.5	1.5	10000000	
SAS2	0.227	170	75	0	0	0	0	9	1	10000000	
SAS3	0.227	170	80	0	20	0	0	8.5	1.5	1000000	
SAS4	0.227	100	65	0	0	0	0	8.5	1.5	10000000	
SAS5	0.227	20	10	2.4	7.1	0	0	0	0	0	
SAS6	0.227	18	17	5.6	4.1	0	1.3	0	0	0	

Variable name	Definition
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank. Optional.
HEADER	Headers for the septic.sep file.

SEPNM	Abridged name of a septic system
sptname	Definition
GCON	Generic type conventional system
GADV	Generic type advanced system
COND	Septic tank with conventional drainfield
SAS1	Septic tank with SAS ^a type 1
SAS2	Septic tank with SAS type 2
SAS3	Septic tank with in-tank N removal and SAS
SAS4	Septic tank with effluent N removal recycle
SAS5	Septic tank with corrugated plastic trickling Filter
SAS6	Septic tank with open-cell form trickling filter
SPF1	Single pass sand filter 1
SPF2	Single pass sand filter 2
SPF3	Single pass sand filter 3
SPF4	Single pass sand filter 4
RCF1	At grade recirculating sand filter
RCF2	Maryland style RSF ^b
RCF3	RSF
CWT1	Septic tank w/ constructed wetland and surface water discharge
CWT2	Municipal wastewater w/ constructed wetland and surface water discharge 1
CWT3	Municipal wastewater w/ constructed wetland and surface water discharge 2
CWT4	Municipal wastewater w/ constructed wetland
CWT5	Municipal wastewater w/ lagoon and constructed wetland
BFL1	Waterloo biofilter (plastic media) 1
BFL2	Waterloo biofilter (plastic media) 2
BFL3	Peat biofilter
TXF1	Recirculating textile filter
TXF2	Foam or textile filter effluent
GFL1	Septic, recirculating gravel filter, UV disinfection
USPT	Untreated Effluent - Texas A&M reference

a: Sand absorption system

b: Recirculating sand filter

Optional.

QS

Septic tank effluent (STE) flow rate ($\text{m}^3/\text{capita/day}$). McCray et al. (2005) proposed $0.227 \text{ m}^3/\text{capita/day}$ as the median value for USA based on the data collected from various sources.




Figure 34.1 Cumulative frequency distribution for residential septic tank effluent flow rate (after McCray et al., 2005)

BODCONCS


7 day Biochemical oxygen demand in STE (mg/L). BOD for a conventional system is typically 170 mg/L. The value varies greatly for different types of septic systems (See Table A-1 of Siegrist et al., 2005).

Required.

TSSCONCS

Total suspended solids in STE (mg/L). TSS for a conventional system is typically 75 mg/L. The value varies greatly for different types of septic systems (See Table A-1 of Siegrist et al., 2005).

Required.

Variable name	Definition
NH4CONCS	Ammonium nitrogen in STE (mg-N/L). NH ₄ for a conventional system is typically 60 mg-N/L (ranging 17~78 mg-N/L). The value varies greatly for different types of septic systems (See Table A-1 of Siegrist et al., 2005).
	 <p>Figure 34.2 Cumulative frequency distribution for ammonium concentration in the septic tank effluent flow rate (after McCray et al., 2005)</p>
	Required.
NO3CONCS	Nitrate nitrogen in STE (mg-N/L). NO ₃ for a conventional system ranges 0~1.94 mg-N/L. The value varies for different types of septic systems (See Table A-1 of Siegrist et al., 2005).
	Required.
NO2CONCS	Nitrite nitrogen in STE (mg-N/L). NO ₂ for a conventional system is typically very low.
	Required.
ORGNCONCS	Organic nitrogen in STE (mg-N/L). ORGN for a conventional system ranges 9.4~15 mg-N/L.
	Required.

Variable name	Definition
MINPS	Concentration of mineral phosphorus in the septic tank effluent (mg/L). Required.
ORGPS	Organic phosphorus in STE (mg-P/L). ORGP for a conventional system is typically 1 mg-p/L. Required.
FCOLIS	Total number of fecal coliform in STE (cfu/100mL). FCOLI for a conventional system is typically 1E7 cfu/100mL. The value varies greatly for different types of septic systems (See Table A-1 of Siegrist et al., 2005). Required.

SNOW.SNO

The SNOW.SNO file contains the input variables for snow. Below is a partial listing of the snow.sno file.

snow.sno								
NAME	FALLTMP	MELTTMP	MELTMX	MELTMN	TIMP	COVMX	COV50	INIT_MM
snow001	1.0	2.0	6.0	3.0	1.0	0.0	0.0	0.0

Variable name	Definition
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank. Optional.
HEADER	Headers for the snow.sno file.
NAME	Name of the snow parameters
FALLTMP	Snowfall temperature (°C). Mean air temperature at which precipitation is equally likely to be rain as snow/freezing rain. The snowfall temperature should be between –5 °C and 5 °C. A default recommended for this variable is SFTMP = 1.0. Required in watersheds where snowfall is significant.
MELTTMP	Snow melt base temperature (°C). The snow pack will not melt until the snow pack temperature exceeds a threshold value, T_{mlt} . The snow melt base temperature should be between –5 °C and 5 °C. A default recommended for this variable is SMTMP = 0.50. Required in watersheds where snowfall is significant.

MELTMX Melt factor for snow on June 21 (mm H₂O/°C-day).

If the watershed is in the Northern Hemisphere, SMFMX will be the maximum melt factor. If the watershed is in the Southern Hemisphere, SMFMX will be the minimum melt factor. SMFMX and SMFMN allow the rate of snow melt to vary through the year. The variables account for the impact of snow pack density on snow melt.

In rural areas, the melt factor will vary from 1.4 to 6.9 mm H₂O/day-°C (Huber and Dickinson, 1988). In urban areas, values will fall in the higher end of the range due to compression of the snow pack by vehicles, pedestrians, etc. Urban snow melt studies in Sweden (Bengston, 1981; Westerstrom, 1981) reported melt factors ranging from 3.0 to 8.0 mm H₂O/day-°C. Studies of snow melt on asphalt (Westerstrom, 1984) gave melt factors of 1.7 to 6.5 mm H₂O/day-°C.

If no value for SMFMX is entered, the model will set SMFMX = 4.5.

Required in watersheds where snowfall is significant.

Variable name	Definition
MELTMN	<p>Melt factor for snow on December 21 (mm H₂O/°C-day).</p> <p>If the watershed is in the Northern Hemisphere, SMFMN will be the minimum melt factor. If the watershed is in the Southern Hemisphere, SMFMN will be the maximum melt factor. SMFMX and SMFMN allow the rate of snow melt to vary through the year. The variables account for the impact of snow pack density on snow melt.</p> <p>In rural areas, the melt factor will vary from 1.4 to 6.9 mm H₂O/day-°C (Huber and Dickinson, 1988). In urban areas, values will fall in the higher end of the range due to compression of the snow pack by vehicles, pedestrians, etc. Urban snow melt studies in Sweden (Bengston, 1981; Westerstrom, 1981) reported melt factors ranging from 3.0 to 8.0 mm H₂O/day-°C. Studies of snow melt on asphalt (Westerstrom, 1984) gave melt factors of 1.7 to 6.5 mm H₂O/day-°C.</p> <p>If no value for SMFMN is entered, the model will set SMFMN = 4.5.</p> <p>Required in watersheds where snowfall is significant.</p>
TIMP	<p>Snow pack temperature lag factor.</p> <p>The influence of the previous day's snow pack temperature on the current day's snow pack temperature is controlled by a lagging factor, ℓ_{sno}. The lagging factor inherently accounts for snow pack density, snow pack depth, exposure and other factors affecting snow pack temperature. TIMP can vary between 0.01 and 1.0. As ℓ_{sno} approaches 1.0, the mean air temperature on the current day exerts an increasingly greater influence on the snow pack temperature and the snow pack temperature from the previous day exerts less and less influence. As TIMP goes to zero, the snow pack's temperature will be less influenced by the current day's air temperature.</p> <p>If no value for TIMP is entered, the model will set TIMP = 1.0.</p> <p>Required in watersheds where snowfall is significant.</p>
COVMX	Minimum snow water content (mm H ₂ O)
COV50	Fraction of COVMX
INIT_MM	Initial snow water content at start of simulation

OPS- The OPS files contain management operations for fertilizer, pesticide, grazing, harvest, irrigation and sweep.

HARV.OPS

The inputs for grazing are found in the HARV.OPS file. This operation harvests the portion of the plant designated as yield and removes the yield from the HRU, but allows the plant to continue growing. This operation is used for hay cuttings. A sample HARV.OPS file is listed below:

NAME	TYP	HI_OVR	EFF	BM_MIN
grain	grain	0	0.95	0
grass_mulch	biomass	0.5	0	2000
grass_bag	biomass	0.5	1	2000
silage	biomass	0.9	0.95	0
forest_cut	tree	0.95	0.99	0
stover_high	residue	0.9	1	1000
stover_med	residue	0.6	1	2000
stover_low	residue	0.3	1	3000
hay_cut_high	biomass	0.8	1	3000
hay_cut_low	biomass	0.8	1	1000
potatoes	tuber	1.1	0.95	0
peanuts	tuber	1.1	0.95	0

<u>Variable name</u>	<u>Definition</u>
TITLE	The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for variables

NAME	Name of harvest operation
TYP	grain;biomass;residue;tree;tuber;
HI_OVR	Harvest index override ((kg/ha)/(kg/ha)) This variable will force the ratio of yield to total aboveground biomass to the specified value. For grain harvest, the harvest index in the plant growth database (plant.dat) is used that assumes that only the seed is being harvested (HI_OVR is not used in grain harvest). If biomass is cut and removed (for example, in hay cuttings), HIOVR must be used to specify the amount of biomass cut. Optional.
EFF	Harvest efficiency. For grain harvest, the harvest efficiency defines the fraction of yield biomass removed by the harvesting equipment, with the remaining yield lost. For biomass harvest, if HARVEFF is close to zero, the cutting or clipping are left on the ground and if HARVEFF is 1.0, all cut biomass (yield) is removed. If the harvest efficiency is not set or 0.00 is entered, the model assumes the user wants to ignore harvest efficiency and sets the fraction to 1.00 so that the entire yield is removed from the HRU. Optional.
BM_MIN	minimum biomass to allow harvest (kg/ha)

GRAZE.OPS

The inputs for grazing are found in the GRAZE.OPS file. This operation removes plant biomass at a specified rate and allows simultaneous application of manure. A sample GRAZE.OPS file is listed below:

graze.ops						
NAME	FERTNM	DAYS	EAT	TRAMP	MANURE	BIO_MIN
fr_gr	dairy_fr	365	10	5	5	500
fr_congr	dairy_fr	365	10	5	5	4000

Variable name	Definition
TITLE	The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for variables

NAME	Name of grazing operation
FERTNM	Name of grazing operation from fertilizer database
EAT	Dry weight of biomass consumed daily ((kg/ha)/day)
TRAMP	Dry weight of biomass trampled daily ((kg/ha)/day)
	Trampling becomes significant as the number of animals grazing per hectare increases. This is a very subjective value which is typically set equal to BIO_EAT, i.e. the animals trample as much as they eat.
MANURE	Dry weight of manure deposited daily ((kg/ha)/day).
BIO_MIN	Minimum plant biomass for grazing (kg/ha)

IRR.OPS

The inputs for irrigation are found in the IRR.OPS file. This operation applies water to the HRU on the specified day. A sample IRR.OPS file is listed below:

irr.ops						
IRR_OP_NAME	IRR_EFF	SURQ_RATIO	DEPTH	IRR_SALT	IRR_NO3	IRR_PO4
surface	0.5	0.4	0	0	0	0
sprinkler	0.7	0.1	0	0	0	0
drip	0.9	0	0	0	0	0
subsurface	1	0	150	0	0	0

Variable name	Definition
TITLE	The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for variables
NAME	Name of irrigation operation
EFF	Irrigation in-field efficiency (0-1).
SURQ	Surface runoff ratio (0-1). (.1 is 10% surface runoff) (fraction)
DEP_MM	Depth of irrigation water applied on HRU (mm). Required.
SALT	Concentration of salt in irrigation (mg/kg). Not currently operational.
NO3	Concentration of nitrate in irrigation (mg/kg)
PO4	Concentration of phosphate in irrigation

CHEM_APP.OPS

The inputs for sweeping operations are found in the CHEM_APP.OPS file. A sample CHEM_APP.OPS file is listed below:

chem_app.ops									
PEST_OP_NAME	FORM	OPERATION	APP_EFF	FOLIAR_EFF	INJECT_DEP	SURF_FRAC	DRIFT_POT	AERIAL_UNIF	
broadcast	solid	spread	0.9	0	0	1	0	1	
band	solid	spread	0.9	0	0	1	0	0.5	
foliar	liquid	spray	0.8	0.7	0	1	0	1	
inject	liquid	inject	0.95	0	150	0.2	0	1	
aerial_liquid	liquid	spray	0.7	0.7	0	1	0.5	1	
aerial_solid	solid	spread	0.9	0	0	1	0.1	1	
drill	solid	inject	0.95	0	50	0.05	0	1	
side_dress	solid	spread	0.9	0	0	1	0	0.5	
fertigate	liquid	spray	0.9	0.5	0	1	0.2	1	
basal	liquid	spread	0.9	0	0	1	0	0.1	
rope_wick	liquid	direct	1	0.95	0	1	0	1	
tree_inject	liquid	inject	0.95	0	300	0	0	0.01	

Variable name	Definition
TITLE	The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for variables
NAME	Name of chemical application operation
FORM	solid; liquid
OP_TYP	operation type-spread; spray; inject; direct
APP_EFF	application efficiency
FOLIAR_EFF	foliar efficiency
INJECT_DEP	injection depth (mm)
SURF_FRAC	surface fraction-amount in upper 10 mm
DRIFT_POT	drift potential
AERIAL_UNIF	aerial uniformity

FIRE.OPS

The inputs for sweeping operations are found in the FIRE.OPS file. A sample FIRE.OPS file is listed below:

fire.ops		
NAME	CN2_UPD	FRAC_BURN
grass	8	1
tree_intense	8	0.9
tree_low	6	0.7

<u>Variable name</u>	<u>Definition</u>
TITLE	The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for variables
NAME	Name of fire operation
CN2_UPD	change in SCS curve number II value
FR_BURN	fraction burned

SWEEEP.OPS

The inputs for sweeping operations are found in the SWEEP.OPS file. A sample SWEEP.OPS file is listed below.

sweep.ops		
SWP_OP_NAME	SWP_EFF	FR_CURB
high_eff	0.8	0.9

<u>Variable name</u>	<u>Definition</u>
TITLE	The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for the variables
NAME	Street sweeping operation name
EFF	<p>Removal efficiency of sweeping operation</p> <p>The removal efficiency of street sweeping is a function of the type of sweeper, whether flushing is a part of the street cleaning process, the quantity of total solids, the frequency of rainfall events and the constituents considered. Removal efficiency can vary depending on the constituent being considered, with efficiencies being greater for particulate constituents. The removal efficiencies for nitrogen and phosphorus are typically less than the solid removal efficiency (Pitt, 1979).</p> <p>Because SWAT assumes a set concentration of nutrient constituents in the solids, the same removal efficiency is in effect used for all constituents. Table 20-7 provides removal efficiencies for various street cleaning programs.</p> <p>SWEPEFF is a fraction that ranges between 0.0 and 1.0. A value of 0.0 indicates that none of the built-up sediments are removed while a value of 1.0 indicates that all of the built-up sediments are removed.</p> <p>Required.</p>
FR_CURB	<p>Fraction of curb length available for sweeping.</p> <p>The availability factor, fr_{av}, is the fraction of the curb length that is sweepable. The entire curb length is often not available for sweeping due to the presence of cars and other obstacles.</p> <p>FR_CURB can range from 0.01 to 1.00. If no value is entered for FR_CURB (FR_CURB left blank or set to 0.0, the model will assume 100% of the curb length is available for sweeping.</p> <p>Required.</p>

LUM – A primary goal of environmental modeling is to assess the impact of human activities on a given system. Central to this assessment is the itemization of the land and water management practices taking place within the system. The primary file used to summarize these practices is the HRU management file (.sch). This file contains input data for planting, harvest, irrigation applications, nutrient applications, pesticide applications, and tillage operations. Information regarding tile drains and urban areas is also stored in this file.

LANDUSE.LUM

Below is a sample LANDUSE.LUM FILE:

Variable name	Definition
TITLE	The first line of the landuse.lum file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for landuse.lum variables
NAME	Name of land use treatments/practice/conditions
CAL_GRP	Calibration group
PLANT_COV	Plant cover (points to plant.ini file)
MGT_OPS	Management operation (points to management.sch file)

CN_LU

(points to ctable.lum file)

Landuse curve number identifier (from table)

Table 19d-1: Runoff Curve Numbers for Cultivated Agricultural Lands

CN_LU	COVER		TREATMENT/PRACTICE
	LANDUSE		
1	Fallow	Bare soil	
2		Crop residue cover*	
3			
4	Row crops Straight row		
5			
6		Straight row w/residue	
7			
8		Contoured	
9			
10		Contoured w/residue	
11			
12		Contoured & Terraced	
13			
14		Contoured & Terraced w/residue	
15			
15	Small grains	Straight Row	
16			
17		Straight Row w/residue	
18			
19		Contoured	
20			
21		Contoured w/residue	
22			
23		Contoured & Terraced	
24			
25		Contoured & Terraced w/residue	
26			

Runoff Curve Numbers for Other Agricultural Lands

CN_LU	COVER	HYDROLOGIC COND	AVERAGE % IMPERVIOUS AREA	Hydrologic Soil Group
	COVER TYPE			

27	Pasture, grassland or range continuous forage for grazing ¹			
28				
29				
30	Meadow—continuous grass, protected from grazing and general mowed for hay			
31	Brush—brush-weed-grass mixture with brush the major element ²			
32				
33				
34	Woods-grass combination (orchard or tree farm)			
35				
36				
37	Woods ³			
38				
39				
40	Farmsteads-building, lanes, driveways and surrounding lots			

* Crop residue cover applies only if residue is on at least 5% of the surface thru
¹ Poor: < 50% ground cover or heavily grazed with no mulch; Fair: 50 to 75%
 ground cover and lightly or only occasionally grazed

¹ Poor: < 50% ground cover; Fair: 50 to 75% ground cover; Good: > 75%

¹ Poor: Forest litter, small trees, and brush are destroyed by heavy grazing or
 burned, and some forest litter covers the soil; Good: Woods are protected fro
 soil.

CONS_PRAC	USLE equation support practice (P) factor (points to cons_practice.lum file)
URB_LU	Urban land use (points to urban.urb file)
URB_RO	usgs_reg buildup_washoff <p>Urban simulation runoff code: USGS_REG - simulate using USGS regression equations Build up/wash off – simulate using build up washoff algorithm</p>
	Most large watersheds and river basins contain areas of urban land use. Estimates of the quantity and quality of runoff in urban areas are required for comprehensive management analysis. SWAT calculates runoff from urban areas with the SCS curve number method or the Green & Ampt equation. Loadings of sediment and nutrients are determined using one of two options. The first is a set of linear regression equations developed by the USGS (Driver and Tasker, 1988) for estimating storm runoff volumes and constituent loads. The other option is to simulate the buildup and washoff mechanisms, similar to SWMM – Storm Water Management Model (Huber and Dickinson, 1988).
OVN	Manning's "n" value for overland flow (points to ovn_table.lum)
TILEDRAIN	Tile drain file name (points to tiledrain.str)
SEPTIC	Septic tank file name (points to septic.str)
FSTRIP	Filter strip file name (points to filterstrip.str)
GRASSWW	Grassed waterways file name (points to
BMPUSER	Best management practices file name

MANAGEMENT.SCH

The inputs management operations are found in the MANAGEMENT.SCH file. A sample MANAGEMENT.SCH file is listed below:

management.sch									
NAME	NUM_OPS	OP	MON	DAY	HUSC	OP_DATA	OP METH	OP_OVER	
csoy_ai_nt	7	1							
autoirr_str.8									
fert			0	0	0.14	anh-nh3	inject	200	FERTILIZER
plnt			0	0	0.15	corn	null	0	PLANT CORN BEGIN
hvkl			10	30	1.2	corn	grain	0	HARVKILL
skip			0	0	0	null	null	0	SKIP_YEAR
plnt			0	0	0.15	soyb	null	0	PLANT SOYBEANS
hvkl			10	30	1.2	soyb	grain	0	HARVKILL
skip			0	0	0	null	null	0	SKIP_YEAR
canary_nomgt			0	0					

SWAT will simulate different types of management operations. The variables for the different operations will be defined in separate sections. The type of operation simulated is identified by the code given for the variable MGT_OP.

The different codes for MGT_OP are:

PCO	plant community: this operation initializes the plant community in the HRU
PLNT	planting/beginning of growing season: this operation initializes the growth of a specific land cover/plant type in the HRU
HARV	harvest only operation: this operation harvests the portion of the plant designated as yield and removes the yield from the HRU, but allows the plant to continue growing. This operation is used for hay cuttings.
HVKL	harvest and kill operation: this operation harvests the portion of the plant designated as yield, removes the yield from the HRU and converts the remaining plant biomass to residue on the soil surface.
TILL	tillage operation: this operation mixes the upper soil layers and redistributes the nutrients/chemicals/etc. within those layers
IRRM	irrigation operation: this operation applies water to the HRU on the specified day. (IRROPS.DAT)
FERT	fertilizer application: this operation adds nutrients to the soil in the HRU on the specified day (FERTOPS.DAT)
PEST	pesticide application: this operation applies a pesticide to the plant and/or soil in the HRU on the specified day
GRAZ	grazing operation: this operation removes plant biomass at a specified rate and allows simultaneous application of manure.
BURN	burn operation: the burn operation records the biomass, residue and phosphorus that is burned.
SWEP	street sweeping operation: this operation removes sediment and nutrient build-up on impervious areas in the HRU. This operation can only be used when the urban build up/wash off routines are activated for the HRU (see IURBAN).
SKIP	skip operation: this operation skips to the end of the year.

For each year of management operations provided, the operations must be listed in chronological order starting in January.


For simulations where a certain amount of crop yield and biomass is required, the user can force the model to meet this amount by setting a harvest index target and a biomass target. These targets are effective only if a harvest and kill operation is used to harvest the crop. Variables are listed below.

Variable name	Definition
TITLE	Title for the management.sch file. Optional (may be blank)
HEADER	Header for the management.sch variables
NAME	Name of the operations
NUM_OPS	Number of operations following
NUM_AUTOS	Number of auto schedule
OP	Management operation name: pcom = plant community plnt = beginning of growing season harv = harvests the portion of the plant designated as yield and removes the yield from the HRU, but allows the plant to continue to grow. hvkl = harvests the portion of the plant designated as yield, removes the yield from the HRU and converts the remaining plant biomass to residue on the soil surface. till = mixed the upper soil layers and redistributes the nutrients/chemicals, etc within thos layers irrm = applies water to the HRU on the specified day fert = adds nutrients to the soil in the specified day pest = applies a pesticide to the plant and/or soil in the HRU on a specified day graz = removes plant biomass at a specified rate and allows simultaneous application of manure burn = burning swep = removes sediment and nutrient build up on impervious areas in the HRU. This operation can only be used when the urban build up/wash off routines are activated for the HRU (see IURBAN) skip
MON	Month operation takes place. Either MONTH/DAY or HUSC is required.
DAY	Day operation takes place. Either MONTH/DAY or HUSC is required.
HUSC	Fraction of total base zero heat units at which operation takes place. Heat unit scheduling is explained in Chapter 5:1 of the Theoretical Documentation. If MONTH and DAY are not provided, HUSC must be set to a value. Either MONTH/DAY or HUSC is required.

OP_DATA	Operation type character
OP_METHOD	Plant name in community
OP_OVER	Harvest index override

Further explanation of management.sch file:

management.sch	OP_DATA from file --->		OP_METHOD from file --->	
OP				
plnt	cots	initial.plt	null	
harv	corn	initial.plt	grain	harv.ops
kill				
hvkl	soyb	initial.plt	grain	harv.ops
till	riprsubs	tillage.til		till.ops
irrm			drip	irr.ops
fert	anh-nh3	fertilizer.frt	broadcast	chem_app.ops
pest	aatrex	pesticide.pst	inject	chem_app.ops
graz				graze.ops
burn				fire.ops
swep				sweep.ops
skip				
mons				
dwm				



OBJECT.CNT FILE

object.cnt: Spatial object counts – (2-stage)

OBJ	HRU	LTE	SUB	MODFL	AQU	CHA	RES	REC	EXCO	DR	CANAL	PUMP	OUT	CHDEG	2DAQU
4	1	0	0	0	0	0	0	0	1	0	0	0	1	1	0

HRU.CON FILE

hru.con (2-stage)

NUMB	NAME	AREA	LAT	LONG	ELEV	HRU	WST	CON_TYP	OVERFLOW	RULESET	OUT_TOT
1	bench	0.480	0.000	0.000	0.000	1	wea1		0	0	0

HRU-DATA.HRU

hru-data.hru: HRU properties – (2-stage)

NUM	NAM	TOPO	HYD	SOIL	LU_MGT	SOLN_INI	SURF_STOR	SNOW	FLD	SCH_UPD
1	hru0010104	hru00101	hru0010104	IN025	agriculture	IN025	null	snow01	null	null

LANDUSE_LUM: General land use properties (2-stage - partial file)

NAME	CAL_GRP	PLNT_COV	MGT_OPS	CN_LU	CONS_PRAC
forestmixed	null	frst_mixed	null	wood_f	up_down_slope
pasture	null	pasture	null	pasth	up_down_slope
agriculture	null	corn_soybean	csoy_ai_nt	rc_strowres_p	up_down_slope
urban	null	urban_residential		urban	up_down_slope
fpbench	null	canary_grass	canary_nomgt	pasth	up_down_slope

MANAGEMENT.SCH: Management schedules – (2-stage)

NAME	NUM_OPS	OP	MON	DAY	HUSC	OP_DATA	OP_METHOD	OP_OVER	
csoy_ai_nt	7	1							
		autoirr_str.8							
		fert	0	0	0.140	anh-nh3	inject	200.	FERTILIZER
		plnt	0	0	0.150	corn	null	0.0	PLNT CORN
		hvkl	10	30	1.200	corn	grain	0.0	HARVKILL
		skip	0	0	0.000	null	null	0.0	SKIP_YEAR
		plnt	0	0	0.150	soyb	null	0.0	PLNT SOYB
		hvkl	10	30	1.200	soyb	grain	0.0	HARVKILL
		skip	0	0	0.000	null	null	0.0	SKIP_YEAR
canary_nomgt	0	0							

CNTABLE.LUM

The SCS curve number is a function of the soil's permeability, land use and antecedent soil water conditions. Typical curve numbers for moisture condition II are listed in the following tables for various land covers and soil types (SCS Engineering Division, 1986). These values are appropriate for a 5% slope.

The curve number may be updated in plant, tillage, and harvest/ kill operations. If CNOP is never defined for these operations, the value set for CN2 will be used throughout the simulation. If CNOP is defined for an operation, the value for CN2 is used until the time of the operation containing the first CNOP value. From that point on, the model only uses operation CNOP values to define the curve number for moisture condition II. Values for CN2 and CNOP should be entered for pervious conditions. In HRUs with urban areas, the model will adjust the curve number to reflect the impact of the impervious areas.

Below is the CNTABLE.LUM FILE:

cntable.lum	CN_A	CN_B	CN_C	CN_D	LANDUSE_DESCRIPTION	TREATMENT	CONDITION
LANDUSE							
fal_bare	77	86	91	94	Fallow	Bare_soil	----
fal_res_p	76	85	90	93	Fallow	Crop_residue_cover	Poor
fal_res_g	74	83	88	90	Fallow	Crop_residue_cover	Good
rc_strow_p	72	81	88	91	Row_crops	Straight_row	Poor
rc_strow_g	67	78	85	89	Row_crops	Straight_row	Good
rc_strowres_p	71	80	87	90	Row_crops	Straight_row_w_residue	Poor
rc_strowres_g	64	75	82	85	Row_crops	Straight_row_w_residue	Good
rc_cont_p	70	79	84	88	Row_crops	Contoured	Poor
rc_cont_g	65	75	82	86	Row_crops	Contoured	Good
rc_contres_p	69	78	83	87	Row_crops	Contoured_w_residue	Poor
rc_contres_g	64	74	81	85	Row_crops	Contoured_w_residue	Good
rc_conter_p	66	74	80	82	Row_crops	Contoured_&_terraced	Poor
rc_conter_g	62	71	78	81	Row_crops	Contoured_&_terraced	Good
rc_conterres_p	65	73	79	81	Row_crops	Contoured_&_terraced_w_residue	Poor
rc_conterres_g	61	70	77	80	Row_crops	Contoured_&_terraced_w_residue	Good
sg_strow_p	65	76	84	88	Small_grains	Straight_row	Poor
sg_strow_g	63	75	83	87	Small_grains	Straight_row	Good
sg_strowres_p	64	75	83	86	Small_grains	Straight_row_w_residue	Poor
sg_strowres_g	60	72	80	84	Small_grains	Straight_row_w_residue	Good
sg_cont_p	63	74	82	85	Small_grains	Contoured	Poor
sg_cont_g	61	73	81	84	Small_grains	Contoured	Good
sg_contres_p	62	73	81	84	Small_grains	Contoured_w_residue	Poor
sg_contres_g	60	72	80	83	Small_grains	Contoured_w_residue	Good
sg_conter_p	61	72	79	82	Small_grains	Contoured_&_terraced	Poor
sg_conter_g	59	70	78	81	Small_grains	Contoured_&_terraced	Good
sg_conterres_p	60	71	78	81	Small_grains	Contoured_&_terraced_w_residue	Poor
sg_conterres_g	58	69	77	80	Small_grains	Contoured_&_terraced_w_residue	Good
legr_strow_p	66	77	85	89	Close-seeded_or_broadcast_legumes_or_rotation	Straight_row	Poor
legr_strow_g	58	72	81	85	Close-seeded_or_broadcast_legumes_or_rotation	Straight_row	Good
legr_cont_p	64	75	83	85	Close-seeded_or_broadcast_legumes_or_rotation	Contoured	Poor
legr_cont_g	55	69	78	83	Close-seeded_or_broadcast_legumes_or_rotation	Contoured	Good
legr_conter_p	63	73	80	83	Close-seeded_or_broadcast_legumes_or_rotation	Contoured_&_terraced	Poor
legr_conter_g	51	67	76	80	Close-seeded_or_broadcast_legumes_or_rotation	Contoured_&_terraced	Good
pastg_p	68	79	86	89	Pasture_grassland_or_range-continuous_forage_for_grazing	----	Poor
pastg_f	49	69	79	84	Pasture_grassland_or_range-continuous_forage_for_grazing	----	Fair
pastg_g	39	61	74	80	Pasture_grassland_or_range-continuous_forage_for_grazing	----	Good
pasth	30	58	71	78	Meadow-continuous_grass_protected_from_grazing_mowed_for_hay	----	----
brush_p	48	67	77	83	Brush-brush-weed-grass_mixture_with_brush_the_major_element	----	Poor
brush_f	35	56	70	77	Brush-brush-weed-grass_mixture_with_brush_the_major_element	----	Fair
brush_g	30	48	65	73	Brush-brush-weed-grass_mixture_with_brush_the_major_element	----	Good
woodgr_p	57	73	82	86	Woods-grass_combination_(orchard_or_tree_farm)	----	Poor
woodgr_f	43	65	76	82	Woods-grass_combination_(orchard_or_tree_farm)	----	Fair
woodgr_g	32	58	72	79	Woods-grass_combination_(orchard_or_tree_farm)	----	Good
wood_p	45	66	77	83	Woods	----	Poor
wood_f	36	60	73	79	Woods	----	Fair
wood_g	30	55	70	77	Woods	----	Good
farm	59	74	82	86	Farmsteads-buildings_lanes_driveways_and_surrounding_lots	----	----
open_p	68	79	86	89	Open_spaces_(lawns_parks_golfcourses_cemeteries_etc.)	----	Poor
urban	98	98	98	98	Paved_parking_lots_roofs_driveways_etc_(excl_right-of-way)	----	----
paveroad	83	89	92	93	Paved_streets_and_roads_(open_ditches_(incl_right-of-way))	----	----
gravroad	76	85	89	91	Gravel_streets_and_roads_(including_right-of-way)	----	----
dirtroad	72	82	87	89	Dirt_streets_and_roads_(including_right-of-way)	----	----

Variable name	Definition
TITLE	The first line of the cntable.lum file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for cntable.lum variables
NAME	Name of land use treatments/practice/conditions
CNA	Land use curve number A
CNB	Land use curve number B
CNC	Land use curve number C
CND	Land use curve number D
	Land use description follows (not read by model)

CONS_PRACTICE.LUM

Below is a sample CONS_PRACTICE.LUM FILE:

cons_practice.lum			
NAME	P_FACTOR	SLOPE_LEN_MAX	DESCRIPTION
up_down_slope	1	121	Up_and_down_slope
cross_slope	0.75	121	Cross_slope_tillage
contour_farming	0.5	121	Contour_tillage
strip_cros_slope	0.37	121	Strip_cropping_cross_slope
strip_contour	0.25	121	Strip_cropping_contour
contour_1-2	0.3	121	Contour_tillage_1-2%_slopes
contour_3-5	0.5	91	Contour_tillage_3-5%_slopes
contour_6-8	0.5	61	Contour_tillage_6-8%_slopes
contour_9-12	0.6	36	Contour_tillage_9-12%_slopes
contour_13-16	0.7	24	Contour_tillage_13-16%_slopes
contour_17-20	0.8	18	Contour_tillage_17-20%_slopes
contour_21-25	0.9	15	Contour_tillage_21-25%_slopes
strip_1-2_past	0.3	244	Strip_cropping_1-2%_slopes_with-pasture
strip_1-2_row	0.6	244	Strip_cropping_1-2%_slopes_with-rowcrops
strip_3-5_past	0.25	183	Strip_cropping_3-5%_slopes_with-pasture
strip_3-5_row	0.5	183	Strip_cropping_3-5%_slopes_with-rowcrops
strip_6-8_past	0.25	122	Strip_cropping_6-8%_slopes_with-pasture
strip_6-8_row	0.5	122	Strip_cropping_6-8%_slopes_with-rowcrops
strip_9-12_past	0.3	73	Strip_cropping_9-12%_slopes_with-pasture
strip_9-12_row	0.6	73	Strip_cropping_9-12%_slopes_with-rowcrops
strip_13-16_past	0.35	49	Strip_cropping_13-16%_slopes_with-pasture
strip_13-16_row	0.7	49	Strip_cropping_13-16%_slopes_with-rowcrops
strip17-20_past	0.4	36	Strip_cropping_17-20%_slopes_with-pasture
strip_17-20_row	0.8	36	Strip_cropping_17-20%_slopes_with-rowcrops
strip_21-25_past	0.45	30	Strip_cropping_21-25%_slopes_with-pasture
strip_21-25_row	0.9	30	Strip_cropping_21-25%_slopes_with-rowcrops
ter_1-2_sodout	0.12	121	terraces_1-2%_slopes_sod-outlet
ter_1-2_undout	0.05	121	terraces_1-2%_slopes_underflow-outlet
ter_3-8_sodout	0.5	76	terraces_3-8%_slopes_sod-outlet
ter_3-8_undout	0.25	76	terraces_3-8%_slopes_underflow--outlet
ter_9-12_sodout	0.6	61	terraces_9-12%_slopes_sod-outlet
ter_9-12_undout	0.3	61	terraces_9-12%_slopes_underflow--outlet
ter_13-16_sodout	0.7	45	terraces_13-16%_slopes_sod-outlet
ter_13-16_undout	0.35	45	terraces_13-16%_slopes_underflow--outlet
ter_17-20_sodout	0.8	45	terraces_17-20%_slopes_sod-outlet
ter_17-20_undout	0.4	45	terraces_17-20%_slopes_underflow--outlet
ter_21-25_sodout	0.9	30	terraces_21-25%_slopes_sod-outlet
ter_21-25_undout	0.45	30	terraces_21-25%_slopes_underflow--outlet

Variable name	Definition
TITLE	The first line of the cons_practice.lum file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for cons_practice.lum variables
NAME	Name of conservation practice
PFAC	Usle P factor
SL_LEN_MX	Maximum slope length (m)

OVN_TABLE.LUM

Below is a sample OVN_TABLE.LUM FILE:

ovn_table.lum:				
OVN_ID	MANN_N	MIN	MAX	DESCRIPTION
fallow_nores	0.01	0.008	0.012	Fallow_no_residue
convtilt_nores	0.09	0.06	0.12	Conventional_tillage_no_residue
convtilt_res	0.19	0.16	0.22	Conventional_tillage_residue
chisplow_nores	0.09	0.06	0.12	Chisel_plow_no_residue
chisplow_res	0.13	0.1	0.16	Chisel_plow_residue
falldisk_res	0.4	0.3	0.5	Fall_disking_residue
notill_nores	0.07	0.04	0.1	No_till_no_residue
notill_0.5-1res	0.12	0.07	0.17	No_till_0.5-1_t/ha_residue
notill_2-9res	0.3	0.17	0.47	No_till_2-9_t/ha_residue
range_sparse	0.13	0.13	0.13	Rangeland_sparse_cover
range_20cover	0.6	0.6	0.6	Rangeland_20%_cover
shortgrass	0.15	0.1	0.2	Short_grass_prairie
densegrass	0.24	0.17	0.3	Dense_grass
bermudagrass	0.41	0.3	0.48	Bermudagrass
forest_light	0.4	0.3	0.5	Forest_light_fair
forest_med	0.6	0.5	0.7	Forest_medium_good
forest_heavy	0.8	0.7	0.9	Forest_heavy
urban_asphalt	0.11	0.11	0.11	Urban_asphalt
urban_concrete	0.012	0.012	0.012	Urban_concrete
urban_rubble	0.024	0.024	0.024	Urban_rubble

Variable name	Definition
TITLE	The first line of the ovn_table.lum file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for ovn_table.lum variables
NAME	Name of conservation practice
OVN	Overland flow manning's n – mean
OVN_MIN	Overland flow manning's n – min
OVN_MAX	Overland flow manning's n - max

CHG – The change section includes the files for calibration simulation runs in SWAT+.

CODES.CAL

The CODES.CAL file contains the input variables for the characteristics of the calibration update properties. Below is a sample CODES.CAL file:

codes.cal								
HYD_HRU	HYD_HRULTE	PLT	SED	NUT	CHSED	CHNUT	RES	
y	n	n	n	n	n	n	n	n

Variable name	Definition
TITLE	The first line of the codes.cal file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for codes.cal variables
HYD_HRU	if y, calibrate hydrologic balance for hru by land use in each region
HYD_HRU1	if y, calibrate hydrologic balance for hru_lte by land use in each region
PLT	if y, calibrate plant growth by land use (by plant) in each region
SED	if y, calibrate sediment yield by land use in each region
NUT	if y, calibrate nutrient balance by land use in each region
CHSED	if y, calibrate channel widening and bank accretion by stream order
CHNUT	if y, calibrate channel nutrient balance by stream order
RES	if y, calibrate reservoir budgets by reservoir

CAL_PARMS.CAL

The CAL_PARMS.CAL file contains the input variables for the characteristics of the calibration update properties. Below is a partial sample CAL_PARMS.CAL file:

cal_parms upd				
187				
NAME	OBJ_TYP	ABSMIN	ABSMAX	UNITS
cn2	hru	25	98	null
usle_p	hru	0	1	null
ovn	hru	0.01	30	null
elev	hru	0	5000	m
slope	hru	0	1	m/m
slope_len	hru	10	150	m
lat_ttime	hru	0	180	days
lat_sed	hru	0	5000	g/L
lat_len	hru	0	150	m
canmx	hru	0	100	mm/H2O
esco	hru	0	1	null
epco	hru	0	1	null
erorgn	hru	0	5	null
erorgp	hru	0	5	null
dis_stream	hru	0	100000	m
biomix	hru	0	1	null

Variable name	Definition
TITLE	The first line of the cal_parms.cal file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
MCHG_PAR	Maximum number of calibration parm changes
HEADER	Headings for cal_parms.cal variables
NAME	cn2, esco, awc, etc.
OB_TYP	object type the parameter is associated with (hru, chan, res, basin, etc)
ABSMIN	minimum range for variable
ABSMAX	maximum change for variable
UNITS	units used for each parameter

CALIBRATION.CAL

The CALIBRATION.CAL file contains the input variables for the characteristics of the calibration update properties. Below is a partial sample CALIBRATION.CAL file:

calibration.cal										
21										
NAME	CHG_TYPE	VAL	COND\$	LYR1	LYR2	YEAR1	YEAR2	DAY1	DAY2	OBJ_TOT
k	pctchg	25	0	1	1	0	0	0	0	0
k	pctchg	20	0	1	2	0	0	0	0	0
k	pctchg	20	0	4	6	0	0	0	0	0
k	pctchg	27	0	0	0	0	0	0	0	0
k	pctchg	25	1	1	2	0	0	0	0	0
hsg	=	0	D							
k	pctchg	25	1	1	1	0	0	0	0	0
texture	=	0	fsl							
k	pctchg	25	2	1	1	0	0	0	0	0
texture	=	0	fsl							
landuse	=	0	past							
k	pctchg	25	2	1	1	0	0	0	6	1
texture	=	0	FSL							
landuse	=	0	past							
k	pctchg	25	1	1	10	0	0	0	0	0
slope	<	10								
t_opt	abschg	12	1	0	0	0	0	0	0	0
plant	=	0	corn							

calibration.cal file continued:

pltnfr1	absval	0.003	1	0	0	0	0	0	0	0				
plant	=	0	grsg											
wsol	pctchg	-50	1	0	0	0	0	0	0	0				
pest	=	0	245-tp											
pcp	pctchg	10	0	0	0	1977	1977	300	300	1	1			
pcp	pctchg	10	0	0	0	1977	1977	300	300	2	1	-3		
pcp	pctchg	10	0	0	0	1977	1977	300	301	0				
pcp	pctchg	10	0	0	0	1977	1977	1	361	0				
pcp	pctchg	10	0	0	0	1978	1978	1	365	0				
pcp	pctchg	10	0	0	0	1979	1979	3	3	0				
tmp	pctchg	5	0	0	0	1977	1977	1	1	1	1			
tmp	pctchg	5	0	0	0	1977	1977	2	7	1	2			
tmp	pctchg	5	1	0	0	1977	1977	2	7	0				

TITLE	The first line of the calibration.cal file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
MCAL	Total number of calibration updates in the file
NAME	Name of SWAT+ variable (NAME column from cal_parms.upd file)
CHG_TYPE	Type of change ('absval', 'abschg', 'pctchg') <ol style="list-style-type: none"> 1. "absval" changes the value of the parameter to the specified value (VAL) 2. "abschg" changes the value of the parameter by abschg. For example, if VAL = -3 under abschg conditions, a condition II curve number of 80 would be changed to 77. 3. "pctchg" changes the parameter by a percentage. For example, if VAL = 5%, a condition II curve number of 80 would be changed to 84.
VAL	Value of change
CONDNS	Calibration parameters can be conditioned on several variables to determine which hru's to apply the changes. Conditions include hydrologic soil group ("hsg"), "texture", "landuse" and "region". Each hru is checked to determine if they match the condition and the change is made to the parameter. Multiple conditions can be applied to each variable.
LYR1	Soil variables can be conditioned by soil layer. For example, if only the first two layers are updated, LYR1=1 and LYR2=2. To make changes applicable to soils with variable number of layers, LYR1=0 assumes layer 1 and LYR2 assumes the last layer.
LYR2	(see definition for LYR1)
YEAR1	These variables are used to update climate data. For example, YEAR1=1977, YEAR2=1978, DAY1=1 and DAY2=365. Precipitation or temperature values will be changed by the specified amount for every day from January 1, 1977 through December 31, 1978.
YEAR2	(see definition for YEAR1)
DAY1	(see definition for YEAR1)
DAY2	(see definition for YEAR1)

OBJ_TOT

The objects to apply the changes can be set using conditions, or they can be specified using OBJ_TOT. the first number in OBJ_TOT is the total number of objects to read. If OBJ_TOT=0, then all objects (ie: hru) are changed. The example shown in the calibration.cal file:

6 1 -3 4 -8 12 -15

would change hru's 1,2,3,4,5,6,7,8,12,13,14 and 15. This allows the changing of specific hru's or easily change all the hru's in a particular subbasin.

ELEM_CNT1

Elements modified

LS_PARMS.CAL

The LS_PARMS.CAL file contains the input variables for the characteristics of the calibration parameter properties. Below is a sample LS_PARMS.CAL file:

ls_parms.cal						
	10					
NAME	CHG_TYP	NEG	POS	LO	UP	
cn2	abschg	-8	8	35	95	
esco	abschg	-1	1	0	1	
lat_len	pctchg	-30	30	5	200	m
k_lo	pctchg	-99	30	0.0001	500	mm/h
slope	pctchg	-25	25	0.0001	0.9	m/m
tconc	pctchg	-30	30	5	960	min
etco	abschg	-0.4	0.4	0.8	1.2	
perco	abschg	-6000	6000	0	6000	
revapc	abschg	-0.4	0.4	0	0.4	
cn3_swf	abschg	-1.2	1.2	-0.2	1	

Variable name	Definition
TITLE	The first line of the ls_parms.cal file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
MLSP	Total number of parameter updates in the file
NAME	Name of SWAT+ variable (NAME column from cal_parms.upd file)
CHG_TYPE	Type of change ('absval', 'abschg', 'pctchg')
NEG	Negative limit of change
POS	Positive limit of change
LO	Lower limit of parameter
UP	Upper limit of parameter

LS_REGIONS.CAL

The LS_REGIONS.CAL file contains the input variables for the characteristics of land use regions parameter properties for HRUs. Below is a sample LS_REGIONS.CAL file:

ls_regions.cal								
	1							
NAME	LUM_NUM	NPSU	ELEM_CNT					
region_1	15	0						
NAME	SRR	ETR	TFR	SED	ORGN	ORGP	NO3	SOLP
landuse001	0.1	0.7	0	3	0	0	0	0
landuse002	0.1	0.7	0	3	0	0	0	0
landuse003	0.1	0.7	0	3	0	0	0	0
landuse004	0.1	0.7	0	3	0	0	0	0
landuse005	0.1	0.7	0	3	0	0	0	0
landuse006	0.1	0.7	0	3	0	0	0	0
corn_noprac	0.15	0.7	0	3	0	0	0	0
corn_conprac	0.15	0.7	0	3	0	0	0	0
oats_noprac	0.15	0.7	0	3	0	0	0	0
oats_conprac	0.1	0.7	0	3	0	0	0	0
past_noprac	0.1	0.7	0	3	0	0	0	0
past_conprac	0.1	0.7	0	3	0	0	0	0
forest_graze	0.1	0.7	0	3	0	0	0	0
forest_congraze	0.1	0.7	0	3	0	0	0	0
farmstead	0.15	0.7	0	3	0	0	0	0

Variable name	Definition
TITLE	The first line of the ls_regions.cal file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
MLSCAL	Total number of regions updates in the file
NAME	Regions calibration name
LUM_NUM	Total number of land use regions in following lines
NUM_REG	The number of elements in following lines
REG	Elements count
NAME2	Name of the land use management regions
SRR	Surface runoff ratio – surface runoff/precip
LFR	Lateral flow ratio – soil lat flow/precip
PCR	Percolation ratio – perc/precip
ETR	ET ratio – ET/precip
TFR	Tile flow ratio – tile flow/total runoff
SED	Sediment yield (t/ha or t)
ORGN	Organic N yield (kg/ha or kg)
ORGP	Organic P yield (kg/ha or kg)
NO3	Nitrate yield (kg/ha or kg)
SOLP	Soluble P yield (kg/ha or kg)

CH_ORDERS.CAL

The CH_ORDERS.CAL file contains the input variables for the characteristics of channel orders parameter properties for SWAT HRUs. Below is a sample CH_ORDERS.CAL file:

chan_orders.cal			
	1		
NAME	ORD_NUM	NPSU	ELEM_CNT
region_1	8	0	
	ORDER	CHW	CHD
gully		100	100
tributary		25	10
main_upper_c		10	10
main_lower_c		5	5
gully_c		0	0
tributary_c		1	1
main_upper_c		1	1
main_lower_c		0.58	0
			0.0

Variable name	Definition
TITLE	The first line of the chn_orders.cal file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
MREG	Total number of stream order updates in the file
NAME	Regions calibration name
ORD_NUM	Total number of stream orders in following lines
NSPU	The number of elements in following lines
ELEM_CNT	
NAME2	Order name
CHW	Channel widening (mm/yr)
CHD	Channel down cutting or accretion (mm/yr)
HC	Head Cut advance (m/yr)
FPD	Flood plain accretion (mm/yr)

CH_PARMS.CAL

The CH_PARMS.CAL file contains the input variables for the characteristics of land use parameter properties for SWAT HRUs. Below is a sample CH_PARMS.CAL file:

Variable name	Definition
TITLE	The first line of the chan_parms.cal file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
MCHP	Total number of stream order updates in the file
HEADER	Heading
NAME	Regions calibration name
CH_TYP	Type of change ('absval', 'abschg', 'pctchg')
NEG	Negative limit of change
POS	Positive limit of change
LO	Lower limit of parameter
UP	Upper limit of parameter

PL_PARMS.CAL

The PL_PARMS.CAL file contains the input variables for the characteristics of land use parameter properties for SWAT HRUs. Below is a sample PL_PARMS.CAL file:

PL_REGIONS.CAL

The PL_REGIONS.CAL file contains the input variables for the characteristics of land use parameter properties for SWAT HRUs. Below is a sample PL_REGIONS.CAL file:

INIT – The initial files includes initialization data for organic matter, pesticide, pathogens, heavy metals and salts.

PLANT.INI

The PLANT.INI file contains the input variables for the characteristics of the plant community properties. The PLANT_COV input in the landuse.lum file points to the name in the plant.ini file. Plant initialization files can be constructed to allow decision tables for planting and harvesting to be used in both northern and southern hemispheres. Below is a sample PLANT.INI file:

plant.ini:										
NAME	PL_COM	ROTYR	CPNM	IGRO	LAI	BIOMS	PHUACC	POP	YRMAT	RSDIN
corn_sb_1	2	1								
			corn	n	0	0	0	0	0	2000
			soyb	n	0	0	0	0	0	2000
corn_sb_2	2	2								
			corn	n	0	0	0	0	0	2000
			soyb	n	0	0	0	0	0	2000
corn_sb_shemi1	2	1								
			corn	y	2	8000	0.3	0	0	2000
			soyb	n	0	0	0	0	0	2000
corn_sb_shemi2	2	2								
			corn	n	0	0	0	0	0	2000
			soyb	y	2	4000	0.3	0	0	2000
corn_con	1	1								
			corn	n	0	0	0	0	0	2000
soyb_con	1	1								
			soyb	n	0	0	0	0	0	2000
corn_con_shemi	1	1								
			corn	y	2	8000	0.3	0	0	2000
soyb_con_shemi	1	1								
			soyb	y	2	4000	0.3	0	0	2000
canary_grass	1	1	cang	y	1	1000	0	0	0	2000

In the example above, corn_sb_1 initializes a corn-soybean rotation with corn growing the first year. This can be used in the northern hemisphere when starting the simulation on January 1 or in the southern hemisphere starting the simulation on July 1. The corn_sb_2 example initializes a corn-soybean rotation with soybeans growing the first year (ROT_YR=2). The corn_sb_shemi1 and corn_sb_shemi2 examples can be used in the southern hemisphere when starting the simulation on January 1 with summer crops growing.

The corn_con and soyb_con examples are for continuous corn and soybeans starting in the cold season (January 1 in northern hemispheres and July 1 in southern hemispheres) and corn_con_shemi1 and soyb_con_shemi are for continuous corn and soybeans in the southern hemisphere starting on January 1.

The canary_grass example is typical of any native perennial plant.

Variable name	Definition
TITLE	The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headers for the variables
NAME	Name of plant community (from PLANT_COV column in the landuse.lum file)
PLANTS_COM	Number of plants in the community
ROTYR	Beginning year of rotation. For example, in a corn-soybean rotation, setting ROTYR=1 will start operations in the second or soybean year of rotation.
CPNM	<p>Plant name (from plants.plt file)</p> <p>A four character code to represent the land cover/plant name.</p> <p>The 4-letter codes in the plant growth and urban databases are used by the GIS interfaces to link land use/land cover maps to SWAT plant types. This code is printed to the output files.</p> <p>When adding a new plant species or land cover category, the four letter code for the new plant must be unique.</p> <p>Required.</p>
IGRO	<p>Land cover status code (character)</p> <p>This code informs the model whether or not a land cover is growing at the beginning of the simulation.</p> <p>‘n’ = no land cover growing ‘y’ = land cover growing</p> <p>Required.</p>

LAI	Initial leaf area index. If a land cover is growing at the beginning of the simulation (IGRO = 1), the leaf area index of the land cover must be defined. Required if IGRO = 1.
BIOMS	Initial dry weight biomass (kg/ha). If a land cover is growing at the beginning of the simulation (IGRO = 1), the initial biomass must be defined. Required if IGRO = 1.
PHUACC	Total number of heat units or growing degree days needed to bring plant to maturity. This value is needed only if a land cover is growing at the beginning of the simulation (IGRO = 1). Calculation of PHU_PLT is reviewed in Chapter 5:1 of the Theoretical Documentation. Required if IGRO = 1.
POP	Plant population
YRMAT	Years to maturity
RSDIN	Initial residue cover (kg/ha)

SOIL_PLANT.INI

soil_plant.ini	SW_FRAC	NUTRIENT	PESTICIDES	PATHOGENS	HEAVY_METALS	SALTS
NAME	0.2	in25	no_ini_pst	no_ini_path	null	null
no_init						
low_init	0.7	in25	low_ini_pst	low_ini_path	null	null

OM_WATER.INI

om_water.ini	flo	sed	orgn	sedp	no3	solp	chia	nh3	no2	cbod	dox	san	sil	cla	sag	lag	grv	temp
om_low_init	0.8	1000	90	80	70	60	30	20	10	9	8	2	1	1000	90	80	70	60
om_high_init	0.9	1100	99	88	77	66	33	22	11	19	28	82	91	1900	98	87	76	65

PEST_HRU.INI**TITLE**

The first line of the initial.pst file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.

HEADER

Heading of file

NAME

Name of pesticide in community

NUM

Number of pesticides in community

EXCO_DF

Name of export coefficient file for pesticide community

DR_DF

Name of delivery ratio file for pesticide community

NAME2

Name in pesticide community

PLT

Amount of pesticide on plant at start of simulation (kg/ha)

SOIL

Amount of pesticide in soil at start of simulation (kg/ha)

ENR

Pesticide enrichment ratio

PEST_WATER.INI (ENTIRE FILE NEEDS ATTENTION)**Variable name** **Definition****TITLE**

The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.

HEADER

Headings for the variables

PATH_HRU.INI (ENTIRE FILE NEEDS ATTENTION)

Variable name	Definition
TITLE	The first line is reserved for user comments. This line is not processed by the model and may be left blank. Optional.
MBAC_DB	
HEADER	Headings for the initial.bac file
NUM	Total number of initial bacteria in file
NUM_DB	Number of bacteria to follow
PLT	Bacteria on plants at beginning of simulation (#cfu/m^2)
SOL	Soluble bacteria in soil at beginning of simulation (#cfu/m^2)
SOR	Sorbed bacteria in soil at beginning of simulation (#cfu/m^2)

PATH_WATER.INI (ENTIRE FILE NEEDS ATTENTION)

Variable name	Definition
TITLE	The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for the variables

HMET_HRU.INI (ENTIRE FILE NEEDS ATTENTION)

Variable name	Definition
TITLE	The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for the variables

HMET_WATER.INI**SALT_HRU.INI (ENTIRE FILE NEEDS ATTENTION)**

Variable name	Definition
TITLE	The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for the variables

SALT_WATER.INI (ENTIRE FILE NEEDS ATTENTION)

Variable name	Definition
TITLE	The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for the variables

SOILS – The soils data used by SWAT+ can be divided into two groups, physical characteristics and chemical characteristics. The physical properties of the soil govern the movement of water and air through the profile and have a major impact on the cycling of water within the HRU. Inputs for chemical characteristics are used to set initial levels of the different chemicals in the soil. While the physical properties are required, information on chemical properties is optional. The soil input (.sol) file defines the physical properties for all layers in the soil.

SOILS.SOL

The SOILS.SOL file contains the input variables for the characteristics of the soil properties. Below is a partial sample SOILS.SOL file (four layer soil):

soils.sol																				
SNAM	NLY	HYD_GRP	ZMX	ANION_EX	CRK	TEXTURE	DEPTH	BD	AWC	K	CBN	CLAY	SILT	SAND	ROCK	ALB	USLE_K	EC	CAL	PH
IN025		4 B		1524	0.5	0.5 sandy-loam		355.6	1.6	0.13	83	1.74	15	19.09	65.91	1.52	0.01	0.2	0	0
								812.8	1.7	0.1	65	0.35	12.5	19.65	67.85	1.62	0.12	0.2	0	0
								1219.2	1.8	0.07	180	0.15	7.5	9.02	83.48	1.71	0.17	0.15	0	0
								1524	1.8	0.04	300	0.05	6	1.88	92.11	1.71	0.21	0.15	0	0

TITLE The first line of the .sol file is reserved for user comments.
The comments may take up to 80 spaces. The title line is
not processed by the model and may be left blank.

HEADER

SNAM Soil name

NLY Number of layers in the soil

HYDGRP Soil hydrologic group (A, B, C, or D).

Required only for the SWAT ArcView interface.

The U.S. Natural Resource Conservation Service (NRCS) classifies soils into four hydrologic groups based on infiltration characteristics of the soils. NRCS Soil Survey Staff (1996) defines a hydrologic group as a group of soils having similar runoff potential under similar storm and cover conditions. Soil properties that influence runoff potential are those that impact the minimum rate of infiltration for a bare soil after prolonged wetting and when not frozen. These properties are depth to seasonally high water table, saturated hydraulic conductivity, and depth to a very slowly permeable layer. The definitions for the different classes are:

- A Soils having high infiltration rates even when thoroughly wetted, consisting chiefly of sands or gravel that are deep and well to excessively drained. These soils have a high rate of water transmission (low runoff potential).
 - B Soils having moderate infiltration rates when thoroughly wetted, chiefly moderately deep to deep, moderately well to well drained, with moderately fine to moderately coarse textures. These soils have a moderate rate of water transmission.
-

Variable name	Definition
HYDGRP, cont.	<p>C Soils having slow infiltration rates when thoroughly wetted, chiefly with a layer that impedes the downward movement of water or of moderately fine to fine texture and a slow infiltration rate. These soils have a slow rate of water transmission (high runoff potential).</p> <p>D Soils having very slow infiltration rates when thoroughly wetted, chiefly clay soils with a high swelling potential; soils with a high permanent water table; soils with a clay pan or clay layer at or near the surface; and shallow soils over nearly impervious materials. These soils have a very slow rate of water transmission.</p>

Guidelines used by USDA Soil Survey to categorize soils into Hydrologic Groups are summarized in Table 22-1.

Table 22-1: Hydrologic Group Rating Criteria

Criteria*	Hydrologic Soil Groups			
	A	B	C	D
Final constant infiltration rate (mm/hr)	7.6-11.4	3.8-7.6	1.3-3.8	0-1.3
Mean permeability: surface layer (mm/hr)	> 254.0	84.0-254.0	8.4-84.0	< 8.4
Mean permeability: most restrictive layer below the surface layer to a depth of 1.0 m (mm/hr)	> 254.0	84.0-254.0	8.4-84.0	< 8.4
Shrink-swell potential: most restrictive layer**	Low	Low	Moderate	High, Very High
Depth to bedrock or cemented pan (mm)	> 1016	> 508	> 508	< 508
DUAL HYDROLOGIC GROUPS				
	A/D	B/D	C/D	
Mean depth to water table (m)	< 0.61	< 0.61	< 0.61	

* These criteria are guidelines only. They are based on the theory that the minimum permeability occurs within the uppermost 50 cm. If the minimum permeability occurs between a depth of 50 to 100 cm, then the Hydrologic Soil Group is increased one group. For example, C to B. If the minimum permeability occurs below a depth of 100 cm, the Hydrologic Soil Group is based on the permeability above 100 cm, using the rules previously given.

** Shrink-swell potential is assigned to a profile using the following guidelines:

Low: All soils with sand, loamy sand, sandy loam, loam or silt loam horizons that are at least 50 cm thick from the surface without a clay horizon within 100 cm of the surface.

Medium: All soils with clay loam horizons within 50 cm of the surface or soils with clay horizons from 50 to 100 cm beneath the surface.

High: All soils with clay horizons within 50 cm of the surface. Lower the shrink-swell potential one class when kaolinite clay is dominant.

Variable name	Definition
ZMX	<p>Maximum rooting depth of soil profile (mm).</p> <p>If no depth is specified, the model assumes the roots can develop throughout the entire depth of the soil profile.</p>
ANION_EXCL	<p>Fraction of porosity (void space) from which anions are excluded.</p> <p>Most soil minerals are negatively charged at normal pH and the net interaction with anions such as nitrate is a repulsion from particle surfaces. This repulsion is termed negative adsorption or anion exclusion.</p> <p>Anions are excluded from the area immediately adjacent to mineral surfaces due to preferential attraction of cations to these sites. This process has a direct impact on the transport of anions through the soil for it effectively excludes anions from the slowest moving portion of the soil water volume found closest to the charged particle surfaces (Jury et al, 1991). In effect, the net pathway of the anion through the soil is shorter than it would be if all the soil water had to be used (Thomas and McMahon, 1972).</p> <p>If no value for ANION_EXCL is entered, the model will set ANION_EXCL = 0.50.</p>
CRK	<p>Potential or maximum crack volume of the soil profile expressed as a fraction of the total soil volume.</p> <p>To accurately predict surface runoff and infiltration in areas dominated by Vertisols, the temporal change in soil volume must be quantified. Bronswijk (1989, 1990) outlines methods used to determine the maximum crack volume.</p>
TEXTURE	<p>Texture of soil layer.</p> <p>This data is not processed by the model and the line may be left blank.</p>

Variable name	Definition
Z(layer #)	Depth from soil surface to bottom of layer (mm).
BD(layer #)	Moist bulk density (Mg/m^3 or g/cm^3). The soil bulk density expresses the ratio of the mass of solid particles to the total volume of the soil, $\rho_b = M_S/V_T$. In moist bulk density determinations, the mass of the soil is the oven dry weight and the total volume of the soil is determined when the soil is at or near field capacity. Bulk density values should fall between 1.1 and 1.9 Mg/m^3 .
AWC(layer #)	Available water capacity of the soil layer (mm $\text{H}_2\text{O}/\text{mm soil}$). The plant available water, also referred to as the available water capacity, is calculated by subtracting the fraction of water present at permanent wilting point from that present at field capacity, $AWC = FC - WP$ where AWC is the plant available water content, FC is the water content at field capacity, and WP is the water content at permanent wilting point. Available water capacity is estimated by determining the amount of water released between in situ field capacity (the soil water content at soil matric potential of -0.033 MPa) and the permanent wilting point (the soil water content at soil matric potential of -1.5 MPa).
K(layer #)	Saturated hydraulic conductivity (mm/hr). The saturated hydraulic conductivity, K_{sat} , relates soil water flow rate (flux density) to the hydraulic gradient and is a measure of the ease of water movement through the soil. K_{sat} is the reciprocal of the resistance of the soil matrix to water flow.
CBN(layer #)	Organic carbon content (% soil weight). When defining by soil weight, the soil is the portion of the sample that passes through a 2 mm sieve.

Variable name	Definition
CLAY(layer #)	Clay content (% soil weight). The percent of soil particles which are < 0.002 mm in equivalent diameter.
SILT(layer #)	Silt content (% soil weight). The percentage of soil particles which have an equivalent diameter between 0.05 and 0.002 mm.
SAND(layer #)	Sand content (% soil weight). The percentage of soil particles which have a diameter between 2.0 and 0.05 mm.
ROCK(layer #)	Rock fragment content (% total weight). The percent of the sample which has a particle diameter > 2 mm, i.e. the percent of the sample which does not pass through a 2 mm sieve.
ALB(top layer)	Moist soil albedo. The ratio of the amount of solar radiation reflected by a body to the amount incident upon it, expressed as a fraction. The value for albedo should be reported when the soil is at or near field capacity.
USLE_K(top layer)	USLE equation soil erodibility (K) factor (units: 0.013 (metric ton m ² hr)/(m ³ -metric ton cm)). Some soils erode more easily than others even when all other factors are the same. This difference is termed soil erodibility and is caused by the properties of the soil itself. Wischmeier and Smith (1978) define the soil erodibility factor as the soil loss rate per erosion index unit for a specified soil as measured on a unit plot. A unit plot is 22.1-m (72.6-ft) long, with a uniform length-wise slope of

Variable name	Definition
USLE_K, cont.	<p>9-percent, in continuous fallow, tilled up and down the slope. Continuous fallow is defined as land that has been tilled and kept free of vegetation for more than 2 years. The units for the USLE soil erodibility factor in MUSLE are numerically equivalent to the traditional English units of 0.01 (ton acre hr)/(acre ft-ton inch).</p> <p>Wischmeier and Smith (1978) noted that a soil type usually becomes less erodible with decrease in silt fraction, regardless of whether the corresponding increase is in the sand fraction or clay fraction.</p> <p>Direct measurement of the erodibility factor is time consuming and costly. Wischmeier et al. (1971) developed a general equation to calculate the soil erodibility factor when the silt and very fine sand content makes up less than 70% of the soil particle size distribution.</p>

$$K_{USLE} = \frac{0.00021 \cdot M^{1.14} \cdot (12 - OM) + 3.25 \cdot (c_{soilstr} - 2) + 2.5 \cdot (c_{perm} - 3)}{100}$$

where KUSLE is the soil erodibility factor, M is the particle-size parameter, OM is the percent organic matter (%), csoilstr is the soil structure code used in soil classification, and cperm is the profile permeability class.

The particle-size parameter, M, is calculated

$$M = (m_{silt} + m_{vfs}) \cdot (100 - m_c)$$

where msilt is the percent silt content (0.002-0.05 mm diameter particles), mvfs is the percent very fine sand content (0.05-0.10 mm diameter particles), and mc is the percent clay content (< 0.002 mm diameter particles).

The percent organic matter content, OM, of a layer can be calculated:

$$OM = 1.72 \cdot orgC$$

where orgC is the percent organic carbon content of the layer (%).

Variable name	Definition
USLE_K, cont.	<p>Soil structure refers to the aggregation of primary soil particles into compound particles which are separated from adjoining aggregates by surfaces of weakness. An individual natural soil aggregate is called a ped. Field description of soil structure notes the shape and arrangement of peds, the size of peds, and the distinctness and durability of visible peds. USDA Soil Survey terminology for structure consists of separate sets of terms defining each of these three qualities. Shape and arrangement of peds are designated as type of soil structure; size of peds as class; and degree of distinctness as grade.</p> <p>Angular Blocky: bounded by planes intersecting at relatively sharp angles</p> <p>Subangular Blocky: having mixed rounded and plane faces with vertices mostly rounded</p> <p>The soil-structure codes for the equation are defined by the type and class of soil structure present in the layer. There are four primary types of structure, several of which are further broken down into subtypes:</p> <ul style="list-style-type: none"> -Platy, with particles arranged around a plane, generally horizontal -Prismlike, with particles arranged around a verticle line and bounded by relatively flat vertical surfaces <ul style="list-style-type: none"> Prismatic: without rounded upper ends Columnar: with rounded caps -Blocklike or polyhedral, with particles arranged around a point and bounded by flat or rounded surfaces which are casts of the molds formed by the faces of surrounding peds -Spheroidal or polyhedral, with particles arranged around a point and bounded by curved or very irregular surfaces that are not accomodated to the adjoining aggregates <ul style="list-style-type: none"> Granular: relatively non-porous Crumb: very porous <p>The size criteria for the class will vary by type of structure and are summarized in Table 22-2.</p>

Variable name	Definition
USLE_K, cont.	Table 22-2: Size classes of soil structure
	Shape of structure Prismatic and
Size Classes	Platy Columnar Blocky Granular
Very fine	< 1 mm < 10 mm < 5 mm < 1 mm
Fine	1-2 mm 10-20 mm 5-10 mm 1-2 mm
Medium	2-5 mm 20-50 mm 10-20 mm 2-5 mm
Coarse	5-10 mm 50-100 mm 20-50 mm 5-10 mm
Very coarse	> 10 mm > 100 mm > 50 mm > 10 mm

The codes assigned to $c_{soilstr}$ are:

- 5 very fine granular
- 6 fine granular
- 7 medium or coarse granular
- 8 blocky, platy, prismlike or massive

Permeability is defined as the capacity of the soil to transmit water and air through the most restricted horizon (layer) when moist. The profile permeability classes are based on the lowest saturated hydraulic conductivity in the profile.

The codes assigned to c_{perm} are:

- 7 rapid (> 150 mm/hr)
- 8 moderate to rapid (50-150 mm/hr)
- 9 moderate (15-50 mm/hr)
- 10 slow to moderate (5-15 mm/hr)
- 11 slow (1-5 mm/hr)
- 12 very slow (< 1 mm/hr)

Williams (1995) proposed an alternative equation:

$$K_{USLE} = f_{csand} \cdot f_{cl-si} \cdot f_{orgc} \cdot f_{hisand}$$

where f_{csand} is a factor that gives low soil erodibility factors for soils with high coarse-sand contents and high values for soils with little sand, f_{cl-si} is a factor that gives low soil erodibility factors for soils with high clay to silt ratios, f_{orgc} is a factor that reduces soil erodibility for soils with high organic carbon content, and f_{hisand} is a factor that reduces soil erodibility for soils with extremely high sand contents. The factors are calculated:

$$f_{csand} = \left(0.2 + 0.3 \cdot \exp \left[-0.256 \cdot m_s \cdot \left(1 - \frac{m_{silt}}{100} \right) \right] \right)$$

Variable name	Definition
USLE_K, cont.	$f_{cl-si} = \left(\frac{m_{silt}}{m_c + m_{silt}} \right)^{0.3}$ $f_{orgc} = \left(1 - \frac{0.0256 \cdot orgC}{orgC + \exp[3.72 - 2.95 \cdot orgC]} \right)$ $f_{hisand} = \left(1 - \frac{0.7 \cdot \left(1 - \frac{m_s}{100} \right)}{\left(1 - \frac{m_s}{100} \right) + \exp[-5.51 + 22.9 \cdot \left(1 - \frac{m_s}{100} \right)]} \right)$
	where m_s is the percent sand content (0.05-2.00 mm diameter particles), m_{silt} is the percent silt content (0.002-0.05 mm diameter particles), m_c is the percent clay content (< 0.002 mm diameter particles), and $orgC$ is the percent organic carbon content of the layer (%).
EC(layer #)	Electrical conductivity (dS/m).
CAL(layer #)	Soil CaCo3 (%). (0 – 50%)
PH(layer #)	Soil Ph (3-10)

NUTRIENTS.SOL

The NUTRIENTS.SOL file Soil nutrient parameters.

Below is a sample NUTRIENTS.SOL file (one layer soil):

nutrients.sol:											
NAME	EXP_CO	TOTALN	INORGN	ORGN	TOTALP	INORGP	ORGP	WATERSOL_P	H3A_P	MEHLICH_P	BRAY_STRONG_P
in25	0.001	13	6.85	3.34	3.22	3.66	0.39	0.16	0.26	1.22	0.85
Irew02	0.001	13	6.85	3.34	3.22	3.66	0.39	0.16	0.26	1.22	0.85
Irew03	0.001	13	6.85	3.34	3.22	3.66	0.39	0.16	0.26	1.22	0.85
Irew04	0.001	13	6.85	3.34	3.22	3.66	0.39	0.16	0.26	1.22	0.85
Irew05	0.001	13	6.85	3.34	3.22	3.66	0.39	0.16	0.26	1.22	0.85
Irew06	0.001	13	6.85	3.34	3.22	3.66	0.39	0.16	0.26	1.22	0.85
Irew07	0.001	13	6.85	3.34	3.22	3.66	0.39	0.16	0.26	1.22	0.85
Irew08	0.001	13	6.85	3.34	3.22	3.66	0.39	0.16	0.26	1.22	0.85
Irew09	0.001	13	6.85	3.34	3.22	3.66	0.39	0.16	0.26	1.22	0.85
Irew10	0.001	13	6.85	3.34	3.22	3.66	0.39	0.16	0.26	1.22	0.85
Irew11	0.001	13	6.85	3.34	3.22	3.66	0.39	0.16	0.26	1.22	0.85
Irew12	0.001	13	6.85	3.34	3.22	3.66	0.39	0.16	0.26	1.22	0.85

TITLE	The first line of the nutrients.sol file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	
NAME	Nutrient name
EXP_CO	Depth coefficient to adjust concentrations for depth
TOTALN	Total N in soil (ppm)
INORGN	Inorganic N in soil surface (ppm)
ORGN	Organic N in soil surface (ppm)
TOTALP	Total P in soil surface (ppm)
INORGP	Inorganic P in soil surface (ppm)
ORGP	Organic P in soil surface (ppm)
WATERSOL_P	Water soluble P in soil surface (ppm)
H3A_P	H3a P in soil surface (ppm)
MEHLICH_P	Mehlich P in soil surface (ppm)
	Bray P in soil surface (ppm)

SOILS_LTE.SOL - The SOILS_LTE.SOL file parameters for LTE watershed . Below is a sample SOILS_LTE.SOL file.

soils_lte.sol			
NAME	AWC	POR	SCON
sand	0.56	0.4	105
loamy_sand	0.116	0.4	60
sandy_loam	0.115	0.4	0.26
loam	0.114	0.4	13.2
silt_loam	0.186	0.43	6.8
silt	0.254	0.47	5.6
silty_clay	0.141	0.43	4.3
clay_loam	0.138	0.4	2.3
sandy_clay_loam	0.113	0.4	1.5
sandy_clay	0.13	0.4	1.2
silty_clay	0.132	0.48	0.9
clay	0.113	0.47	1.5

TITLE	The first line of the soils_lte.sol file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
HEADER	Headings for variables
NAME/TEXTURE	Texture description (cross walked from TEXTURE column in HRU-LTE.HRU file)
AWC	Available water capacity for LTE soil (mm/mm)
POR	Porosity for LTE soil (mm/mm)
SCON	Saturated conductivity for LTE soil (mm/hr)

D TABLE – Decision tables are a precise yet compact way to model complex rule sets and their corresponding actions.

Decision tables, like flowcharts and if-then-else and switch-case statements, associate conditions with actions to perform, but in many cases do so in a more elegant way (see Wikipedia – ‘Decision table’)

STRUCTURE OF DECISION TABLES

- I. Conditions
- II. Condition alternatives
- III. Actions
- IV. Action entries

Each decision corresponds to a variable, relation or predicate whose possible values are listed among the condition alternatives. Each action is a procedure or operation to perform, and the entries specify whether (or in what order) the action is to be performed for the set of condition alternatives the entry corresponds to. Many decision tables include in their condition alternatives the ‘don’t care’ symbol, a hyphen. Using ‘don’t cares’ can simplify decision tables, especially when a given condition has little influence on the actions to be performed. In some cases, entire conditions thought to be important initially are found to be irrelevant when none of the conditions influence which actions are performed.

Decision tables, especially when coupled with the use of a domain-specific language, allow developers and policy experts to work from the same information, the decision tables themselves.

Tools to render nested if statements from traditional programming languages into decision tables can also be used as a debugging tool.

Decision tables have proven to be easier to understand and review than code, and have been used extensively and successfully to produce specifications for complex systems.

Quadrant I. Number of conditions, alternatives and actions

1. Conditional variables
2. Limit variables (each conditional variable has predefined limit variables)

CHAR NAME	TYPE	DESCRIPTION	UNITS	LIMIT VAR
-----------	------	-------------	-------	-----------

soil_water	soil	wp, fc, ul
w_stress	plant	
month	time	
jday	time	
hu	plant	
n_stress	plant	
soil_n	soil	
soil_p	soil	
n_applied	mgt	
plant	plant	
rot_yr	mgt	
biomass	plant	
cover	plant/soil	
lai		
stir_tillage	mgt	
vol	res	pvol, evol
flow	chan	

Quadrant II. Condition alternatives

1. Condition rules – all alternatives met (<, >, =, -)

Quadrant III. Actions

ACTION	OPTIONS
irrigate	amt, file → irr.ops
release	rate, day, weir
plant	name from plants.plt
harvest	file → harv.ops
tillage	file → till.ops
fire	file → fire.ops
(structures)	
(herd)	
(water-rights)	

Quadrant IV. Action Entries

1. ‘y’ (yes)
2. ‘n’ (no)

D_TABLE.DTL

The D_TABLE.DTL file contains the input variables for the nutrient characteristics of the soil properties. Below is a sample D_TABLE.DTL file:

```
d_table.dtl - Little River Watershed
2
NAME CONDS ALTS ACTS
autoirr_str.8 1 1 1
VAR OBJ OB_NUM LIM_VAR LIM_OP LIM_CONST ALT1
w_stress plant 1 null - 0.7 <
ACT_TYP NAME OPTION CONST FILE_POINTER OUTCOME
irrigate drip_high file 0 drip y
```

NAME	COND\$	ALTS	ACT\$					
sw_deficit75		1	1	1				
VAR	OBJ			OB_NUM	LIM_VAR	LIM_OP	LIM_CONST	ALT1
soil_water	hru			0	fcap_mm	-	75.	<
ACT_TYP	NAME			OPTION CONST		FILE_POINTER		OUTCOME
irrigate	sprinkler_high	rate		0		sprinkler_high		y

Variable name	Definition
----------------------	-------------------

TITLE	The first line of the file is reserved for user comments. The comments may take up to 80 spaces. The title line is not processed by the model and may be left blank.
MDTBL	Total number of decision tables in the file
HEADER	Header
NAME	Name of decision table
COND\$	Number of conditions
ALTS	Number of alternatives
ACTS	Number of actions
VAR	Condition variable (vol, sw, time, etc)
OB	Object variable (res, hru, canal, etc)
OB_NUM	Object number
LIM_VAR	Limit variable (evol, pvol, fc, ul, etc)
LIM_OP	Limit operator (*,+,-)
LIM_CONST	Limit constant
ALT	Condition alternatives
TYP	Type of action (reservoir, irrigate, fertilizer, etc)
NAME	Name of action
OPTION	Action option-specific to type of action (ie for reservoir, option to input rate, days of drawdown, weir equation pointer, etc)
CONST	Constant used for rate, days, etc
FILE_POINTER	Pointer for option (ie weir equation pointer)
ACT_OUTCOMES	Action outcomes ('y' to perform action; 'n' to not perform action)
CONST	

Example decision table for continuous corn and explanation:

NAME	CONDs	ALTS	ACTs						
pl_hv_corn	6	4	3						
VAR	OBJ	OB_NUM	LIM_VAR	LIM_OP	LIM_CONST	ALT1	ALT2	ALT3	ALT4
soil_water	hru	0	fc	*	1.05	<	<	-	-
phu_base0	hru	0	null	-	0.15	>	-	-	-
phu_plant	hru	0	phu_mat	-	1.15	-	>	-	-
year_rot	hru	0	null	-	1	=	=	=	-
jday	hru	0	null	-	350	-	-	=	-
year_rot	hru	0	null	-	1	-	-	-	>
ACT_TYP	OBJ	OBJ_NUM	NAME	OPTION	CONST	CONST2	FP	OUTCOMES	
plant	hru	0	plant_corn	corn1500	0	1	null	y	n
harvest_kill	hru	0	grain_harv	corn1500	0	1	grain	n	y
rot_reset	hru	0	reset_1	null	1	0	null	n	n

In the above table, there are 6 conditions, 4 alternatives and 3 actions.

Description of the conditions:

1. soil_water – if soil water is too high ($> 1.05 * \text{field capacity}$), it will be too wet to operate machinery
2. phu_base0 – (0.15) when the sum base zero heat units for the year (starting Jan 1) exceeds 0.15, indicating it's warm enough to plant
3. phu_plant – (1.15) harvest is scheduled when the sum of the heat units for the crop exceed 1.15 (if the heat units to maturity for the crop = 1500, then harvest would be scheduled at $1.15 * 1500 = 1725$).
4. year_rot – needed to identify the current year of rotation. In this example, corn is grown in year 1.
5. jday – julian day (350) – if heat units are not met by this day, the plants are harvested regardless of heat units. This ensures the crop is harvested.
6. year_rot – need to reset the year of rotation

Description of the alternatives:

If all of the conditions for each alternative are met, outcomes are checked for 'y' to take action. Alternatives with dash ('-') are not checked.

1. plant corn based on heat units:
if soil water < 1.05 and
if phubase0 > 0.15 and
if year_rot = 1 and
then
check outcomes for 'y' and if 'y', take that action
2. Harvest corn based on crop accumulated heat units
If soil_water < 1.05 and
If phu_plant > 1.15 and
If year_rot = 1 and
then
check outcomes for 'y' and if 'y', take that action
3. Harvest corn based on day of year
If year_rot = 1 and
If jday = 350
then

30 SWAT+ INPUT/OUTPUT FILE DOCUMENTATION, VERSION 2016

check outcomes for 'y' and if 'y', take that action

4. Reset rotation year

If year_rot > 1

then

check outcomes for 'y' and if 'y', take that action

Description of the actions:

1. Plant – corn1500 – cross walked to plant name in plants.plt file
2. Harvest_kill – corn1500 – cross walked to plant name in plants.plt file
grain – relates to harvest type in harv.ops file
3. CONST2 set = 1 signifies that only 1 action (operation) is allowed in the calendar year.
4. rot_reset- rotation reset – for continuous corn (1 year rotation). The rotation year is reset to 1 at the end of every year.

Fertilizer (will work for Corn and Corn/Soybean rotation):

NAME	COND\$	ALTS	ACTS						
fert_rot_1	5	2	2						
VAR	OBJ	OB_NUM	LIM_VAR	LIM_OP	LIM_CONST			ALT1	ALT2
phu_base0	hru	0	null	-	0.12			>	-
year_rot	hru	0	null	-	1			=	=
n_stress	hru	0	null	-	0.9			-	<
plant_gro	hru	0	y	-	1			-	=
phu_plant	hru	0	phu_mat	-	1.05			-	<
ACT_TYP	OBJ	OBJ_NUM	NAME	OPTION	CONST	CONST2	FP	OUTCOMES	
fertilize	hru	0	ammonia_spring	anh_nh3	160.	1	inject	y	n
fertilize	hru	0	side_dress	urea	50.	2	broadcast	n	y

In the above table, there are 5 conditions, 2 alternatives and 2 actions.

Description of the conditions:

1. phu_base0 – schedule spring and anhydrous ammonia application when base zero heat units exceed 0.12
2. year_rot – checks for year 1 of rotation. This table will work for continuous corn and corn-soybean rotation when corn is planted in the first year.
3. n_stress – used to check side dress urea application. If n-stress is less than 0.9, the side dress application will occur.
4. plant_gro – the side dress occurs while the plant is growing
5. phu_plant – to ensure the side dress application occurs before the plant reaches maturity

Description of the alternatives:

If all of the conditions for each alternative are met, outcomes are checked for 'y' to take action. Alternatives with dash ('-') are not checked.

1. Apply spring anhydrous ammonia

If phu_base0 > 0.12 and

If year_rot = 1

Then

Apply anhydrous ammonia (anh_nh3)

2. Apply urea
If year_rot = 1 and
If n_stress < 0.9 and
If plant_gro = 1 (plant growing) and
If phu_plant < 1.0
Then
Apply side_dress (urea)

Descriptions of the Actions:

1. Apply 160 kh/ha of anh-nh3 (fertilizer name in fertilizer.frt file) - one time
2. Apply 50 kg/ha of urea (fertilizer name in fertilizer.frt file) a maximum of two times

NAME	COND\$	ALTS	ACT\$								
pl_hv_corn	9	4	3								
VAR	OBJ	OB_NUM	LIM_VAR	LIM_OP	LIM_CONST			ALT1	ALT2	ALT3	ALT4
soil_water	hru	0	fc	*	1.05			<	<	-	-
phu_base0	hru	0	null	-	0.15			>	-	-	-
phu_base0	hru	0	null	-	0.50			<	-	-	-
phu_plant	hru	0	phu_mat	-	1.15			-	>	-	-
year_rot	hru	0	null	-	1			=	=	=	-
plant_gro	hru	0	n	-	1			=	-	-	-
plant_gro	hru	0	y	-	1			-	=	=	-
jday	hru	0	null	-	350			-	-	=	-
year_rot	hru	0	null	-	1			-	-	-	>
ACT_TYP	OBJ	OBJ_NUM	NAME	OPTION	CONST	CONST2	FP	OUTCOMES			
plant	hru	0	plant_corn	corn1500	0	0	null	y	n	n	n
harvest_kill	hru	0	grain_harv	corn1500	0	0	grain	n	y	y	n
rot_reset	hru	0	reset_1	null	1	0	null	n	n	n	y

In the above table, there are 9 conditions, 4 alternatives and 3 actions.

Description of the conditions:

7. soil_water – if soil water is too high ($> 1.05 * \text{field capacity}$), it will be too wet to operate machinery
8. phu_base0 – (0.15) when the sum base zero heat units for the year (starting Jan 1) exceeds 0.15, indicating it's warm enough to plant
9. phu_base0 – (0.50) this prevents planting late in the year after the previous crop has been harvested
10. phu_plant – (1.15) harvest is scheduled when the sum of the heat units for the crop exceed 1.15 (if the heat units to maturity for the crop = 1500, then harvest would be scheduled at $1.15 * 1500 = 1725$).
11. year_rot – needed to identify the current year of rotation. In this example, corn is grown in year 1.
12. plant_gro – ‘n’ – needed to allow planting only when a crop is not growing
13. plant_gro – ‘y’ – needed to allow harvesting only when a plant is growing
14. jday – julian day (350) – if heat units are not met by this day, the plants are harvested regardless of heat units. This ensures the crop is harvested.
15. year_rot – need to reset the year of rotation

Description of the alternatives:

If all of the conditions for each alternative are met, outcomes are checked for ‘y’ to take action. Alternatives with dash (‘-’) are not checked.

5. plant corn based on heat units:
if soil water < 1.05 and
if phubase0 > 0.15 and
if phubase0 < 0.50 and
if year_rot = 1 and
if plant_gro = 1
then
check outcomes for ‘y’ and if ‘y’, take that action
6. Harvest corn based on crop accumulated heat units
If soil_water < 1.05 and
If phu_plant > 1.15 and
If year_rot = 1 and
If plant_gro = 1 and
Then
7. check outcomes for ‘y’ and if ‘y’, take that action

8. Harvest corn based on day of year
If year_rot = 1 and
If plant_gro = 1 and
If jday = 350
then
check outcomes for 'y' and if 'y', take that action
9. check outcomes for 'y' and if 'y', take that action
10. Reset rotation yeardg
If year_rot > 1
then
check outcomes for 'y' and if 'y', take that action

Description of the actions:

5. Plant – corn1500 – cross walked to plant name in plants.plt file
6. Harvest_kill – corn1500 – cross walked to plant name in plants.plt file
grain – relates to harvest type in harv.ops file
7. rot_reset – rotation reset – for continuous corn (1 year rotation). The rotation year is reset to 1 at the end of every year.

Example decision table for fertilizer and explanation:

Fertilizer Example:

NAME	COND\$	ALTS	ACT\$							
fert_rot_1	5	2	2							
VAR	OBJ	OB_NUM	LIM_VAR	LIM_OP	LIM_CONST				ALT1	ALT2
phu_base0	hru	0	null	-	0.12				>	-
year_rot	hru	0	null	-	1				=	=
n_stress	hru	0	null	-	0.9				-	<
plant_gro	hru	0	y	-	1				-	=
phu_plant	hru	0	phu_mat	-	1.05				-	<
ACT_TYP	OBJ	OBJ_NUM	NAME	OPTION	CONST	CONST2	FP		OUTCOMES	
fertilize	hru	0	ammonia_spring	anh_nh3	160.	1	inject		y	n
fertilize	hru	0	side_dress	urea	50.	2	broadcast		n	y

In the above table, there are 5 conditions, 2 alternatives and 2 actions.

Description of the conditions:

6. phu_base0 – schedule spring and anhydrous ammonia application when base zero heat units exceed 0.12
7. year_rot – checks for year 1 of rotation. This table will work for continuous corn and corn-soybean rotation when corn is planted in the first year.
8. n_stress – used to check side dress urea application. If n-stress is less than 0.9, the side dress application will occur.
9. plant_gro – the side dress occurs while the plant is growing
10. phu_plant – to ensure the side dress application occurs before the plant reaches maturity

Description of the alternatives:

If all of the conditions for each alternative are met, outcomes are checked for 'y' to take action. Alternatives with dash ('-') are not checked.

3. Apply spring anhydrous ammonia
If phu_base0 > 0.12 and
If year_rot = 1
Then
Apply anhydrous ammonia (anh_nh3)
4. Apply urea
If year_rot = 1 and
If n_stress < 0.9 and

```
If plant_gro = 1 (plant growing) and
If phu_plant < 1.0
Then
Apply side_dress (urea)
```

Descriptions of the Actions:

3. Apply 160 kg/ha of anh-nh3 (fertilizer name in fertilizer.frt file) - one time
 4. Apply 50 kg/ha of urea (fertilizer name in fertilizer.frt file) a maximum of two times
-

1) Decision tables for planting and harvesting.

Warm season annual crops (continuous corn example). This decision table will work with any warm season annual.

NAME	COND\$	ALTS	ACTS										
pl_hv_corn	6	4	3										
VAR	OBJ	OB_NUM	LIM_VAR	LIM_OP	M_CONST				ALT1	ALT2	ALT3	ALT4	
soil_water	hru	0	fc	*	1.5				<	<	-	-	
plant_gro	hru	0	n	-	0				=	-	-	-	
phu_base0	hru	0	null	-	0.15				>	-	-	-	
phu_plant	hru	0	phu_mat	-	1.15				-	>	-	-	
year_rot	hru	0	null	-	1				=	=	=	>	
days_plant	hru	0	null	-	200				-	-	=	-	
ACT_TYP	OBJ	OBJ_NUM	NAME	OPTION	CONST	CONST2	FP	OUTCOMES					
plant	hru	0	plant_corn	corn	0	1	null	y	n	n	n	n	
harvest_kill	hru	0	grain_harv	corn	0	1	grain	n	y	y	n	n	
rot_reset	hru	0	reset_1	null	1	0	null	n	n	n	n	y	

In the above table, there are 6 conditions, 4 alternatives and 3 actions.

Description of the conditions:

16. soil_water – if soil water is too high ($> 1.50 * \text{field capacity}$), it will be too wet to operate machinery
17. plant_gro – (“n”) Planting allowed if plant is not growing.
18. phu_base0 – (0.15) when the sum base zero heat units for the year (starting Jan 1) exceeds 0.15, indicating it's warm enough to plant
19. phu_plant – (1.15) harvest is scheduled when the sum of the heat units for the crop exceed 1.15 (if the heat units to maturity for the crop = 1500, then harvest would be scheduled at $1.15 * 1500 = 1725$).
20. year_rot – needed to identify the current year of rotation. In this example, corn is grown in year 1.
21. days_plant – days since last plant (200) to ensure harvest occurs before next crop is planted.

Description of the alternatives:

If all of the conditions for each alternative are met, outcomes are checked for ‘y’ to take action. Alternatives with dash (‘-’) are not checked.

11. plant corn based on heat units:
if soil water < 1.50*fc and
if phubase0 > 0.15*phu_mat and
if year_rot = 1 and
then
check outcomes for ‘y’ and if ‘y’, take that action (plant)
12. Harvest corn based on crop accumulated heat units
If soil_water < 1.50*fc and
If phu_plant > 1.15*phu_mat and

```
If year_rot = 1 and
then
check outcomes for 'y' and if 'y', take that action (plant)
13. Harvest corn based on days since planting
If year_rot = 1 and
If days_plant =200
then
check outcomes for 'y' and if 'y', take that action (harvest)
14. Reset rotation year
If year_rot > 1
then
check outcomes for 'y' and if 'y', take that action (rot_reset)
```

Description of the actions:

- 8. plant – corn – cross walked to plant name in plants.plt file
- 9. harvest_kill – corn – cross walked to plant name in plants.plt file
grain – relates to harvest type in harv.ops file
- 10. rot_reset- rotation reset – for continuous corn (1 year rotation). The rotation year is reset to 1 at the end of every year.

2) Cool season annual crops (continuous winter wheat example).

pl_hv_wwht	6	4	3									
VAR	OBJ	OB_NUM	LIM_VAR	LIM_OP	M_CONST				ALT1	ALT2	ALT3	ALT4
soil_water	hru	0	fc	*	1.5				<	<	-	-
plant_gro	hru	0	n	-	0				=	-	-	-
phu_base0	hru	0	null	-	0.85				>	-	-	-
phu_plant	hru	0	phu_mat	-	1.15				-	>	-	-
year_rot	hru	0	null	-	1				=	=	=	>
days_plant	hru	0	null	-	200				-	-	=	-
ACT_TYP	OBJ	OBJ_NUM	NAME	OPTION	CONST	CONST2	FP	OUTCOMES				
plant	hru	0	plant_wwht	wwht	0	1	null	y	n	n	n	n
harvest_kill	hru	0	grain_harv	wwht	0	1	grain	n	y	y	n	n
rot_reset	hru	0	reset_1	null	1	0	null	n	n	n	n	y

The cool season annual decision table is similar to the warm season except for the heat units to schedule planting. Planting is triggered when base zero heat units exceed 0.85 of the total annual base zero heat units.

3) Warm season annual crops with 2-year rotation.

NAME	COND\$	ALTS	ACTS									
pl_hv_corn_sb	7	7	5									
VAR	OBJ	OB_NUM	LIM_VAR	LIM_OP	M_CONST				ALT1	ALT2	ALT3	ALT4
soil_water	hru	0	fc	*	1.5				<	<	<	<
plant_gro	hru	0	n	-	0				=	=	-	-
phu_base0	hru	0	null	-	0.15				>	>	-	-
phu_plant	hru	0	phu_mat	-	1.15				-	-	>	>
year_rot	hru	0	null	-	1				=	-	=	-
year_rot	hru	0	null	-	2				-	=	-	=
days_plant	hru	0	null	-	200				-	-	-	=
ACT_TYP	OBJ	OBJ_NUM	NAME	OPTION	CONST	CONST2	FP	OUTCOMES				
plant	hru	0	plant_corn	corn	0	1	null	y	n	n	n	n
plant	hru	0	plant_soyb	soyb	0	1	null	n	y	n	n	n
harvest_kill	hru	0	grain_harv	corn	0	1	grain	n	n	y	n	y
harvest_kill	hru	0	grain_harv	soyb	0	1	grain	n	n	y	n	y
rot_reset	hru	0	reset_2	null	1	0	null	n	n	n	n	n

The 2-year rotation, warm season annual decision is identical to the continuous corn warm season, with the addition of a condition to check for second year of rotation. In the first year of rotation, corn is planted and harvested, while soybeans are grown in the second year. An action for resetting the rotation year is triggered when the rotation year exceeds two.

- 4) Warm and cool season annuals in rotation (4-year rotation is corn-corn-soybeans-winter wheat-soybeans).

NAME	COND\$		ALTS		ACT\$														
	10	11			7														
VAR	OBJ	OB_NUM	LIM_VAR	LIM_OP	M_CONST		ALT1	ALT2	ALT3	ALT4	ALT5	ALT6	ALT7	ALT8	ALT9	ALT10	ALT11		
soil_water	hru	0	fc	*	1.5		<	<	-	<	<	<	<	-	-	-	-	-	
phu_base0	hru	0	null	-	0.15		>	>	-	-	-	-	-	-	-	-	-	-	
days_harv	hru	0	null	-	7		-	-	=	=	-	-	-	-	-	-	-	-	
phu_plant	hru	0	phu_mat	-	1.15		-	-	-	>	>	>	-	-	-	-	-	-	
year_rot	hru	0	null	-	3		<	-	-	-	<	-	-	<	-	-	-	-	
year_rot	hru	0	null	-	2		-	-	-	-	>	-	-	>	-	-	-	-	
year_rot	hru	0	null	-	3		-	=	-	=	-	-	-	-	-	-	-	-	
year_rot	hru	0	null	-	4		-	-	=	-	-	-	-	=	-	=	=	-	
days_plant	hru	0	null	-	200		-	-	-	-	-	-	-	-	=	=	=	-	
year_rot	hru	0	null	-	4		-	-	-	-	-	-	-	-	-	-	-	>	
ACT_TYP	OBJ	OBJ_NUM	NAME	OPTION	CONST	CONST2	FP	UTCOMES											
plant	hru	0	plant_corn	corn	0	1	null	y	n	n	n	n	n	n	n	n	n	n	
plant	hru	0	plant_soyb	soyb	0	1	null	n	y	y	n	n	n	n	n	n	n	n	
plant	hru	0	plant_wwht	wwht	0	1	null	n	n	y	n	n	n	n	n	n	n	n	
harvest_kill	hru	0	grain_harv	corn	0	1	grain	n	n	n	y	n	n	y	n	n	n	n	
harvest_kill	hru	0	grain_harv	soyb	0	1	grain	n	n	n	y	n	n	y	n	y	n	n	
harvest_kill	hru	0	grain_harv	wwht	0	1	grain	n	n	n	n	n	n	y	n	n	y	n	
rot_reset	hru	0	reset_4	null	1	0	null	n	n	n	n	n	n	n	n	n	n	y	

Adding the winter crop to the rotation required a change in the planting of the winter wheat. Winter wheat planting is scheduled using the days_harv condition. When days since the last harvest = 7, and soil water is below 1.5*fc, and in rotation year 3, winter wheat is planted.

- 5) Perennial grass and range. If there is no management of native grass or range, no management file is needed and “null” can be entered in the MGT_OPS column in landuse.lum file. In plants.ini, the plants can be growing at the start of the simulation (IGRO=“y”) and initial leaf area, biomass, residue etc. on the first day of the simulation can be input.

a) Hay cutting (continuous alfalfa)

NAME	COND\$		ALTS		ACT\$													
	3	1	1															
VAR	OBJ	OB_NUM	LIM_VAR	LIM_OP	LIM_CONST											ALT1		
soil_water	hru	0	fc	*	1.5												<	
phu_plant	hru	0	phu_mat	-	0.5												>	
biomass	hru	0	null	-	3000												>	
ACT_TYP	OBJ	OBJ_NUM	NAME	OPTION	CONST	CONST2	FP	OUTCOMES										
harvest	hru	0	hay_harv	alfa	0	3	biomass	y										

Hay cuttings are scheduled when soil water is below 1.5*fc, heat units exceed 0.5*phu_mat and above ground biomass exceeds 3,000 kg/ha. In this case, no additional conditions are needed since heat units are reset during a cutting operation. The “harvest” action harvests “alfa” “biomass” with a maximum of 3 harvests per year (CONST2).

b) Grazing

graze_summer	3	1	1						
VAR	OBJ	OB_NUM	LIM_VAR	LIM_OP	M_CONST				ALT1
jday	hru	0	null	-	120				>
jday	hru	0	null	-	200				<
biomass	hru	0	null	-	3000				>
ACT_TYP	OBJ	OBJ_NUM	NAME	OPTION	CONST	CONST2	FP	OUTCOMES	
graze	hru	0	summer_high	beef_high	0	0	null	y	

graze_winter	3	2	1						
VAR	OBJ	OB_NUM	LIM_VAR	LIM_OP	LIM_CONST				ALT1 ALT2
jday	hru	0	null	-	295				> -
jday	hru	0	null	-	85				- <
biomass	hru	0	null	-	3000				> >
ACT_TYP	OBJ	OBJ_NUM	NAME	OPTION	CONST	CONST2	FP	OUTCOMES	
graze	hru	0	winter_low	beef_low	0	0	null	y	y

These decision tables schedule grazing by dates for summer and winter grazing schedules. The winter grazing allows razing between day 295 and 85 when biomass is above 3,000 kg/ha. The tables can be easily modified to use heat units instead of dates and also to include different grazing management schedules.

- 6) Forest. When a native forest it not managed, no management file is needed and “null” can be entered in the MGT_OPS column in landuse.lum. Initial LAI, biomass, residue and initial years to maturity will need to be input in plants.ini. When forests are cut, a simple decision table can be used.

forest_cut	2	1	1						
VAR	OBJ	OB_NUM	LIM_VAR	LIM_OP	M_CONST				ALT1
cur_yrs_mat	hru	0	null	-	20				=
jday	hru	0	null	-	295				=
ACT_TYP	OBJ	OBJ_NUM	NAME	OPTION	CONST	CONST2	FP	OUTCOMES	
harvest	hru	0	tree_harv	frsd	0	0	forest_cut	y	

In the 20th year of growth, on julian day 295, the forest is harvested. The “forest_cut” operation in harv.ops specifies the harvest index and efficiency used in the operation.

- 7) Wetland. When a wetland it not managed, no management file is needed and “null” can be entered in the MGT_OPS column in landuse.lum.

Fertilizer decision table:

NAME	COND\$	ALTS	ACTS							
fert_sprg_sic	5	2	2							
VAR	OBJ	OBJ_NUM	LIM_VAR	LIM_OP	M_CONST				ALT1	ALT2
phu_base0	hru	0	null	-	0.12				>	-
year_rot	hru	0	null	-	1				=	=
n_stress	hru	0	null	-	0.9				<	<
plant_gro	hru	0	y	-	1				-	=
phu_plant	hru	0	phu_mat	-	1.05				-	<
ACT_TYP	OBJ	OBJ_NUM	NAME	OPTION	CONST	CONST2	FP	OUTCOMES		
fertilize	hru	0	ammonia_spring	anh_nh3	160	1	inject	y	n	
fertilize	hru	0	side_dress	urea	50	2	broadcast	n	y	

PLANT.INI file:

plant.ini:										
NAME	PL_COM	ROTYR	CPNM	IGRO	LAI	BIOMS	PHUACC	POP	YRMAT	RSDIN
corn_sb_1	2	1								
			corn	n	0	0	0	0	0	2000
			soyb	n	0	0	0	0	0	2000
corn_sb_2	2	2								
			corn	n	0	0	0	0	0	2000
			soyb	n	0	0	0	0	0	2000
corn_sb_shemi1	2	1								
			corn	y	2	8000	0.3	0	0	2000
			soyb	n	0	0	0	0	0	2000
corn_sb_shemi2	2	2								
			corn	n	0	0	0	0	0	2000
			soyb	y	2	4000	0.3	0	0	2000
corn_con	1	1								
			corn	n	0	0	0	0	0	2000
soyb_con	1	1								
			soyb	n	0	0	0	0	0	2000
corn_con_shemi	1	1								
			corn	y	2	8000	0.3	0	0	2000
soyb_con_shemi	1	1								
			soyb	y	2	4000	0.3	0	0	2000
canary_grass	1	1								
			cang	y	1	1000	0	0	0	2000

REGIONS-

LS_UNIT.ELE

The LS_UNIT.ELE file contains the input variables

Below is a sample LS_UNIT.ELE

```
ls_unit.ele
NUMB   NAME  OBTYPE  OBTYPENO  BSN_FRAC  SUB_FRAC  REG_FRAC
 1     hru1    hru        1      0.500      0.5       0
 2     hru2    hru        2      0.500      0.5       0
```

Variable name	Definition
TITLE	Description of the LS_UNIT.ELE file
HEADER	
NUMB	The sequential number of the LS_UNIT.ELE
NAME	Name
OB_TYP	Type of object to print (cha, res, etc)
OBTYPENO	Object type number
BSN_FRAC	fraction of element in basin (expansion factor)
SUB_FRAC	fraction of element in sub (expansion factor)

LS_UNIT.DEF

The LS_UNIT.DEF file contains the input variables

Below is a sample LS_UNIT.DEF

```
ls_unit.def    Subbasin
 2
NUMB      NAME      AREA_HA      NSPU      ELEM1      ELEM2
 1        lcu1      493.38      1         1          2
```

Variable name	Definition
TITLE	Description of the LS_UNIT.DEF file
MLSU	Number of regions
HEADER	
NUMB	The sequential number of the LS_UNIT.DEF
NAME	
AREA_HA	Surface area
NSPU	
ELEM_CNT	

LS_REG.DEF

The LS_REG.DEF file contains the input variables

Below is a sample LS_REG.DEF

```
ls_reg.def Subbasin
2
NUMB      NAME      AREA_HA      NSPU      ELEM1      ELEM2
1          lcu1     493.38       1          1          2
```

Variable name	Definition
TITLE	Description of the LS_REG.DEF file
MREG	Number of regions
MLUG	Number of landuse groups
HEADER	
NUMB	The sequential number of the LS_REG.DEF
NAME	
AREA_HA	Surface area
NSPU	
ELEM_CNT	

CH_CATUNIT.DEF

The CH_CATUNIT.DEF file contains the input variables

Below is a sample CH_CATUNIT.DEF

```
Ch_catunit.def Subbasin
2
NUMB      NAME      AREA_HA      NSPU      ELEM1      ELEM2
1          lcu1     493.38       1          1          2
```

Variable name	Definition
TITLE	Description of the CH_CATUNIT.DEF file
MREG	Number of regions
HEADER	
NUMB	The sequential number of the CH_CATUNIT.DEF
NAME	
AREA_HA	Surface area
NSPU	
ELEM_CNT	

CH_REG.DEF

The CH_REG.DEF file contains the input variables

Below is a sample CH_REG.DEF

```
Ch_reg.def Subbasin
 2
  NUMB      NAME      AREA_HA      NSPU      ELEM1      ELEM2
  1        lcu1     493.38       1          1          2
```

Variable name	Definition
TITLE	Description of the CH_REG.DEF file
MREG	Number of regions
HEADER	
NUMB	The sequential number of the CH_REG.DEF
NAME	
AREA_HA	Surface area
NSPU	
ELEM_CNT	

AQU_CATUNIT.ELE

The AQU_CATUNIT.ELE file contains the input variables

Below is a sample AQU_CATTUNIT.ELE

```
Aqu_catunit.ele
NUMB   NAME   OBTYP   OBTYPNO   BSN_FRAC   SUB_FRAC   REG_FRAC
 1     hru1    hru        1      0.500      0.5        0
 2     hru2    hru        2      0.500      0.5        0
```

Variable name	Definition
TITLE	Description of the AQU_CATUNIT.ELE file
HEADER	
NUMB	The sequential number of the AQU_CATUNIT.ELE
NAME	
OBTYP	Type of object to print (cha, res, etc)
OBTYPNO	Object type number
BSN_FRAC	fraction of element in basin (expansion factor)
SUB_FRAC	fraction of element in sub (expansion factor)
REG_FRAC	fraction of element in calibration region (expansion factor)

AQU_CATUNIT.DEF

The AQU_CATUNIT.DEF file contains the input variables

Below is a sample AQU_CATUNIT.DEF

```
Aqu_catunit.def Subbasin
2
NUMB      NAME       AREA_HA      NSPU      ELEM1      ELEM2
  1        lcu1      493.38      1          1          2
```

Variable name Definition

TITLE	Description of the AQU_CATUNIT.DEF file
MREG	Number of regions
HEADER	
NUMB	The sequential number of the AQU_CATUNIT.DEF
NAME	
AREA_HA	Surface area
NSPU	
ELEM_CNT	

AQU_REG.DEF

The AQU_REG.DEF file contains the input variables

Below is a sample AQU_REG.DEF

```
aqu_reg.def Subbasin
2
NUMB      NAME       AREA_HA      NSPU      ELEM1      ELEM2
  1        lcu1      493.38      1          1          2
```

Variable name Definition

TITLE	Description of the AQU_REG.DEF file
MREG	Number of regions
HEADER	
NUMB	The sequential number of the AQU_REG.DEF
NAME	
AREA_HA	Surface area
NSPU	
ELEM_CNT	

RES_CATUNIT.ELE

The RES_CATUNIT.ELE file contains the input variables

Below is a sample RES_CATTUNIT.ELE

res_catunit.ele

NUMB	NAME	OBTYP	OBTYPNO	BSN_FRAC	SUB_FRAC	REG_FRAC	
1	hru1	hru		1	0.500	0.5	0
2	hru2	hru		2	0.500	0.5	0

Variable name	Definition
TITLE	Description of the RES_CATUNIT.ELE file
HEADER	
NUMB	The sequential number of the RES_CATUNIT.ELE
NAME	
OBTYP	Type of object to print (cha, res, etc)
OBTYPNO	Object type number
BSN_FRAC	fraction of element in basin (expansion factor)
SUB_FRAC	fraction of element in sub (expansion factor)
REG_FRAC	fraction of element in calibration region (expansion factor)

RES_REG.DEF

The RES_REG.DEF file contains the input variables

Below is a sample RES_REG.DEF

res_reg.def Subbasin

NUMB	NAME	AREA_HA	NSPU	ELEM1	ELEM2
1	lcu1	493.38	1	1	2

Variable name	Definition
TITLE	Description of the RES_REG.DEF file
MREG	Number of regions
HEADER	
NUMB	The sequential number of the RES_REG.DEF
NAME	
AREA_HA	Surface area
NSPU	
ELEM_CNT	

RES_CATUNIT.DEF

The RES_CATUNIT.DEF file contains the input variables

Below is a sample RES_CATTUNIT.DEF

```
res_catunit.def Subbasin
 2
  NUMB      NAME     AREA_HA      NSPU      ELEM1      ELEM2
    1       lcu1     493.38        1         1         2
```

Variable name Definition

TITLE	Description of the RES_CATUNIT.DEF file
MREG	Number of regions
HEADER	
NUMB	The sequential number of the RES_CATUNIT.DEF
NAME	
AREA_HA	Surface area
NSPU	
ELEM_CNT	

REC_CATUNIT.ELE

The REC_CATUNIT.ELE file contains the input variables

Below is a sample REC_CATTUNIT.ELE

```
rec_catunit.ele
NUMB   NAME   OBTYP   OBTYPNO   BSN_FRAC   SUB_FRAC   REG_FRAC
 1     hru1    hru        1       0.500      0.5        0
 2     hru2    hru        2       0.500      0.5        0
```

Variable name Definition

TITLE	Description of the REC_CATUNIT.ELE file
HEADER	
NUMB	The sequential number of the REC_CATUNIT.ELE
NAME	
OBTYP	Type of object to print (cha, res, etc)
OBTYPNO	Object type number
BSN_FRAC	fraction of element in basin (expansion factor)
SUB_FRAC	fraction of element in sub (expansion factor)
REG_FRAC	fraction of element in calibration region (expansion factor)

REC_CATUNIT.DEF

The REC_CATUNIT.DEF file contains the input variables

Below is a sample REC_CATUNIT.DEF

rec_catunit.def Subbasin

2	NUMB 1	NAME lcu1	AREA_HA 493.38	NSPU 1	ELEM1 1	ELEM2 2
---	-----------	--------------	-------------------	-----------	------------	------------

Variable name Definition

TITLE	Description of the REC_CATUNIT.DEF file
MREG	Number of regions
HEADER	
NUMB	The sequential number of the REC_CATUNIT.DEF
NAME	
AREA_HA	Surface area
NSPU	
ELEM_CNT	

REC_REG.DEF

The REC_REG.DEF file contains the input variables

Below is a sample REC_REG.DEF

rec_reg.def Subbasin

2	NUMB 1	NAME lcu1	AREA_HA 493.38	NSPU 1	ELEM1 1	ELEM2 2
---	-----------	--------------	-------------------	-----------	------------	------------

Variable name Definition

TITLE	Description of the REC_REG.DEF file
MREG	Number of regions
HEADER	
NUMB	The sequential number of the REC_REG.DEF
NAME	
AREA_HA	Surface area
NSPU	
ELEM_CNT	

PATH PCP/PATH TMP/PATH SLR/PATH HMD/PATH WND

The PATH weather files contain the daily values for the simulation run. The data files can be present in the same directory as the other input data OR in a separate sub-directory. If they are copied to a sub-directory, the following should be input so the model will read from the files during runtime.

In the following example, the data directory is: c:\LREW and the weather will be read from c:\LREW\weather.

Example:

CLIMATE_PCP	weather\\
CLIMATE_TMP	weather\\
CLIMATE_SLR	weather\\
CLIMATE_HMD	weather\\
CLIMATE_WND	weather\\

(d:\swatplus_code\water_bal_plant_wx_sums_or_avgs.xlsx)

Basin Outputs – The following table defines whether the water balance and plant weather variables are averaged or summed in the output file. All losses and nutrients are summed.

WATER BAL - AVERAGE	WATER BAL - SUM	PLANT WX - AVERAGE	PLANT WX - SUM
cn	precip	lai	yield
sw	snofall	bioms	strsw
sw_300	snoqlt	residue	strsa
snopack	surq_gen	sol_tmp	strstmp
	latq	nplnt	strsn
	wateryld	pplnt	strsp
	perc	tmx	percn
	et	tmn	
	tloss	tmpav	
	eplant	solrad	
	esoil	wndspd	
	surq_cont	rhum	
	pet	phubase0	
	qtile		
	irr		
	surq_runon		
	latq_runon		
	overbank		
	surq_cha		
	surq_res		
	surq_ls		
	latq_cha		
	latq_res		
	latq_ls		
LOSSES and NUTRIENTS			
(all sums)			