AETHER MUG
USER MANUAL

Case Study: Aether Mug Example



Table of Contents

1. Product Overview
2. What's in the Box
3. Charging Instructions
4. How to Use the AetherMug
5. Safety Guidelines
6. Troubleshooting
7. Warranty & Support

01

Product Overview

Overview

The AetherMug is a smart ceramic mug designed to maintain your beverages at the perfect temperature. Featuring Bluetooth connectivity and an intuitive touch display, it combines modern technology with everyday convenience.

Purpose

The AetherMug ensures your beverages stay at your ideal temperature, making it perfect for work, study sessions, or relaxing at home.

Key features

The major features:

- Adjustable temperature range: 95°F – 150°F (35°C – 65°C)
- 4-hour battery life
- Auto shut-off after 30 minutes of inactivity
- App integration with AetherSync
- LED indicator and touch-sensitive controls
- USB-C charging

02

What’s in the box?

Aether Mug comes with:

- 1x AetherMug
- 1x USB-C Charging Cable
- 1x Quick Start Guide



03

Charging Instructions

The AetherMug comes with a standard charger. Please follow the steps below for proper use.

STEPS

1. Connect the USB-C cable to the charging port located underneath the AetherMug.
2. Plug the other end into a USB power adapter.
3. A blinking green LED indicates the mug is charging.
4. A solid green LED means the mug is fully charged.
5. A full charge typically takes 2 hours.

04

How to use the Aethermug.

The AetherMug is designed for ease of use. With just the touch of a button, your mug will be ready to function. Simply download the app and connect to get started.

Steps

1. Turn on the AetherMug by tapping the touch-sensitive display.
2. Adjust your desired temperature by sliding your finger left or right on the display.
3. Download and install the AetherSync app from the App Store or Google Play.
4. Pair your AetherMug via Bluetooth through the AetherSync app for remote control and preset settings.

05

Safety Guidelines

At Aethermug, user safety is our top priority. Please review the following guidelines carefully to ensure proper and safe operation of the product.

Guidelines

- Do not submerge the AetherMug in water.
- Only use the included USB-C charging cable.
- Keep out of reach of small children when operating.
- Do not use the mug if it appears damaged.

06

Troubleshooting

The main issues and their corresponding solutions are listed below. Please note that additional issues may occasionally arise.

Problem	Solution
• Mug Not Heating	• Ensure the mug is charged and powered on.
• Bluetooth won’t connect	• Restart the AetherSync app and retry pairing.
• LED flashing red	• Battery critically low; recharge immediately.

If a problem persists or is not listed, please contact support. We will be happy to assist you.

07

Warranty & Support

The AetherMug includes a 1-year limited warranty against manufacturing defects.

For assistance and support, please contact: support@aethermug