## **Project 3: Line Tracking Sensor**

#### 1.Description

The tracking sensor is actually an infrared sensor.

The component used here is the TCRT5000 infrared tube. Its working principle is to use different reflectivity of infrared light to colors, then convert



the strength of the reflected signal into a current signal.

During the process of detection, black is active at HIGH level while white is active at LOW level. The detection height is 0-3 cm.

Keyestudio 3-channel line tracking module has integrated 3 sets of TCRT5000 infrared tubes on a board, which is more convenient for wiring and control.

By rotating the adjustable potentiometer on the sensor, it can adjust the detection sensitivity of the sensor.

### 2.Specification


Operating Voltage: 3.3-5V (DC)

Interface: 5PIN

Output Signal: Digital signal

Detection Height: 0-3 cm

Note: Before testing, rotate the




www.keyesunio.com.TrimPo

potentiometer on the sensor to adjust the detection sensitivity. The sensitivity is best when adjusting the LED to a threshold between ON and OFF.

## 3. Components

Keyestudio 4.0  Development  Board *1	Keyestudio 8833 Motor Driver Expansion Board *1		Red LED Module*1
Est to the second of the secon			CED SE
5P Dupont Wire*1	USB Cable*1	3P Dupont Wire*1	Keyestudio Line Tracking Sensor*1

## 4.Wiring Diagram




G, V, S1, S2 and S3 of the line tracking sensor are connected to G (GND), V (VCC), D11, D7 and D8 of the sensor expansion board.


#### 5.Test Code

#### 6.Test Result

After successfully uploading the code to the V4.0 board, connect the wirings according to the wiring diagram, and use a USB cable to connect the computer to power the board.

After powering on, open the serial monitor and you will view status of three line tracking sensors. When no signals are received, the value is 1. If we cover the sensor with a white paper, the value will be 0.





## 7.Code Explanation

Serial.begin(9600)- Initialize serial port, set baud rate to 9600

pinMode- Define the pin as input or output mode


digitalRead-Read the state of pin, which are generally HIGH and LOW

www.keyestudio.com

level

### 8.Extension Practice

After knowing its working principle, you can connect an LED to D9 so as to control LED by it.



```
pinMode(M_pin, INPUT); // make the M_pin as an input
 pinMode(R_pin, INPUT); // make the R_pin as an input
 pinMode(9, OUTPUT);
void loop()
 val_L = digitalRead(L_pin);//read the L_pin:
 val_R = digitalRead(R_pin);//read the R_pin:
 val_M = digitalRead(M_pin);//read the M_pin:
 Serial.print("left:");
 Serial. print (val_L);
 Serial.print(" middle:");
 Serial.print(val M);
 Serial.print(" right:");
 Serial.println(val R);
 delay(500);// delay in between reads for stability
  if ((val_L = LOW) \mid | (val_M = LOW) \mid | (val_R = LOW)) / / if left line tracking sensor detects signals
   Serial.println("HIGH");
   digitalWrite(9, HIGH);//LED is off
 else//if left line tracking sensor doesn't detect signals
   Serial.println("LOW");
   digitalWrite(9, LOW);//LED is off
```

After successfully uploading the code to the V4.0 board, connect the wirings according to the wiring diagram, and use a USB cable to connect the computer to power the board.

After powering on, make a paper close to the sensor, then we can find the LED light up when covering the line tracking sensor.