







TEMPSTAR VER/FL-VER



TEMPSTAR HH-E-VER



1.888.800.5672
www.jacksonwws.com


Jackson
WAREWASHING SYSTEMS

INSTALL GUIDE



TEMPSTAR SERIES DOOR-TYPE DISHMACHINES

-  = risk of electric shock
riesgo de electrocución
risque de décharge électrique
-  = caustic chemicals
químicos cáusticos
produits chimiques caustiques
-  = ground wire
cable a tierra
fil de terre
-  = verify
verificar
vérifier
-  = use fingers/hands
utilizar los dedos/manos
utilisez vos doigts/mains
-  = use eyes
utiliza tus ojos
utilisez vos yeux
-  = reference data plate
mire la placa de datos
regarder la plaque signalétique
-  = water
agua
eau
-  = not supplied
no se suministra
non fourni
-  = level
nivel
niveau




TEMPSTAR[®] VER/FL-VER/HH-E-VER

1


If not already installed, scan the QR code.

Si no es instalado escanee código QR.



Si pas déjà installé, scannez le code QR.





4







7





2




5



8






3



6



External Dispenser System
Sistema dispensador externo
Système de distribution externe



9

