



10




Hold for three seconds. Time will display.

Mantenga durante tres segundos. Aparecerá el tiempo.


Maintenez la main pendant trois secondes. Le temps s'affichera.



13



14





11





Hold for three seconds. Time will display.

Mantenga durante tres segundos. Aparecerá el tiempo.

Maintenez la main pendant trois secondes. Le temps s'affichera.



12



1.888.800.5672
www.jacksonwws.com

Jackson
WAREWASHING SYSTEMS

INSTALL GUIDE



DISHSTAR HT

DYNASTAR SERIES DOOR-TYPE DISHMACHINES



= risk of electric shock
riesgo de electrocución
risque de décharge électrique



= caustic chemicals
químicos cáusticos
produits chimiques caustiques



= ground wire
cable a tierra
fil de terre



= verify
verificar
vérifier



= use fingers/hands
utilizar los dedos/manos
utilisez vos doigts/mains



= use eyes
utiliza tus ojos
utilisez vos yeux



= reference data plate
mire la placa de datos
regarder la plaque signalétique



= water
agua
eau



= not supplied
no se suministra
non fourni




= listen
escuchar
écoute












= on
encendido
allumé



= off
apagado
éteint





20 ± 5 PSI