
## Stand off Socket Manual

1. Find Socket from Fitting Pack



2. Install "Stand off" by socket



