Digital Communications SSY125, Lectures 5 and 6

Communication over a Noisy Channel (Chapters 4 and 5)

Christian Häger Slides prepared by Alexandre Graell i Amat



November 8, 2023



digital data, voice movie, audio 100110101



satellite link, fiber, telephone line, hard-disk drive, DVD



100011101

In These Lectures...

- How much information can we transmit reliably over an unreliable channel?
- How do we achieve this in practice?



digital data, voice movie, audio 100110101



satellite link, fiber, telephone line, hard-disk drive, DVD




100011101

In These Lectures...

- How much information can we transmit reliably over an unreliable channel?
- How do we achieve this in practice?

Shannon's Seminal Contribution

There is a fundamental limit, i.e., a highest rate, at which information can be transmitted reliably over the channel: channel capacity.









Discrete Memoryless Channel

• The input and output of the channel, $x = (x_1, x_2, ...,)$ and $y = (y_1, y_2, ...,)$, are discrete, i.e., $x_i \in \mathcal{X}$ and $y_i \in \mathcal{Y}$.



- The input and output of the channel, $x = (x_1, x_2, ...,)$ and $y = (y_1, y_2, ...,)$, are discrete, i.e., $x_i \in \mathcal{X}$ and $y_i \in \mathcal{Y}$.
- Channel is defined by $P_{Y|X}(y|x)$




- The input and output of the channel, $x=(x_1,x_2,\ldots,)$ and $y=(y_1,y_2,\ldots,)$, are discrete, i.e., $x_i\in\mathcal{X}$ and $y_i\in\mathcal{Y}$.
- Channel is defined by $P_{Y|X}(y|x)$ with (memoryless)

$$P_{\boldsymbol{Y}|\boldsymbol{X}}(\boldsymbol{y}|\boldsymbol{x}) =$$




- The input and output of the channel, $x=(x_1,x_2,\ldots,)$ and $y=(y_1,y_2,\ldots,)$, are discrete, i.e., $x_i\in\mathcal{X}$ and $y_i\in\mathcal{Y}$.
- Channel is defined by $P_{Y|X}(y|x)$ with (memoryless)

$$P_{Y|X}(y|x) = \prod_{i} P_{Y|X}(y_i|x_i).$$




- The input and output of the channel, $x = (x_1, x_2, ...,)$ and $y = (y_1, y_2, ...,)$, are discrete, i.e., $x_i \in \mathcal{X}$ and $y_i \in \mathcal{Y}$.
- Channel is defined by $P_{Y|X}(y|x)$ with (memoryless)

$$P_{Y|X}(y|x) = \prod_{i} P_{Y|X}(y_i|x_i).$$



- The input and output of the channel, $x = (x_1, x_2, ...,)$ and $y = (y_1, y_2, ...,)$, are discrete, i.e., $x_i \in \mathcal{X}$ and $y_i \in \mathcal{Y}$.
- Channel is defined by $P_{Y|X}(y|x)$ with (memoryless)

$$P_{Y|X}(y|x) = \prod_{i} P_{Y|X}(y_i|x_i).$$




Discrete Memoryless Channel

- The input and output of the channel, $x = (x_1, x_2, ...,)$ and $y = (y_1, y_2, ...,)$, are discrete, i.e., $x_i \in \mathcal{X}$ and $y_i \in \mathcal{Y}$.
- Channel is defined by $P_{Y|X}(y|x)$ with (memoryless)

$$P_{Y|X}(y|x) = \prod_{i} P_{Y|X}(y_i|x_i).$$


• Channel input: $X \in \mathcal{X}$.



- The input and output of the channel, $x = (x_1, x_2, ...,)$ and $y = (y_1, y_2, ...,)$, are discrete, i.e., $x_i \in \mathcal{X}$ and $y_i \in \mathcal{Y}$.
- Channel is defined by $P_{Y|X}(y|x)$ with (memoryless)

$$P_{Y|X}(y|x) = \prod_{i} P_{Y|X}(y_i|x_i).$$

- Channel input: $X \in \mathcal{X}$.
- Channel output: $Y \in \mathcal{Y}$.



- The input and output of the channel, $x = (x_1, x_2, ...,)$ and $y = (y_1, y_2, ...,)$, are discrete, i.e., $x_i \in \mathcal{X}$ and $y_i \in \mathcal{Y}$.
- Channel is defined by $P_{Y|X}(y|x)$ with (memoryless)

$$P_{Y|X}(y|x) = \prod_{i} P_{Y|X}(y_i|x_i).$$

- Channel input: $X \in \mathcal{X}$.
- Channel output: $Y \in \mathcal{Y}$.
- Entirely specified by the conditional PMF $P_{Y|X}(y|x)$.

• Both the channel input and the channel output are random variables

Both the channel input and the channel output are random variables

The information content of a random variable, its uncertainty, is given by the entropy!

Both the channel input and the channel output are random variables —
 The information content of a random variable, its uncertainty, is given by the entropy!

Average amount of uncertainty on the input of the channel X:

$$\mathsf{H}(X) = \sum_{x \in \mathcal{X}} P(x) \log \frac{1}{P(x)}.$$

Both the channel input and the channel output are random variables —
 The information content of a random variable, its uncertainty, is given by the entropy!

Average amount of uncertainty on the input of the channel X:

$$\mathsf{H}(X) = \sum_{x \in \mathcal{X}} P(x) \log \frac{1}{P(x)}.$$

We have shown...

$$0 \leq \mathsf{H}(X) \leq \log |\mathcal{X}|.$$

Both the channel input and the channel output are random variables —
 The information content of a random variable, its uncertainty, is given by the entropy!

Average amount of uncertainty on the input of the channel X:

$$\mathsf{H}(X) = \sum_{x \in \mathcal{X}} P(x) \log \frac{1}{P(x)}.$$

We have shown...

$$0 \le \mathsf{H}(X) \le \log |\mathcal{X}|.$$

Average amount of uncertainty on the channel output Y:

$$\mathsf{H}(Y) = \sum_{y \in \mathcal{V}} P(y) \log \frac{1}{P(y)}.$$

Definition (Conditional Entropy of X given Y = y)

The conditional entropy of X given the event $Y=\boldsymbol{y}$ is

$$\mathsf{H}(X|Y=y) \triangleq \sum_{x \in X} P(x|y) \log \frac{1}{P(x|y)}$$

Definition (Conditional Entropy of X given Y = y)

The conditional entropy of X given the event Y=y is

$$\mathsf{H}(X|Y=y) \triangleq \sum_{x \in X} P(x|y) \log \frac{1}{P(x|y)}$$

Definition (Conditional Entropy)

$$\mathsf{H}(X|Y) =$$

Definition (Conditional Entropy of X given Y = y)

The conditional entropy of X given the event Y = y is

$$\mathsf{H}(X|Y=y) \triangleq \sum_{x \in X} P(x|y) \log \frac{1}{P(x|y)}$$

Definition (Conditional Entropy)

$$\mathsf{H}(X|Y) = \sum_{y \in \mathcal{Y}} P(y) \mathsf{H}(X|Y = y)$$

Definition (Conditional Entropy of X given Y = y)

The conditional entropy of X given the event Y = y is

$$\mathsf{H}(X|Y=y) \triangleq \sum_{x \in X} P(x|y) \log \frac{1}{P(x|y)}$$

Definition (Conditional Entropy)

$$\begin{split} \mathsf{H}(X|Y) &= \sum_{y \in \mathcal{Y}} P(y) \mathsf{H}(X|Y = y) \\ &= \sum_{y \in \mathcal{Y}} P(y) \sum_{x \in \mathcal{X}} P(x|y) \log \frac{1}{P(x|y)} \end{split}$$

Definition (Conditional Entropy of X given Y = y)

The conditional entropy of X given the event Y=y is

$$\mathsf{H}(X|Y=y) \triangleq \sum_{x \in X} P(x|y) \log \frac{1}{P(x|y)}$$

Definition (Conditional Entropy)

$$\begin{split} \mathsf{H}(X|Y) &= \sum_{y \in \mathcal{Y}} P(y) \mathsf{H}(X|Y = y) \\ &= \sum_{y \in \mathcal{Y}} P(y) \sum_{x \in \mathcal{X}} P(x|y) \log \frac{1}{P(x|y)} \\ &= \sum_{x \in \mathcal{X}} \sum_{y \in \mathcal{Y}} P(y) P(x|y) \log \frac{1}{P(x|y)} \end{split}$$

Definition (Conditional Entropy of X given Y = y)

The conditional entropy of X given the event Y=y is

$$\mathsf{H}(X|Y=y) \triangleq \sum_{x \in X} P(x|y) \log \frac{1}{P(x|y)}$$

Definition (Conditional Entropy)

$$\begin{split} \mathsf{H}(X|Y) &= \sum_{y \in \mathcal{Y}} P(y) \mathsf{H}(X|Y = y) \\ &= \sum_{y \in \mathcal{Y}} P(y) \sum_{x \in \mathcal{X}} P(x|y) \log \frac{1}{P(x|y)} \\ &= \sum_{x \in \mathcal{X}} \sum_{y \in \mathcal{Y}} P(y) P(x|y) \log \frac{1}{P(x|y)} \\ &= \sum_{x \in \mathcal{X}} \sum_{y \in \mathcal{Y}} P(x,y) \log \frac{1}{P(x|y)}. \end{split}$$

Theorem (Conditioning reduces entropy)

For any two random variables X and Y,

$$H(X|Y) \le H(X)$$
.

with equality if and only if X and Y are statistically independent.

Definition (Joint Entropy)

The joint entropy of X and Y is defined as

$$H(X,Y) =$$

Definition (Joint Entropy)

The joint entropy of X and Y is defined as

$$\mathsf{H}(X,Y) = \sum_{x \in \mathcal{X}} \sum_{y \in \mathcal{Y}} P(x,y) \log \frac{1}{P(x,y)}.$$

Definition (Joint Entropy)

The joint entropy of X and Y is defined as

$$\mathsf{H}(X,Y) = \sum_{x \in \mathcal{X}} \sum_{y \in \mathcal{Y}} P(x,y) \log \frac{1}{P(x,y)}.$$

It gives the uncertainty of the overall system.

Definition (Joint Entropy)

The joint entropy of X and Y is defined as

$$\mathsf{H}(X,Y) = \sum_{x \in \mathcal{X}} \sum_{y \in \mathcal{Y}} P(x,y) \log \frac{1}{P(x,y)}.$$

It gives the uncertainty of the overall system.

Lemma

The joint entropy of two statistically independent random variables X and Y is

Definition (Joint Entropy)

The joint entropy of X and Y is defined as

$$\mathsf{H}(X,Y) = \sum_{x \in \mathcal{X}} \sum_{y \in \mathcal{Y}} P(x,y) \log \frac{1}{P(x,y)}.$$

It gives the uncertainty of the overall system.

Lemma

The joint entropy of two statistically independent random variables X and Y is

$$\mathsf{H}(X,Y) = \mathsf{H}(X) + \mathsf{H}(Y).$$

For any ${\it useful}$ communication channel, the output Y and the input X are not independent.

For any ${\it useful}$ communication channel, the output Y and the input X are not independent.

Lemma (Chain Rule)

The joint entropy of two random variables X and Y is given by

$$\mathsf{H}(X,Y) =$$

For any ${\it useful}$ communication channel, the output Y and the input X are not independent.

Lemma (Chain Rule)

The joint entropy of two random variables X and Y is given by

$$\mathsf{H}(X,Y) = \mathsf{H}(X) + \mathsf{H}(Y|X).$$

For any useful communication channel, the output Y and the input X are not independent.


Lemma (Chain Rule)


The joint entropy of two random variables \boldsymbol{X} and \boldsymbol{Y} is given by

$$\mathsf{H}(X,Y) = \mathsf{H}(X) + \mathsf{H}(Y|X).$$


Since P(x,y) = P(y,x), we can also write

$$\mathsf{H}(X,Y) = \mathsf{H}(Y) + \mathsf{H}(X|Y).$$






• How much information about the transmitted random variable X we gain from Y?



• How much information about the transmitted random variable X we gain from Y?


Equivalently...



 How much information about the transmitted random variable X we gain from Y?


Equivalently...

How much uncertainty remains on the knowledge of X after receiving Y



 How much information about the transmitted random variable X we gain from Y?

Equivalently...




 How much information about the transmitted random variable X we gain from Y?

Equivalently...

How much uncertainty remains on the knowledge of X after receiving $Y \longrightarrow$ The conditional entropy of X given Y, $\mathsf{H}(X|Y)!$


• How much information have we conveyed over the channel?



 How much information about the transmitted random variable X we gain from Y?

Equivalently...


- How much information have we conveyed over the channel?
 - Before receiving Y: Uncertainty on X is



 How much information about the transmitted random variable X we gain from Y?

Equivalently...


- How much information have we conveyed over the channel?
 - Before receiving Y: Uncertainty on X is H(X)



 How much information about the transmitted random variable X we gain from Y?

Equivalently...


- How much information have we conveyed over the channel?
 - Before receiving Y: Uncertainty on X is H(X)
 - After receiving Y: Uncertainty on X is



 How much information about the transmitted random variable X we gain from Y?

Equivalently...


- How much information have we conveyed over the channel?
 - Before receiving Y: Uncertainty on X is H(X)
 - After receiving Y: Uncertainty on X is H(X|Y)



 How much information about the transmitted random variable X we gain from Y?

Equivalently...

- How much information have we conveyed over the channel?
 - Before receiving Y: Uncertainty on X is H(X)
 - After receiving Y: Uncertainty on X is H(X|Y)
 - Thus, the information conveyed is:



 How much information about the transmitted random variable X we gain from Y?

Equivalently...

- How much information have we conveyed over the channel?
 - Before receiving Y: Uncertainty on X is H(X)
 - After receiving Y: Uncertainty on X is H(X|Y)
 - Thus, the information conveyed is: H(X) H(X|Y)!

Definition (Mutual Information)

The mutual information between X and Y is

$$I(X;Y) \triangleq H(X) - H(X|Y).$$

Definition (Mutual Information)

The mutual information between X and Y is

$$I(X;Y) \triangleq H(X) - H(X|Y).$$

 The mutual information measures the average reduction in uncertainty about X that results from learning the value of Y.

Definition (Mutual Information)

The mutual information between X and Y is

$$I(X;Y) \triangleq H(X) - H(X|Y).$$

 The mutual information measures the average reduction in uncertainty about X that results from learning the value of Y.

By simple manipulation of the entropies,

$$I(X;Y) = \sum_{x \in X} \sum_{y \in Y} P(x,y) \log \frac{P(x,y)}{P(x)P(y)}.$$

Definition (Mutual Information)

The mutual information between X and Y is

$$I(X;Y) \triangleq H(X) - H(X|Y).$$

 The mutual information measures the average reduction in uncertainty about X that results from learning the value of Y.

By simple manipulation of the entropies,

$$I(X;Y) = \sum_{x \in X} \sum_{y \in Y} P(x,y) \log \frac{P(x,y)}{P(x)P(y)}.$$

Properties

Definition (Mutual Information)

The mutual information between X and Y is

$$I(X;Y) \triangleq H(X) - H(X|Y).$$

 The mutual information measures the average reduction in uncertainty about X that results from learning the value of Y.

By simple manipulation of the entropies,

$$I(X;Y) = \sum_{x \in X} \sum_{y \in Y} P(x,y) \log \frac{P(x,y)}{P(x)P(y)}.$$

Properties

P1
$$I(X;Y) \ge 0$$
,

Definition (Mutual Information)

The mutual information between X and Y is

$$I(X;Y) \triangleq H(X) - H(X|Y).$$

 The mutual information measures the average reduction in uncertainty about X that results from learning the value of Y.

By simple manipulation of the entropies,

$$I(X;Y) = \sum_{x \in X} \sum_{y \in Y} P(x,y) \log \frac{P(x,y)}{P(x)P(y)}.$$

Properties

P1
$$I(X;Y) \ge 0$$
,

P2 I(X;Y) = 0 if and only if X and Y are independent,

Definition (Mutual Information)

The mutual information between X and Y is

$$I(X;Y) \triangleq H(X) - H(X|Y).$$

 The mutual information measures the average reduction in uncertainty about X that results from learning the value of Y.

By simple manipulation of the entropies,

$$I(X;Y) = \sum_{x \in X} \sum_{y \in Y} P(x,y) \log \frac{P(x,y)}{P(x)P(y)}.$$

Properties

- P1 $I(X;Y) \ge 0$,
- P2 I(X;Y) = 0 if and only if X and Y are independent,
- P3 I(X;Y) = I(Y;X),

Definition (Mutual Information)

The mutual information between X and Y is

$$I(X;Y) \triangleq H(X) - H(X|Y).$$

 The mutual information measures the average reduction in uncertainty about X that results from learning the value of Y.

By simple manipulation of the entropies,

$$I(X;Y) = \sum_{x \in X} \sum_{y \in Y} P(x,y) \log \frac{P(x,y)}{P(x)P(y)}.$$

Properties

- P1 I(X;Y) > 0,
- P2 I(X;Y) = 0 if and only if X and Y are independent,
- P3 I(X;Y) = I(Y;X),
- P4 $I(X;Y) \leq \min(H(X), H(Y))$.

• How much information can we transmit over the cannel?

- How much information can we transmit over the cannel?
 - No control over the channel.

- How much information can we transmit over the cannel?
 - No control over the channel.
 - However, control over $P_X(x)$.

- How much information can we transmit over the cannel?
 - No control over the channel.
 - However, control over $P_X(x)$.
- The mutual information I(X;Y) depends on $P_X(x)!$.


- How much information can we transmit over the cannel?
 - No control over the channel.
 - However, control over $P_X(x)$.
- The mutual information I(X;Y) depends on $P_X(x)!$.

Definition (Channel Capacity)


For a given channel, the channel capacity is defined to be the maximum of the mutual information, maximized over all possible input distributions $P_X(x)$,

$$\mathsf{C} \triangleq \max_{P_X} \mathsf{I}(X;Y).$$

Running Example: The Binary Symmetric Channel




Running Example: The Binary Symmetric Channel




• Input: $X \in \mathcal{X} = \{0, 1\}.$

Running Example: The Binary Symmetric Channel



- Input: $X \in \mathcal{X} = \{0, 1\}$.
- Output: $Y \in \mathcal{Y} = \{0, 1\}.$

Running Example: The Binary Symmetric Channel



- Input: $X \in \mathcal{X} = \{0, 1\}.$
- Output: $Y \in \mathcal{Y} = \{0, 1\}.$
- Channel defined by the transition probabilities

$$P(0|0) = P(1|1) = 1 - \varepsilon$$

$$P(1|0) = P(0|1) = \varepsilon.$$

Running Example: The Binary Symmetric Channel

• We compute first the mutual information,

I(X;Y)

Running Example: The Binary Symmetric Channel

$$\mathsf{I}(X;Y) = \mathsf{H}(Y) - \mathsf{H}(Y|X)$$

Running Example: The Binary Symmetric Channel

$$\begin{split} \mathsf{I}(X;Y) &= \mathsf{H}(Y) - \mathsf{H}(Y|X) \\ &= \mathsf{H}(Y) - \sum_{x \in \mathcal{X}} P(x) \mathsf{H}(Y|X=x) \end{split}$$

Running Example: The Binary Symmetric Channel

$$\begin{split} \mathsf{I}(X;Y) &= \mathsf{H}(Y) - \mathsf{H}(Y|X) \\ &= \mathsf{H}(Y) - \sum_{x \in \mathcal{X}} P(x) \mathsf{H}(Y|X=x) \\ &= \mathsf{H}(Y) - (P(0)\mathsf{H}(Y|X=0) + P(1)\mathsf{H}(Y|X=1)) \end{split}$$

Running Example: The Binary Symmetric Channel

$$\begin{split} \mathsf{I}(X;Y) &= \mathsf{H}(Y) - \mathsf{H}(Y|X) \\ &= \mathsf{H}(Y) - \sum_{x \in \mathcal{X}} P(x) \mathsf{H}(Y|X = x) \\ &= \mathsf{H}(Y) - (P(0) \mathsf{H}(Y|X = 0) + P(1) \mathsf{H}(Y|X = 1)) \\ &= \mathsf{H}(Y) - \underbrace{(P(0) + P(1))}_{=1} \mathsf{H}_{\mathsf{b}}(\varepsilon) \end{split}$$

Running Example: The Binary Symmetric Channel

$$\begin{split} \mathsf{I}(X;Y) &= \mathsf{H}(Y) - \mathsf{H}(Y|X) \\ &= \mathsf{H}(Y) - \sum_{x \in \mathcal{X}} P(x) \mathsf{H}(Y|X=x) \\ &= \mathsf{H}(Y) - (P(0)\mathsf{H}(Y|X=0) + P(1)\mathsf{H}(Y|X=1)) \\ &= \mathsf{H}(Y) - \underbrace{(P(0) + P(1))}_{=1} \mathsf{H}_{\mathsf{b}}(\varepsilon) \\ &= \mathsf{H}(Y) - \mathsf{H}_{\mathsf{b}}(\varepsilon) \end{split}$$

Running Example: The Binary Symmetric Channel

$$\begin{split} \mathsf{I}(X;Y) &= \mathsf{H}(Y) - \mathsf{H}(Y|X) \\ &= \mathsf{H}(Y) - \sum_{x \in \mathcal{X}} P(x) \mathsf{H}(Y|X = x) \\ &= \mathsf{H}(Y) - (P(0) \mathsf{H}(Y|X = 0) + P(1) \mathsf{H}(Y|X = 1)) \\ &= \mathsf{H}(Y) - \underbrace{(P(0) + P(1))}_{=1} \mathsf{H}_{\mathsf{b}}(\varepsilon) \\ &= \mathsf{H}(Y) - \mathsf{H}_{\mathsf{b}}(\varepsilon) \\ &\leq \end{split}$$

Running Example: The Binary Symmetric Channel

· We compute first the mutual information,

$$\begin{split} \mathsf{I}(X;Y) &= \mathsf{H}(Y) - \mathsf{H}(Y|X) \\ &= \mathsf{H}(Y) - \sum_{x \in \mathcal{X}} P(x) \mathsf{H}(Y|X=x) \\ &= \mathsf{H}(Y) - (P(0)\mathsf{H}(Y|X=0) + P(1)\mathsf{H}(Y|X=1)) \\ &= \mathsf{H}(Y) - \underbrace{(P(0) + P(1))}_{=1} \mathsf{H}_{\mathsf{b}}(\varepsilon) \\ &= \mathsf{H}(Y) - \mathsf{H}_{\mathsf{b}}(\varepsilon) \\ &\leq 1 - \mathsf{H}_{\mathsf{b}}(\varepsilon). \end{split}$$

Running Example: The Binary Symmetric Channel

• We compute first the mutual information,

$$\begin{split} \mathsf{I}(X;Y) &= \mathsf{H}(Y) - \mathsf{H}(Y|X) \\ &= \mathsf{H}(Y) - \sum_{x \in \mathcal{X}} P(x) \mathsf{H}(Y|X = x) \\ &= \mathsf{H}(Y) - (P(0)\mathsf{H}(Y|X = 0) + P(1)\mathsf{H}(Y|X = 1)) \\ &= \mathsf{H}(Y) - \underbrace{(P(0) + P(1))}_{=1} \mathsf{H}_{\mathsf{b}}(\varepsilon) \\ &= \mathsf{H}(Y) - \mathsf{H}_{\mathsf{b}}(\varepsilon) \\ &\leq 1 - \mathsf{H}_{\mathsf{b}}(\varepsilon). \end{split}$$

I(X;Y) depends on P_Y , thus on P_X !

Running Example: The Binary Symmetric Channel

$$I(X;Y) = H(Y) - H_b(\varepsilon)$$


• Let $P(X=0) = \delta$ and $P(X=1) = 1 - \delta$.

$$I(X;Y) = H(Y) - H_b(\varepsilon)$$

- Let $P(X = 0) = \delta$ and $P(X = 1) = 1 \delta$.
- The mutual information is maximized for


$$I(X;Y) = H(Y) - H_b(\varepsilon) \le 1 - H_b(\varepsilon).$$

- Let $P(X = 0) = \delta$ and $P(X = 1) = 1 \delta$.
- The mutual information is maximized for $\delta=\frac{1}{2}$ (equally likely symbols)




$$I(X;Y) = H(Y) - H_b(\varepsilon) \le 1 - H_b(\varepsilon).$$

- Let $P(X = 0) = \delta$ and $P(X = 1) = 1 \delta$.
- The mutual information is maximized for $\delta = \frac{1}{2}$ (equally likely symbols)



$$I(X;Y) = H(Y) - H_b(\varepsilon) \le 1 - H_b(\varepsilon).$$

- Let $P(X = 0) = \delta$ and $P(X = 1) = 1 \delta$.
- The mutual information is maximized for $\delta=\frac{1}{2}$ (equally likely symbols)
- The maximum of the mutual information is the channel capacity,




$$I(X;Y) = H(Y) - H_b(\varepsilon) \le 1 - H_b(\varepsilon).$$


- Let $P(X = 0) = \delta$ and $P(X = 1) = 1 \delta$.
- The mutual information is maximized for $\delta=\frac{1}{2}$ (equally likely symbols)
- The maximum of the mutual information is the channel capacity,

$$C_{BSC} = 1 - H_b(\varepsilon)$$
 bits.

$$C_{BSC} = 1 - H_b(\varepsilon)$$
 bits.




$$C_{BSC} = 1 - H_b(\varepsilon)$$
 bits.



Running Example: The Binary Symmetric Channel

$$C_{BSC} = 1 - H_b(\varepsilon)$$
 bits.

• It is maximum (1 bit) for $\varepsilon = 0$ and $\varepsilon = 1$.



$$\mathsf{C}_{\mathsf{BSC}} = 1 - \mathsf{H}_{\mathsf{b}}(\varepsilon)$$
 bits.

- It is maximum (1 bit) for $\varepsilon = 0$ and $\varepsilon = 1$.
- It is zero for $\varepsilon = \frac{1}{2}$ The channel is useless!

Definition (Channel Capacity)

For a given channel, the channel capacity is defined to be the maximum of mutual information, maximized over all possible input distributions P(x),

$$\mathsf{C} \triangleq \max_{P_X(x)} \mathsf{I}(X;Y).$$

Definition (Channel Capacity)

For a given channel, the channel capacity is defined to be the maximum of mutual information, maximized over all possible input distributions P(x),

$$\mathsf{C} \triangleq \max_{P_X(x)} \mathsf{I}(X;Y).$$

 The channel capacity is a measure of the information conveyed by a channel, but...

Definition (Channel Capacity)

For a given channel, the channel capacity is defined to be the maximum of mutual information, maximized over all possible input distributions P(x),

$$\mathsf{C} \triangleq \max_{P_X(x)} \mathsf{I}(X;Y).$$

 The channel capacity is a measure of the information conveyed by a channel, but... What is its operational meaning?

The channel capacity is the maximum transmission rate at which we can communicate reliably over the channel!

The channel capacity is the maximum transmission rate at which we can communicate reliably over the channel!

Theorem (Shannon's Channel Coding Theorem)

For a discrete-time channel, it is possible to transmit information with an arbitrarily small probability of error if the communication rate R is below the channel capacity, i.e., R < C. More precisely, for any $R \le C$, there exist a sequence of coding schemes of length N with average error probability $P_{\rm e}^{(N)}$ that tends to zero as $N \to \infty$, i.e., $P_{\rm e}^{(N)} \to 0$ as $N \to \infty$. Conversely, any sequence of coding schemes with vanishing error probability must have $R \le C$. Hence, the probability of error for transmission above capacity is bounded above zero.

The channel capacity is the maximum transmission rate at which we can communicate reliably over the channel!

Theorem (Shannon's Channel Coding Theorem)

For a discrete-time channel, it is possible to transmit information with an arbitrarily small probability of error if the communication rate R is below the channel capacity, i.e., R < C. More precisely, for any $R \le C$, there exist a sequence of coding schemes of length N with average error probability $P_{\rm e}^{(N)}$ that tends to zero as $N \to \infty$, i.e., $P_{\rm e}^{(N)} \to 0$ as $N \to \infty$. Conversely, any sequence of coding schemes with vanishing error probability must have $R \le C$. Hence, the probability of error for transmission above capacity is bounded above zero.

For
$$\varepsilon=0.25$$
, $\mathsf{C}_{\mathsf{BSC}}=1-\mathsf{H}_{\mathsf{b}}(\varepsilon)=1-\mathsf{H}_{\mathsf{b}}(0.25)=0.1887$

The channel capacity is the maximum transmission rate at which we can communicate reliably over the channel!

Theorem (Shannon's Channel Coding Theorem)

For a discrete-time channel, it is possible to transmit information with an arbitrarily small probability of error if the communication rate R is below the channel capacity, i.e., $R < \mathsf{C}$. More precisely, for any $R \le \mathsf{C}$, there exist a sequence of coding schemes of length N with average error probability $P_{\mathsf{e}}^{(N)}$ that tends to zero as $N \to \infty$, i.e., $P_{\mathsf{e}}^{(N)} \to 0$ as $N \to \infty$. Conversely, any sequence of coding schemes with vanishing error probability must have $R \le C$. Hence, the probability of error for transmission above capacity is bounded above zero.

Running Example: The Binary Symmetric Channel

For $\varepsilon=0.25$, $\mathsf{C}_{\mathsf{BSC}}=1-\mathsf{H}_{\mathsf{b}}(\varepsilon)=1-\mathsf{H}_{\mathsf{b}}(0.25)=0.1887\longrightarrow \mathsf{Reliable}$ communication is possible as long as we transmit at a rate <0.1887 bits per channel use.

Communication Over the AWGN Channel

Additive White Gaussian Noise (AWGN) Channel

Continuous-time, complex AWGN channel,

$$y(t) = x(t) + n(t),$$

where x(t) is bandlimited with bandwidth W and has signal power P, the symbol interval is T=1/W, and n(t) is complex AWGN with PSD N_{0} and

$$\mathsf{SNR} \triangleq \frac{P}{\mathsf{N}_0 W}.$$

Additive White Gaussian Noise (AWGN) Channel

Continuous-time, complex AWGN channel,

$$y(t) = x(t) + n(t),$$

where x(t) is bandlimited with bandwidth W and has signal power P, the symbol interval is T=1/W, and n(t) is complex AWGN with PSD N_0 and

$$\mathsf{SNR}\triangleq\frac{P}{\mathsf{N}_0W}.$$

Discrete-time AWGN channel.

$$y = x + n$$

where $x=(x_1,x_2,\ldots)$ is the transmitted sequence of constellation symbols with average energy per symbol E_s , and n is a sequence of i.i.d. Gaussian noise random variables with zero mean and variance $\sigma^2=N_0/2$ per real dimension.





• Input of the channel X is distributed according to to $p(x) = p_X(x)$.



- Input of the channel X is distributed according to to $p(x) = p_X(x)$.
- Channel law (conditional PDF):

$$p(y|x) = p_{Y|X}(y|x) = \frac{1}{2\pi\sigma^2}e^{-\frac{|y-x|^2}{2\sigma^2}}.$$



- Input of the channel X is distributed according to to $p(x) = p_X(x)$.
- Channel law (conditional PDF):

$$p(y|x) = p_{Y|X}(y|x) = \frac{1}{2\pi\sigma^2} e^{-\frac{|y-x|^2}{2\sigma^2}}.$$

• Signal-to-noise ratio:

$$\mathsf{SNR} \triangleq \frac{\mathsf{E_s}}{\mathsf{N_0}} = \frac{\mathsf{E_s}}{2\sigma^2}.$$





 For a given p_X, the amount of information that can be conveyed over the channel is given by the mutual information

$$I(X;Y) = \iint p(x,y) \log \frac{p(x,y)}{p(x)p(y)} dx dy,$$



 For a given p_X, the amount of information that can be conveyed over the channel is given by the mutual information

$$I(X;Y) = \iint p(x,y) \log \frac{p(x,y)}{p(x)p(y)} dx dy,$$

If X is a discrete RV,

$$I(X;Y) = \sum_{x \in X} \int P(x)p(y|x) \log \frac{p(x,y)}{P(x)p(y)} dy,$$



 For a given p_X, the amount of information that can be conveyed over the channel is given by the mutual information

$$\mathsf{I}(X;Y) = \iint p(x,y) \log \frac{p(x,y)}{p(x)p(y)} dx dy,$$

If X is a discrete RV.

$$I(X;Y) = \sum_{x \in X} \int P(x)p(y|x) \log \frac{p(x,y)}{P(x)p(y)} dy,$$

 The ultimate limit at which we can transmit reliably is given by the channel capacity,

$$\mathsf{C} \triangleq \max_{p_X} \mathsf{I}(X;Y).$$

Capacity of the Discrete-Time AWGN Channel

The channel capacity of the discrete-time complex AWGN channel with average energy per symbol E_s , noise variance $\sigma^2=N_0/2$ per dimension, and $SNR=\frac{E_s}{2\sigma^2}$ is

$$C_{AWGN-D} = \log(1 + SNR)$$
 [bits/channel use] or [bits/symbol],

and is achieved by a Gaussian input distribution, i.e., $X \sim \mathcal{CN}(0, \mathsf{E_s}).$

Capacity of the Discrete-Time AWGN Channel

The channel capacity of the discrete-time complex AWGN channel with average energy per symbol E_s , noise variance $\sigma^2=N_0/2$ per dimension, and $SNR=\frac{E_s}{2\sigma^2}$ is

$$C_{AWGN-D} = \log (1 + SNR)$$
 [bits/channel use] or [bits/symbol],

and is achieved by a Gaussian input distribution, i.e., $X \sim \mathcal{CN}(0, \mathsf{E_s})$.

Capacity of the Continuous-Time AWGN Channel

The channel capacity of the continuous-time AWGN channel of bandwidth \boldsymbol{W} is

$$C_{AWGN-C} = W \log (1 + SNR)$$
 [bits/s],

where the SNR =
$$\frac{P}{N_0W}$$
.

Capacity of the Discrete-Time AWGN Channel

The channel capacity of the discrete-time complex AWGN channel with average energy per symbol E_s, noise variance $\sigma^2=N_0/2$ per dimension, and SNR = $\frac{E_s}{2\sigma^2}$ is

$$C_{AWGN-D} = \log (1 + SNR)$$
 [bits/channel use] or [bits/symbol],

and is achieved by a Gaussian input distribution, i.e., $X \sim \mathcal{CN}(0, \mathsf{E_s})$.

Capacity of the Continuous-Time AWGN Channel

The channel capacity of the continuous-time AWGN channel of bandwidth \boldsymbol{W} is

$$C_{AWGN-C} = W \log (1 + SNR)$$
 [bits/s],

where the SNR = $\frac{P}{N_0W}$.

The capacity C_{AWGN-C} depends on only two parameters, the channel bandwidth W and the SNR.

Capacity of the Discrete-Time AWGN Channel

The channel capacity of the discrete-time real AWGN channel with average energy per symbol E_s, noise variance $\sigma^2=N_0/2$, and SNR = $\frac{E_s}{\sigma^2}$ is

$$C_{AWGN-D} = \frac{1}{2} \log (1 + SNR)$$
 [bits/channel use] or [bits/symbol],

and is achieved by a Gaussian input distribution, i.e., $X \sim \mathcal{N}(0, \mathsf{E_s})$.

The Channel Coding Theorem for the AWGN Channel

Theorem (Channel Coding Theorem, Discrete-Time Channel)

All rates R below $\mathsf{C}_{\mathsf{AWGN-D}}$ are achievable, i.e., for every $R < \mathsf{C}_{\mathsf{AWGN-D}}$ there exists a sequence of coding schemes with vanishing error probability $P_{\mathsf{e}}^{(N)} \to 0$ as the block length $N \to \infty$. Conversely, any sequence of coding schemes of rate R and block length N with error probability $P_e^N \to 0$ must have a rate $R < \mathsf{C}_{\mathsf{AWGN-D}}$.

The Channel Coding Theorem for the AWGN Channel

Theorem (Channel Coding Theorem, Discrete-Time Channel)

All rates R below $\mathsf{C}_{\mathsf{AWGN-D}}$ are achievable, i.e., for every $R < \mathsf{C}_{\mathsf{AWGN-D}}$ there exists a sequence of coding schemes with vanishing error probability $P_{\mathsf{e}}^{(N)} \to 0$ as the block length $N \to \infty$. Conversely, any sequence of coding schemes of rate R and block length N with error probability $P_e^N \to 0$ must have a rate $R < \mathsf{C}_{\mathsf{AWGN-D}}$.

What the Theorem Tells Us: Achievable Rates

Arbitrarily reliable transmission can be achieved on the discrete-time channel at any rate $R < \mathsf{C}_{\mathsf{AWGN-D}}$ if codes of large length are used.

The Channel Coding Theorem for the AWGN Channel

Theorem (Channel Coding Theorem, Discrete-Time Channel)

All rates R below $\mathsf{C}_{\mathsf{AWGN-D}}$ are achievable, i.e., for every $R < \mathsf{C}_{\mathsf{AWGN-D}}$ there exists a sequence of coding schemes with vanishing error probability $P_{\mathsf{e}}^{(N)} \to 0$ as the block length $N \to \infty$. Conversely, any sequence of coding schemes of rate R and block length N with error probability $P_e^N \to 0$ must have a rate $R < \mathsf{C}_{\mathsf{AWGN-D}}$.

What the Theorem Tells Us: Achievable Rates

Arbitrarily reliable transmission can be achieved on the discrete-time channel at any rate $R < \mathsf{C}_{\mathsf{AWGN-D}}$ if codes of large length are used. \longrightarrow Rate R is achievable.

The Channel Coding Theorem for the AWGN Channel

Theorem (Channel Coding Theorem, Discrete-Time Channel)


All rates R below $\mathsf{C}_{\mathsf{AWGN-D}}$ are achievable, i.e., for every $R < \mathsf{C}_{\mathsf{AWGN-D}}$ there exists a sequence of coding schemes with vanishing error probability $P_{\mathsf{e}}^{(N)} \to 0$ as the block length $N \to \infty$. Conversely, any sequence of coding schemes of rate R and block length N with error probability $P_e^N \to 0$ must have a rate $R < \mathsf{C}_{\mathsf{AWGN-D}}$.

What the Theorem Tells Us: Achievable Rates


Arbitrarily reliable transmission can be achieved on the discrete-time channel at any rate $R < \mathsf{C}_{\mathsf{AWGN-D}}$ if codes of large length are used. \longrightarrow Rate R is achievable.

For the Continuous-Time Channel...


Reliable transmission can be achieved on the continuous-time channel at any bit rate $R_{\rm b}$ [bits/second] ($R_{\rm b}=R/T$) such that $R_{\rm b}<{\sf C}_{\sf AWGN-C}$.




• To support spectral efficiency R, we must have $\mathsf{SNR} > 2^R - 1$



• To support spectral efficiency R, we must have $\mathsf{SNR} > 2^R - 1$



• To support spectral efficiency R, we must have $\mathsf{SNR} > 2^R - 1$



- \bullet To support spectral efficiency R, we must have $\mathsf{SNR} > 2^R 1$
- The capacity behaves quite differently in the two regimes

Power-Limited and Bandwidth-Limited Regimes

Power-Limited and Bandwidth-Limited Channels

Ideal band-limited AWGN channels may be classified as bandwidth-limited (SNR \gg 1) or power-limited (SNR \ll 1) according to whether they permit transmission at high spectral efficiencies or not.

Power-Limited Regime, SNR $\ll 1$ (While W Can Grow Very Large)

We can approximate channel capacity as

$$\mathsf{C}_{\mathsf{AWGN-D}} = \log(1 + \mathsf{SNR})$$

Power-Limited Regime, SNR $\ll 1$ (While W Can Grow Very Large)

We can approximate channel capacity as

$$C_{AWGN-D} = \log(1 + SNR) \approx$$

Power-Limited Regime, SNR $\ll 1$ (While W Can Grow Very Large)

We can approximate channel capacity as

$$C_{AWGN-D} = \log(1 + SNR) \approx \frac{1}{\ln 2} SNR,$$

Power-Limited Regime, SNR $\ll 1$ (While W Can Grow Very Large)

We can approximate channel capacity as

$$C_{AWGN-D} = \log(1 + SNR) \approx \frac{1}{\ln 2} SNR,$$

i.e., C_{AWGN-D} increases linearly with SNR.

Power-Limited Regime, SNR $\ll 1$ (While W Can Grow Very Large)

We can approximate channel capacity as


$$C_{AWGN-D} = \log(1 + SNR) \approx \frac{1}{\ln 2} SNR,$$

i.e., C_{AWGN-D} increases linearly with SNR.

In the Power-Limited Regime

Doubling the SNR doubles the capacity.

Capacity Curve



• For low SNR the gain is linear.

Bandwidth-Limited Regime, SNR $\gg 1$

When the SNR is large, we have

$$\mathsf{C}_{\mathsf{AWGN-D}} = \log(1 + \mathsf{SNR})$$

Bandwidth-Limited Regime, SNR $\gg 1$

When the SNR is large, we have

$$C_{AWGN-D} = \log(1 + SNR)$$
$$\approx \log SNR,$$

Bandwidth-Limited Regime, SNR>>> 1

When the SNR is large, we have

$$C_{AWGN-D} = \log(1 + SNR)$$
$$\approx \log SNR,$$

i.e., C_{AWGN-D} increases logarithmically with SNR.

Bandwidth-Limited Regime, SNR>>> 1

When the SNR is large, we have


$$C_{AWGN-D} = \log(1 + SNR)$$
$$\approx \log SNR,$$

i.e., C_{AWGN-D} increases logarithmically with SNR.

In the Bandwidth-Limited Regime


 Doubling the SNR (every additional 3 dB in SNR) yields an increase in achievable spectral efficiency of only 1 (bit/s)/Hz.


Capacity Curve




- For low SNR the gain is linear.
- For high SNR the gain is only logarithmic.








ullet A binary channel encoder maps information bits u to binary codewords c



- ullet A binary channel encoder maps information bits u to binary codewords c
- A symbol mapper Φ maps the binary codewords to a sequence of complex symbols $\boldsymbol{x}=(x_1,x_2,\ldots,x_N)$



- ullet A binary channel encoder maps information bits u to binary codewords c
- A symbol mapper Φ maps the binary codewords to a sequence of complex symbols $x=(x_1,x_2,\ldots,x_N)$
- Each symbol x_i takes on values in $\mathcal{X} = \{\mathsf{X}_1, \mathsf{X}_2, \dots, \mathsf{X}_M\} \subset \mathbb{C}$ according to $P_X(x_i)$
- Example: M-QAM constellations with $P_X(x) = 1/M$ for all $x \in \mathcal{X}$



- ullet A binary channel encoder maps information bits u to binary codewords c
- A symbol mapper Φ maps the binary codewords to a sequence of complex symbols $x=(x_1,x_2,\ldots,x_N)$
- Each symbol x_i takes on values in $\mathcal{X} = \{\mathsf{X}_1, \mathsf{X}_2, \dots, \mathsf{X}_M\} \subset \mathbb{C}$ according to $P_X(x_i)$
- Example: M-QAM constellations with $P_X(x) = 1/M$ for all $x \in \mathcal{X}$





- ullet A binary channel encoder maps information bits u to binary codewords c
- A symbol mapper Φ maps the binary codewords to a sequence of complex symbols $x=(x_1,x_2,\ldots,x_N)$
- Each symbol x_i takes on values in $\mathcal{X} = \{\mathsf{X}_1,\mathsf{X}_2,\ldots,\mathsf{X}_M\} \subset \mathbb{C}$ according to $P_X(x_i)$
- Example: M-QAM constellations with $P_X(x) = 1/M$ for all $x \in \mathcal{X}$
- At the receiver, apply appropriate "inverse" operations: demapper Φ^{-1} and channel decoder





- ullet A binary channel encoder maps information bits u to binary codewords c
- A symbol mapper Φ maps the binary codewords to a sequence of complex symbols $x=(x_1,x_2,\ldots,x_N)$
- Each symbol x_i takes on values in $\mathcal{X} = \{\mathsf{X}_1, \mathsf{X}_2, \dots, \mathsf{X}_M\} \subset \mathbb{C}$ according to $P_X(x_i)$
- Example: M-QAM constellations with $P_X(x) = 1/M$ for all $x \in \mathcal{X}$
- At the receiver, apply appropriate "inverse" operations: demapper Φ^{-1} and channel decoder


How much do we loose by restricting ourselves to M-QAM?























- Bandwidth-Limited: We need to use higher-order QAM constellations
- There is a gap between the mutual information curves and the capacity.

Power Efficiency and Energy per Information Bit



• To compare coded communication systems we consider the ratio

$$\frac{E_b}{N_0}$$

where E_b is the energy per information bit. E_b/N_0 is referred to as the power efficiency.

Power Efficiency and Energy per Information Bit



To compare coded communication systems we consider the ratio

$$\frac{E_b}{N_0}$$
,

where E_b is the energy per information bit. E_b/N_0 is referred to as the power efficiency.

ullet For a coded system that encodes sequences $m{u}$ of K bits onto sequences $m{x}$ of N symbols with average energy per symbol $\mathbf{E_s}$. Then,

$$E_b =$$

Power Efficiency and Energy per Information Bit



• To compare coded communication systems we consider the ratio

$$\frac{E_b}{N_0}$$

where E_b is the energy per information bit. E_b/N_0 is referred to as the power efficiency.

• For a coded system that encodes sequences ${\pmb u}$ of K bits onto sequences ${\pmb x}$ of N symbols with average energy per symbol ${\sf E_s}$. Then,

$$\mathsf{E_b} = \frac{\mathsf{E_s}}{R}.$$

Power Efficiency and Energy per Information Bit



• To compare coded communication systems we consider the ratio

$$\frac{E_b}{N_0}$$
,

where E_b is the energy per information bit. E_b/N_0 is referred to as the power efficiency.

• For a coded system that encodes sequences u of K bits onto sequences x of N symbols with average energy per symbol E_s . Then,

$$\mathsf{E}_\mathsf{b} = \frac{\mathsf{E}_\mathsf{s}}{R}.$$

• SNR = $\frac{E_s}{N_0} = R \frac{E_b}{N_0}$.

Communication is reliable if

 $R < \mathsf{C}_{\mathsf{AWGN-D}}$

Communication is reliable if

$$\begin{aligned} R &< \mathsf{C}_{\mathsf{AWGN-D}} \\ &= \log \left(1 + \frac{\mathsf{E}_{\mathsf{s}}}{2\sigma^2} \right) \end{aligned}$$

Communication is reliable if

$$\begin{split} R &< \mathsf{C}_{\mathsf{AWGN-D}} \\ &= \log \left(1 + \frac{\mathsf{E_s}}{2\sigma^2} \right) \\ &= \log \left(1 + R \frac{\mathsf{E_b}}{2\sigma^2} \right) \end{split}$$

Communication is reliable if

$$\begin{split} R &< \mathsf{C}_{\mathsf{AWGN-D}} \\ &= \log \left(1 + \frac{\mathsf{E}_{\mathsf{s}}}{2\sigma^2} \right) \\ &= \log \left(1 + R \frac{\mathsf{E}_{\mathsf{b}}}{2\sigma^2} \right) \\ &= \log \left(1 + R \frac{\mathsf{E}_{\mathsf{b}}}{\mathsf{N}_{\mathsf{0}}} \right). \end{split}$$

Communication is reliable if

$$\begin{split} R &< \mathsf{C}_{\mathsf{AWGN-D}} \\ &= \log \left(1 + \frac{\mathsf{E_s}}{2\sigma^2} \right) \\ &= \log \left(1 + R \frac{\mathsf{E_b}}{2\sigma^2} \right) \\ &= \log \left(1 + R \frac{\mathsf{E_b}}{\mathsf{N_0}} \right). \end{split}$$

For reliable transmission, the minimum E_b/N_0 to support a rate R is

$$\frac{\mathsf{E_b}}{\mathsf{N_0}} > \frac{2^R - 1}{R}.$$

Communication is reliable if

$$\begin{split} R &< \mathsf{C}_{\mathsf{AWGN-D}} \\ &= \log \left(1 + \frac{\mathsf{E_s}}{2\sigma^2} \right) \\ &= \log \left(1 + R \frac{\mathsf{E_b}}{2\sigma^2} \right) \\ &= \log \left(1 + R \frac{\mathsf{E_b}}{\mathsf{N_0}} \right). \end{split}$$

For reliable transmission, the minimum E_b/N_0 to support a rate R is

$$\frac{\mathsf{E}_\mathsf{b}}{\mathsf{N}_\mathsf{0}} > \frac{2^R - 1}{R}.$$

Using,
$$\lim_{R\to 0}\frac{2^R-1}{R}=\ln 2$$
,
$$\mathsf{E_b/N_0}>\ln 2=-1.59~\mathrm{dB},$$

Communication is reliable if


$$\begin{split} R &< \mathsf{C}_{\mathsf{AWGN-D}} \\ &= \log \left(1 + \frac{\mathsf{E}_\mathsf{s}}{2\sigma^2} \right) \\ &= \log \left(1 + R \frac{\mathsf{E}_\mathsf{b}}{2\sigma^2} \right) \\ &= \log \left(1 + R \frac{\mathsf{E}_\mathsf{b}}{\mathsf{N}_\mathsf{0}} \right). \end{split}$$


For reliable transmission, the minimum E_b/N_0 to support a rate R is

$$\frac{\mathsf{E}_\mathsf{b}}{\mathsf{N}_\mathsf{0}} > \frac{2^R - 1}{R}.$$


Using,
$$\lim_{R\to 0} \frac{2^R - 1}{R} = \ln 2$$
, $\mathsf{E}_\mathsf{h}/\mathsf{N}_\mathsf{0} > \ln 2 = -1.59 \; \mathrm{dB}$.

i.e., it is not possible to transmit reliably over the AWGN channel at E_b/N_0 smaller than $-1.59~\mathrm{dB}$, even when we let $R \to 0!$.







ullet All rates R below the red curve are achievable.




- All rates R below the red curve are achievable.
- For a given R, all values of E_b/N₀ in the right of the red curve are achievable.




- All rates R below the red curve are achievable.
- For a given R, all values of E_b/N₀ in the right of the red curve are achievable.
- R is usually referred to as spectral efficiency, since determines how efficiently we use the spectrum $(R = R_b T = R_b/W)$.




- All rates R below the red curve are achievable.
- For a given R, all values of E_b/N₀ in the right of the red curve are achievable.
- R is usually referred to as spectral efficiency, since determines how efficiently we use the spectrum $(R = R_bT = R_b/W)$.
- Uncoded transmission performs far away from the theoretical limit.






A fundamental tradeoff between power and bandwidth



A fundamental tradeoff between power and bandwidth

• The required E_b/N_0 increases with increasing R, while increasing R decreases the required bandwidth to support the same information rate R_b .



A fundamental tradeoff between power and bandwidth

- The required E_b/N₀ increases with increasing R, while increasing R decreases the required bandwidth to support the same information rate R_b.
- Decreasing R requires less E_b/N₀, but higher bandwidth to support the same R_b.