















MODE[1:0] = 00 ==> 13MHz REFCLK

MODE[3:2] = BOOT\_SEL

MODE[4] = 0 ==> RESERVED TIE LOW

BOOT\_SEL = 0 ==> DON'T BOOT (USE JTAG INSTEAD)

BOOT\_SEL = 1 ==> BOOT FROM SPI FLASH

<b>X</b> MOS <sup>™</sup>			
Copyright (c) 2009 XMOS Ltd.			
PROJECT NAME			
EXAMPLE			
SIZE	SHEET NAME		REV
<b>A2</b>	L2_124QFN		1V0
DATE	9-26-2008_17:44	SHEET 1	OF 1