NEW USERS READ FIRST:	_ ouou motal	lir	nked in the FORSo	an Training section	structions' tab below. When FORScan is completely installed and setup, review the tutorial document on BEFORE making any changes. Don't forget to backup your modules first!		
Feature Name	Module	Key Position	Default Value (Ignore if different on your truck)	New Value	Notes	FTE Member	Status
TPMS (Tire Pressure Monitoring System) thresholds	BdyCM as built	726-40-01	xxxx 3C50 xxxx	xxxx 3C41 xxxx	3C41 indicates 60 psi front 65 psi rear. First two digits are front, second two are rear. Replace either of those two values with the desired PSI has equivalent. (28=40 PSI, 2d=45 PSI, 32=50 PSI, 37=55 PSI, 3C=60 PSI, 41=65 PSI, 46=70 PSI, 50=80 PSI)	switch.	Multiple Confirmations
Double Horn Honk Disable	BdyCM as built	726-41-02	xxx1 xxxx xxxx	xxxx xxxx 0	This disables the double honk when walking away from truck with engine running and key fob in pocket. Recommended to implement the Secure Idle (Police Mode) feature to prevent unauthorized driving away without the key fob.	switch.	Multiple Confirmations
og Lights with High Beam LED and some HALOGEN	BdyCM as built	726-27-01	xxxx xxx1 xxxx	xxxx xxxx0 xxxx	This allows LED fog lights to stay on when high beams are also turned on. This code has been confirmed to work with some halogen headight trucks also. Also known as Bambi mode (to see deer better).		Multiple Confirmations
og Lights with High Beam FALOGEN	BdyCM as built	726-27-01	x0xx xxxx xxxx	x1xx xxxx xxxx	This allows Halogen fog lights to stay on when high beams are also turned on. Also known as Bambi mode (to see deer better).	KubotaOrange76	Multiple Confirmations
Show Temps on Gauges	IPC	720-07-01	xxxx xEA xxxx	xxxx x**x xxxx	Display exact termperatures above the gauge on the center cluster. Replace ** with E5 with brake controller, 65 if no brake controller. A5 adds temps above gauges without adding boost gauge and boost data to menus.		Multiple Confirmations
Heated and Cooled Seats Icons on Home and Climate Screens	APIM	7D0-01-01	XXXX XXXX X4XX	XXXX XXXX X*XX	1 = Cooled seats option on screen, no heated seats or heated wheel option. 2 = Heated/cooled seats option on screen with no heated wheel option. 3 = Heated seats on screen, no cooled seats and no heated wheel option. 4 = No on screen heated/cooled seats on any screen, heated wheel is in top left. 5 = Unknown 6 = Heated/Cooled seats and heated wheel options on screen. 7 = Heated seats and heated wheel, no cooled seats. 8 = Rear Climate Control panel, no heated/cooled options for front.		Multiple Confirmations
Fog Light Switches Off w/Blinker	BdyCM as built	726-28-02	xxxx x0xx xxxx	xxxx x1xx xxxx	Confirmed on LED and halogen headlights/fog lights.  0 (Default Operation - Fog Lights Constant), 1 (Fog Lights Switchback w/Blinker)		Multiple Confirmations
Disable Door Lock Horn Honk	BdyCM as built	726-38-02	xxx1 xxxx xxxx	xxxx xxxx 0xxx	1 (Enabled - Default), 0 (Disabled)	AllGoNShow	Multiple Confirmations
Secure Idle (Police Mode)	BdyCM as built	726-42-01	x0xx xxxx xxxx	x1xx xxxx xxxx	Prevents vehicle transmission from shifting out of Park without passive key inside vehicle (Shifter Locked w/No Key Detected message) 0=Disabled 1=Enabled	AllGoNShow	Multiple Confirmations
Remember Fog Lights on Startup	BdyCM as built	726-27-01	xxxx x1xx xxxx	xxxx xxxx0 xxxx	Default value does not remember either high beam or fog light status on key off/on. Headlight switch in Auto position. Restores previous setting only if lights are needed on next startup.	AllGoNShow	Multiple Confirmations
Remember Fog Lights and High Beams on Startup	BdyCM as built	726-27-01	xxxx x1xx xxxx	xxxx xxx0 x1xx	Default value does not remember either high beam or fog light status on key off/on. Headlight switch in	AllGoNShow	Multiple Confirmations
Speedometer Recalibration for Different Tire Size	ВСМ	726-12-01	xxxx xx00 xxxx	xxxx xx4C xxxx	Auto position. Restores previous setting only if lights are needed on next startup.  Forum comment: "Original tire size 275/7018, New size 285/75718. No DTC codes after 900 miles. This is a small change. Larger tire size changes do calibrate the speedometer but a check engine light will persist."	KubotaOrange76	Multiple Confirmations
Sync 3 Boot Screen Animations	APIM	7D0-02-01	xxxx x1xx xxxx	xxxx x7xx xxxx	The following can be used for a slightly larger calibration (approx 2.5%) without CEL: xxxx-0AAE-xxxx  GT350 Boot Screen Animation *Sync 3.0 only	RebelZ	Multiple Confirmations
Sync 3 Boot Screen Animations	APIM	7D0-02-01 7D0-02-01	xxxx x1xx xxxx	xxxx x9xx xxxx	GT350 Boot Screen Animation *Sync 3.0 only	RebelZ	Multiple Confirmations
Sync 3 Boot Screen Animations	APIM	7D0-02-01	xxxx x1xx xxxx	xxxx x5xx xxxx	Raptor SVT Boot Screen Animation *Sync 3.0 only	RebelZ	Multiple Confirmations
Sync 3 Boot Screen Animations	APIM APIM	7D0-02-01	XXXX X1XX XXXX	XXXX X6XX XXXX	Mustang Boot Screen Animation *Sync 3.0 only Lincoln Presidential Boot Screen Animation *Sync 3.0 only	RebelZ RebelZ	Multiple Confirmations Multiple Confirmations
Sync 3 Boot Screen Animations	BCM	7D0-02-01 726-31-02	xxxx x1xx xxxx	xxxx x4xx xxxx xxxx 07xx xxxx	Fixes Incorrect Color Choices When Using Lincoln Theme	RebelZ Livinitup	Single Confirmation
Sync 3 Boot Screen Animations	APIM	7D0-02-01	xxxx x1xx xxxx	xxxx x8xx xxxx	Vignale Boot Screen Animation *Sync 3.0 only	RebelZ	Multiple Confirmations
Sync 3 Boot Screen Animations	APIM	7D0-02-01	xxxx x1xx xxxx	xxxx x5xx xxxx	Raptor Ford Performance Boot Screen Animation *Sync 3.0, Sync 2.2	RebelZ	Multiple Confirmations
Sync 3 Boot Screen Animations	APIM	7D0-02-01	xxxx x1xx xxxx	xxxx xCxx xxxx	RS Boot Screen Animation *Sync 3.0, Sync 2.2	RebelZ	Multiple Confirmations
Sync 3 Boot Screen Animations Sync 3 Boot Screen Animations	APIM APIM	7D0-02-01 7D0-02-01	xxxx x1xx xxxx	xxxx xBxx xxxx xxxx xDxx xxxx	RS Boot Screen Animation *Sync 3.0, Sync 2.2 RS Boot Screen Animation *Sync 3.0, Sync 2.2	RebelZ RebelZ	Multiple Confirmations  Multiple Confirmations
yno o boot ourour / minationo	BCM	726-17-01	0000 0000 0045	0101 0101 014A	The Book editor Franklin Cyric C.S., Cyric E.E.	TODOLE	manple communication
	BCM	726-17-02	0101 0101 014B	0101 0101 014B	Allows front windows to open/close with remote button. To open windows, press the unlock button once on		
Global Window Open/Close	BCM	726-30-01		0101 xxxx xxxx	fob, then press and hold the unlock button again until front windows begin opening. To close windows, press and hold the lock button for approximately 5 seconds and release when windows begin to close.	RebelZ	Multiple Confirmations
Slobal William Openiolose	DDM PDM	740-05-01 741-05-01	9A00 E7 8A00 D8	Dxxx xxxx xxxx  Dxxx xxxx xxxx	Window movement can be interrupted at any time by pressing either the lock or unlock buttons.		
	IPC	720-02-01	3xxx xxxx xxxx	7xxx xxxx xxxx	Adds new menu item under Advanced Settings/Vehicle/Windows to enable Remote Close. Remote Open	KYLongRifle	Multiple Confirmations
Disable Panic Alarm Horn	BCM	726-01-02	xxx0 xxxx xxxx	xxx1 xxxx xxxx	or Close can be enabled and disabled using the checkboxes.  Disables the horn when pressing the panic button on key fob. Lights will still flash.	Livnitup	Single Confirmation
Panic Alarm Button Press Count	BCM	726-37-01	xxxx xxx2 xxxx	XXXX XXX* XXXX	Replace the asterisk with one of the following: 0=Panic alarm button on fob disabled, 1=Panic alarm button	Livnitup	Multiple Confirmations
Enable/Disable Spot Lights	BCM	726-56-01	XXXX X1XX XXXX	xxxx x0xx xxxx	on fob requires 2 presses, 2=Panic alarm button on fob requires single press to activate.		Single Confirmation
Disable Tire Pressure Monitor	BCM	726-08-01	x1xx xxxx xxxx	x0xx xxxx xxxx	1 for enable, 0 for disable	Livnitup Livnitup	Multiple Confirmations
Fimeouts for Heated Steering Wheel	HSWM	714-01-01	*xxx xxxx xxxx	*xxx xxxx xxxx	HSWM is Heated Steering Wheel Module. Replace the asterisk with one of the following: 1=Timeout disabled, 8=5 mins, 9=10 mins, A=12 mins, B=15 mins, C=18 mins, D=20 mins, E=25 mins, F=30 mins	Livnitup	Not confirmed, possible F150 only module
Parking lamps on with low	BCM	726-26-02	x0xx xxxx xxxx	x1xx xxxx xxxx	Enables parking lamps while headlights are on low beam when in DRL (daytime running lights).	Livnitup	Waiting Confirmation
peams for DRL Remove CD Option from Sync	APIM	7D0-04-01	x1xx xxxx xxxx	x0xx xxxx xxxx	Remove the CD player from source in the Sync screen	Livnitup	Multiple Confirmations
Remove Sirius from Sync	APIM	7D0-01-01	*xxx xxxx xxxx	8xxx xxxx xxxx	Removes Sirius as a media source in Sync. If * is A change to 8, if 2 change to 0. Change does not take	Texmudder	Multiple Confirmations
Courtesy Lamps Ramp Down	BCM	726-32-02		XX** XXXX XXXX	effect immediately. Turn truck off, open and shut door, wait 30 seconds and restart.  Courtesy Lamps ramp down duration (seconds converted to hex)	Livnitup	Waiting Confirmation
Courtesy Lamps Ramp Up	BCM	726-32-02		XXXX XX** XXXX	Courtesy Lamps ramp up duration (seconds converted to hex)	Livnitup	Waiting Confirmation
Courtesy Lamps Configuration	BCM	726-31-01		XXXX X*XX XXXX	Courtesy Lamps Cfg: 0=immediate, 1=Theater Dimming	Livnitup	Waiting Confirmation
Puddle Lights Show Time	BCM	726-31-01		XXXX XXXX **XX	Approach (Puddle) Light Show Max Time (seconds converted to hex). When truck unlocked via fob.  Change asterisks to one of the following: 4 4A=30 Gal, 5 07=34 Gal, 5 EA=40 Gal, 7 19=48 Gal, 7 65=50	Livnitup	Waiting Confirmation
Change Fuel Tank Size	IPC	720-03-01	xxx* **xx xxxx	xxx* **xx xxxx	Gal, 8 22=55 Gal (This parameter is programmed to accept 4 digit Liters in this format XXX.x 55gal converts to liters of 208.198L so 208.2L rounded then drop the decimal 2082 decimal to HEX equal 822.)	KYLongRifle	Multiple Confirmations
Passenger Seat Belt Chime Disable	IPC	720-01-01	xxxx xx6x xxxx	xxxx xx2x xxxx	Number 2 in this position disables the chime on the driver seat	jjmcc2	Waiting Confirmation
Passenger Seat Belt Chime Diable	IPC	720-01-01		xxxx xx4x xxxx	Number 4 in this position disables the chime on the passenger seat	jjmcc2	Waiting Confirmation
Disble all Seat Belt Chimes	IPC	720-01-01		xxxx xx0x xxxx	Number 0 in this position disables the chime on the driver and passenger seats. NOTE: Seat belts can be disabled via instructions in the owners manual	jjmcc2	Multiple Confirmations
Autofold/Unfold Mirrors via	DDM DDM	740-03-01 740-12-01		x8xx xx Fxxx or FCxx	Autofold mirrors via unlock/lock on fob. ** Tow mirrors require swapping pins 18 & 19 on mirror connector.		
_ock/Unlock on Fob	PDM	741-03-01		x8xx xx	See link: http://www.f150forum.com/f118/tow-mirrors-auto-fold-mod-pictures-365884/. Fxxx works on trucks with 2 key fobs but FCxx is required if using 3 or 4 key fobs.	hollapm	Multiple Confirmations
	PDM	741-12-01		Fxxx or FCxx			
	DDM DDM	740-03-01 740-12-01		x84x xx Fxxx or FCxx	Autofold mirrors - Lincoln Style (doesn't unfold/fold with unlock/lock on fobrequires opening/closing door).		
Autofold/Unfold Mirrors (Lincoln Style)	PDM	740-12-01		x84x xx	** Tow mirrors require swapping pins 18 & 19 on mirror connector. See link: http://www.f150forum. com/f118/tow-mirrors-auto-fold-mod-pictures-365884/. Fxxx works on trucks with 2 key fobs but FCxx is	hollapm	Multiple Confirmations
	PDM	741-12-01		Fxxx or FCxx	required if using 3 or 4 key fobs.		
Suno 2 Thoma F OT (D)	APIM	7D0-01-02		0xxx xxxx xxxx xxxx xDxx xxxx	Changes the Suns 2 agrees to a CT thoma. Salash to CT	Livinitus	Multiple Confirmation -
Sync 3 Theme - Ford GT (Blue)	AFIN	7D0-02-01 7D0-03-01		XXXX XUXX XXXX	Changes the Sync 3 screens to a GT theme. Splash screen will change to GT.	Livinitup	Multiple Confirmations
ncrease radio on time after ruck shut down	APIM	7D0-01-01	xx2x xxxx xxxx	xx6x xxxx xxxx	This changes the radio power-off delay to 60 minutes after the truck is shut off. Wait for the ingition power to time out and then turn the radio back on with the RADIO power button. Alternatively, after turning off the ignition, open and close any door to disable accessory power. Then press the radio power button to turn		Multiple Confirmations
Add DPF Filter % to screen	IPC	720-07-02	x7xx xxxx	xFxx xxxx	radio back on. It will now stay on for the extended time amount.  This adds the DPF % screen to the Truck information screen. Some trucks will report a camera error after making this modification. To avoid that, make your update according to the following: If your original default value is 0, change to 8, if 1, change to 9, if 2 then A, if 3 then B, if 4 then C, if 5 then D, if 6 then E, if 4 then S, then S and		Multiple Confirmations
Power Point Timeout Disable	всм	726-39-01	xxxx x1xx xxxx	xxxx x0xx xxxx	7 then F (as shown).  Turns off the timeout on the power points in the truck. Battery Monitoring System (BMS) will override unless disabled. This feature has had multiple confirmations but also failed on other trucks. Differences are unknown.  Multiple Confirmations		
	всм	726-39-01	xxxx x1xx xxxx	**** XXXX XXXX	Replace the **** with 3870. Allows power points to remain powered for 4 hours after the vehicle is shut down. After four hours the power points will timeout and stop supplying voltage to plugged in devices. This feature has had multiple confirmations but also failed on other furcks. Differences are unknown.  Single Confirmation		Single Confirmation
Power Point Timeout 4 Hours					Disables battery protection system. Electrical systems will remain on and vehicle batteries can drain		

NEW USERS READ FIRST:	Detailed installation and setup instructions are on the 'Setup instructions' tab below. When FORScan is completely installed and setup, review the tutorial document linked in the FORScan Training section BEFORE making any changes. Don't forget to backup your modules first!						
Daytime Running Lights (DRL)	всм	726-50-01		XXxx	Replace XX with the two digit value of the desired lights to illuminate in DRL mode.  0.1 = DRL Master Disable  0.2 = Low Beams  0.4 = Front Fog Lamps  0.8 = Front Turn Lamps  1.0 = Dedicated DRL Lights (LED Light Bars/Strips) - Enables BCM DRL Outputs  2.0 = High Beams  4.0 = Low Beams  4.0 = Low Beams and Dedicated DRL Lights  1.2 = Lights  1.3 = Lights  1.3 = Lights  1.4 = Lights  1.4 = Lights  1.5 = L	DanMc85 & Livinitup	Single Confirmation
Outer Halo Lights as DRLs	всм	726-26-02 726-50-01		x1xx xxxx xxxx 017F	Outer halo lights as DRLs (no low beam, no turn signals). Confirmed on F150s but waiting confirmation on SDs	Livinitup	Waiting Confirmation
Halogen to LED Headlight Conversion	ВСМ	726-26-02	xxxx xxx1 xxxx	xxxx xxxx0 xxxx	Frequency select configuration: 0 = default for OEM LED; 1 = default for OEM Halogen. Excellent tutorial that goes beyond the instructions provided here: https://www.ford-rucks.com/forums/1517743-complete-how-to-halogen-b	Livinitup & jmeo	Waiting Confirmation
Halogen to LED Rear Turn	BCM	726-27-02		XXXX XXXX X*XX	Rear bulb turn outage config: 1=outage, 0=no outage		
Signal Conversion DESCRIPTION PENDING	BCM	726-28-01		x*xx xxxx xxxx	Rear LED turn outage cfg: 1=outage 0=no outage		
Bluetooth Pairing Name	APIM	7D0-04-01		XXXX XXXX **XX	This changes the device name of the truck when pairing bluetooth devices. Change the asteriscs with: 2D=Raptor, De=F150, DF=520, 01e=750, 1=8MKZ, 02=Foox, 0.5=Fusion, 0.4=C-Max, 0.6=Mustang, 0.8=Escape, 0.9=Esge, 24=Mondeo, 0.8=Explorer, 20=Fiesta, 18=MKC, 2E=Continental, 1C=MKX, 1E=Navigator, 0.C=Expedition.** The above only works in Sync 3 vs. 20 and if you wish to change it you must remove paired phone from Sync 3 & paired name from phone and re-pair.	Livinitup	Waiting Confirmation
Average Speed Display	IPC	720-01-01	2F0F 1064 724D		Adds "Average Speed" menu item to the Trip/Fuel menu.	Livinitup	Multiple Confirmations
Massage Seats Turn Signal Flash Count	SCMG/SCMH	Multiple 724-01-01	XXXX X6XX XX	See link  xxxx x*xx xx	Link to F160 Spreadsheet for all values Replace "with one of the following. 0=f Flash OUC False 1=f Flash OUC True 2=f Flash OUC False 3=f Flash OUC True 4=Z Flashes OUC False 5=Z Flashes OUC True 6=S Flashes OUC False 5=Z Flashes OUC True 8=4 Flashes OUC False 5=4 Flashes OUC True 8=4 Flashes OUC False 5=4 Flashes OUC True C=6 Flashes OUC False 5=5 Flashes OUC True C=6 Flashes OUC False 5=5 Flashes OUC True C=7 Flashes OUC False 5=5 Flashes OUC True On Until Cancelled (OUC) means manually moving the turn signal arm in opposite direction or manually cancelling the turn signal. Two flashes are added automatically when trailer is attached.	Livinitup	Waiting Confirmation  Multiple Confirmations
Switch Steering Wheel Buttons	SCCM	724-01-01	xxxx 0xxx xx	xxxx 8xxx xx	If you like your stereo buttons on the left instead of the right this value will swap button functions from right bank to left bank. Note: This is only for the Up,Down,Right,Left/Center buttons. Not the lower set for cruise control, voice commands, etc. Cluster Crossover Ctg: 0=disable, 8=enable	Livinitup	Waiting Confirmation
Ambient LED Lighting (Door Ajar)	ВСМ	726-31-01		x*xx xxxx xx	Replace * with one of the following: 0=loe Blue (Ford), 1=Orange (Ford), 2=Soft Blue (Ford), 3=Red (Ford), 4=Green (Ford), 5=Blue (Ford), 5=Purple (Ford), 7=White (Lincoln), 8=Amber (Lincoln), 9=Teal (Lincoln), 4=Red (Lincoln), 8=Blue (Lincoln), 6=Unknown, F=Unknown. Note: 5ync 3: Use Lincoln Splash Screen Brand (7D0-01-02 Bxxx xxxx xx), or your APIM so that on screen color selections will match EOM if you use a color greater than or equal to 7.		Single Confirmation
Ambient LED Lighting (Entry)	ВСМ	726-31-02		xxxx x*xx xx	Replace * with one of the following: 0=loc Blue (Ford), 1=Orange (Ford), 2=Soft Blue (Ford), 3=Red (Ford), 4=Creen (Ford), 5=Blue (Ford), 6=Purple (Ford), 7=White (Lincoln), 8=Amber (Lincoln), 9=Teal (Lincoln), 6=Green (Lincoln), 0=Lincoln), 1=Union (Lincoln),		Single Confirmation
Add Hill Descent Control	ABS	760-03-01	x1xx xx	х3хх хх	This feature requires addition of an activation button on the dash. Replace the hazard button with a dual function hazard and HDC enable button part #: HC3Z-13D730-CA. For more information see the following thread: https://www.ford-trucks.com/forums/1503198-forscan-adding-hill-descent-control-to-non-fx4-4x4. html	Mooch91	Single Confirmation
Add TPMS "Specified" to display	IPC	720-04-01		xx*x xxxx xxxx	Replace * with one of the following: 0=TBC Gain disabled & TPMS Specified value disabled 4=TBC Gain enabled & TPMS Specified value disabled 8=TBC Gain disabled & TPMS Specified value enabled C=TBC Gain enabled & TPMS Specified value enabled C=TBC Gain enabled & TPMS Specified value enabled	Livinitup	Multiple Confirmations
Disable Traction Control	IPC	720-01-01		xx2x xxxx xxxx	AdvanceTrac Disabled	Livinitup	Single Confirmation
Enter NAV Destination and viewing texts while vehicle is in motion	APIM	7D0-02-01		5753 xxxx xxxx	Enables entering NAV destination and viewing texts while vehicle is in motion. Sync version must be upgraded to version 2.2 or higher. Instruction for upgrading Sync begin on post 204 Page \$2 of the FORScan spreadsheet. https://www.ford-trucks.com/forums/1460787-forscan-spreadsheet-52.html. Ahem, do we need to say it? This feature should be used by the passenger and the driver should keep their eyes on the road. Be smart and be safe. This feature disables automatic 911 calling if in an accident.	Livinitup	Multiple Confirmations
Disable Door Chime when Door Ajar	iPC	720-01-02	xx1x xxxx xxxx	xx0x xxxx xxxx	Disables door chime when door open and ignition on.	neonovulator	Multiple Confirmations
Disable Key In Ignition Chime	iPC	720-02-01		xx*x xxxx xxxx	This disables chime when key is in the iginition and ignition is off. Subtract 8 from the value in the * position. For example, if C then change to 4. This feature is dependent upon the Disable Door Chime when Door Ajar feature. That must be enabled first for this to work.	neonovulator	Multiple Confirmations
Disable Illuminated Entry/Exit - Dark Car Mode	BCM	726-32-01		xxxx x1xx xxxx	Turns off parking and cargo lights when door is opened.	R1xterGonz0	Single Confirmation
Remote Start Enable/Disable	BCM BCM	726-58-02 726-22-02		xxxx xxxx x1xx xxx* xxxx xxxx	Silent mode. Waiting for better description  Substitute * with one of the following: 0=disabled, 1=enabled	Livinitup	Single Confirmation Waiting Confirmation
	APIM	7D0-01-01		xxxx xxx3 xxxx	Adds climate screen to Sync v3 and above XL and XLT trims. Note: Fan speed control does not work,		
Add Climate Screen for XL/XLT	APIM	7D0-01-02		xxxx x2xx xxxx	remains on the analog dial, Does not add dual climate capabilities, Temp control does not work, remains on the analog dial. What does work- On/Off, AC & Recirculate On/Off, Vent Control - foot, dash, windshield, Some volce commands	Uzumati	Single Confirmation
Ambient Light Sensor Speed	всм	726-26-01		xxx* xxxx xxxx	0=15 seconds delay turning on headlamps when dark, 1=2 seconds delay turning on headlamps when dark	Livinitup	Single Confirmation
Speedometer Calibration for 37 inch Tires	BCM	726-12-01		0163 0ACC xxxx	This update will correct the speedometer to read accurately for the larger tire size. It will however, also set a check engine light (CEL) because of the difference from factory settings. There appears to be no other negative effects other than the CEL.	KubotaOrange76	Single Confirmation
Enable Auto-Regen Checkbox	IPC/PCM	720-07-02	Plain English.	Not HEX.	negative effects other than the CEL.  Enable auto regen in IPC and select option 3 under "DPF manual regeneration" in PCM. (Not as built.)	screwy	Multiple Confirmations

Module Acronym	Module Description	Address Characters	Utility	Web Address	
ABS	Anti-Lock Brake System Module	760	Decimal to Hex Converter:	http://www.asciitohex.com/	
ACM	Audio Front Control Module	727	Math for conversion	http://www.permadi.com/tutorial/numDecToHex/	
APIM	Sync Module	7D0	As Built data by individual VIN	Motorcraft Service AsBuilt Data	
BCM	Body Control Module	726	Owner's manuals and other delivery docs	https://www.motorcraftservice.com/ownerinformation	
	Cruise Control Module	764	Link to F150 FORScan spreadsheet	F150 Features & Modules Mapping	
	Digitial Audio Control Module C	T	FORScan download page	http://www.forscan.org/download.html	
	Front Seat Climate Control Module		FORScan Forum	FORScan Forum	
DDM	Driver Door Module	740	F150 Forum	https://www.f150forum.com/f2/forscan-applications-346877/	
DSP	Audio Digital Signal Processing Module	783	Ford Mustang Forum	http://www.mustang6g.com/forums/showthread.php?t=61773	
FCIM	Front Control Interface Module	7A7	Ford Raptor Forum	http://www.fordraptorforum.com/f260/forscan-changes-tweak-your-truck-52149/	
GWM	Gateway Module A	716	Powerstroke Army Forum	http://powerstrokearmy.com/forums/showthread.php?t=74531&showall=1	
HSWM	Heated Steering Wheel Module	714	F150 Ecoboost Forum	http://www.f150ecoboost.net/forum/6-f150-ecoboost-chat/18362-forscan-ability-change-bcm-build-data-activate.h	html
HUD	Heads Up Display Module	7B2	Fusion Forum	http://www.2gfusions.net/showthread.php?tid=4573	
IPC	Instrument Panel Cluster	720	Sync 3.0 Update with NAV	https://1drv.ms/u/s!AgM4_H5aFPr20m9NrR67iLLwIRIP	
IPMA	Image Processing Module A	706	Sync 3.0 Update without NAV	https://www.transfernow.net/93c957x2pbbt	
IPMB	Image Processing Module B	7B1			
ocs	Occupant Classification System Module				
PAM	Parking Assist Control Module	736			
PCM	Powertrain Control Module	7E0			
PDM	Passenger Door Module	741			
PSCM	Power Steering Control Module				
RBM	Running Board Control Module	766			
RTM	Radio Transceiver Module	751			
SCCM	Steering Column Control Module	724			
SCMG	Driver Multi-Contour Seat Module	712			
SCMH	Passenger Multi-Contour Seat Module	713			
SODL	Side Obstacle Detection Control Module LH	7C4			
SODR	Side Obstacle Detection Control Module RH	7C6			
TBM	Trailer Brake Control Module	757			
TCM	Transmission Control Module	7E1			
TCCM	Transfer Case Control Module	761			
TRM	Trailer Module	791			

Three steps for downloading, installing and activating the FORScan software:	
1. Register on the Forum	http://www.forscan.org/forum/ucp.php?mode=register
<ol> <li>Download and install FORScan for Windows. Must be run on a Microsoft Windows PC or tablet th Bluetooth connectivity. This can be run on an Apple computer if run in Bootcamp mode or Parallels. Hardware ID (found in FORScan software under the steering wheel with a question mark icon).</li> </ol>	
3. Generate the Extended License (free) using the previously copied Hardware ID	http://forscan.org/forum/extlic.php
At this point you are registered on the forum and your copy of the FORScan software is activated.	
Connecting FORScan to the truck:	
The FORScan software connects to the truck's computer modules via a Bluetooth OBDII connector. many connectors available and some work properly and others don't. The following is proven to work Search "OBDLink MX Bluetooth" on Amazon.	
Compatible USB OBDII adapter with manual switch	http://amzn.to/2ziwvPU
Another compatible USB OBDII adapter with manual switch	http://amzn.to/2gOVfsy
The final step is to plug in the adapter into the truck's OBDII port and pair the device with your compinistructions for OBDII device). After pairing, select the OBDII adapter in the FORScan software under gear icon) and the Connection tab. Once selected, press the Vehicle Interface and Information icon (the exclamation point) button and FORScan will begin scanning all available modules. Wait until com you're ready to go.	er Settings (the (the auto with
FORScan Training:	
Extremely helpful tutorial which provides real-word examples as to how to use the software and mak modules. Thanks to Livinitup.	te updates to https://docs.google.com/document/d/1- 8dKaS_Spu4Zw4hV_CrKC4tLoP9G8yejqegF1wxlqxY/edit
Backing Up Modules Before Modifications:	
Note from Livnitup: "Guys, you should backup any module before you make changes. I've seen a lot regretting not doing this down the line. There are modules that Ford doesn't list on the as-built webpt DDM/PDM so if you don't have those backed up and make a mistake you'be S.O.L. trying to get yo values. It only takes a minute to go into each module, click "save all" at the bottom and name it some BCM-original, IPC-original, etc."	age like ur original
Disclaimer:	
This information is provided for enthusiasts who are willing to experiment and test on their personal vis no guarantee that any of these items will work in any particular truck and may have negative or un consequences. If you choose to make any modifications to your truck you do so at your own risk	