

2. TABLE OF CONTENTS

1. ALTERATION LIST	1
2. TABLE OF CONTENTS	4
3. GENERAL	5
4. DIAGNOSTIC COMMUNICATIONS	6
4.1 DIAGNOSTIC INTERFACE PROTOCOLS	6
4.2 ESTABLISHING CCP DIAGNOSTIC COMMUNICATION	6
4.3 BLOCK DOWNLOAD/UPLOAD (WRITING/READING TO/FROM EEPROM)	6
4.4 STOP DTC LOGGING	7
4.5 DOWN-LOADING DEFAULT VALUES TO EEPROM	7
4.6 INITIATE CLEARING DTCs	7
4.7 INITIATE PUTTING BEM INTO PLANT MODE	7
4.8 VERIFYING EEPROM MAP	7
4.9 VERIFYING CAN (Hi & Lo) IN AND CAN (Hi & Lo) OUT	7
5. FIXED FEED, SOURCE & RETURN CHARACTERISTICS	
6. ANALOGUE INPUT VOLTAGES AND CURRENTS	9
6.1 FRONT INTERMITTENT WIPER DWELL POT	9
6.2 CABIN TEMPERATURE SENSOR AND FAN SUPPLY (HIGH SERIES ONLY)	9
6.3 SUNLOAD SENSOR (HIGH SERIES ONLY)	10
7. DIGITAL INPUT VOLTAGES	11
8. OUTPUT VOLTAGES	12
8.1 RELAY CLEANING PROCESS	12
8.2 SWITCHED OUTPUT & SOLID STATE OUTPUT VOLTAGES	12
9. WATCHDOG / RESET TESTS	15
9.1 MUTUAL WATCHDOG - TEMIC TEST	15
9.2 MUTUAL WATCHDOG - MOTOROLA TEST	15
10. QUIESCENT CURRENT	16
11. LOW VOLTAGE RESET	17
12. SOFTWARE	18
12.1 SOFTWARE VERSION NUMBER	18
12.2 BEM VARIANT	18
13. TILA FUNCTIONAL TEST	19
14. RF RECEIVER FUNCTIONAL TEST	20
15. EEPROM MEMORY MAP	23
16. DOCUMENT REFERENCES	24
17. APPENDIX	24
17.1 FIGURE 1A HIGH SERIES TEST CIRCUIT	25
17.2 FIGURE 1B LOW SERIES TEST CIRCUIT	26
17.3 RAM MEMORY MAP	28
17.4 CCP ENCRYPTION ALGORITHM	29
17.5 CALCULATE DST ENCRYPTION KEY	29