

Heat Transfer


Transient heat conduction using numerical methods

Lecturer: Jakob Hærvig

Notation for transient problems

- **On space axis** m, n, k denote node number in x, y, z -directions
 - Distance between nodes is Δx
- **On time axis** i denote node number in t -direction (time)
 - Time between nodes is Δt
- General notation:

$$T_{m,n,k}^i$$



Recalling finite differences from old days 😊


Consider a function f that depends on x . The first derivative is then

defined as the slope of the tangent:

$$\frac{df(x)}{dx} = \lim_{\Delta x \rightarrow 0} \frac{f(x + \Delta x) - f(x)}{\Delta x}$$

- Leaving out the limit, we get an *approximate* solution:

$$\frac{df(x)}{dx} \approx \frac{f(x + \Delta x) - f(x)}{\Delta x}$$




Applying finite differences to our 1D domain

Remember, we are looking for:

$$\frac{\partial^2 T}{\partial x^2}$$

We may approximate first derivative *at midpoints* as:

$$\frac{\partial T}{\partial x} \Big|_{x_{m-1/2}} \approx \frac{T_m - T_{m-1}}{\Delta x} \quad \text{and} \quad \frac{\partial T}{\partial x} \Big|_{x_{m+1/2}} \approx \frac{T_{m+1} - T_m}{\Delta x}$$



... now, we can approximate the second derivative using two first-order derivatives:

$$\frac{\partial^2 T}{\partial x^2} \Big|_{x_m} \approx \frac{\frac{\partial T}{\partial x} \Big|_{x_{m+1/2}} - \frac{\partial T}{\partial x} \Big|_{x_{m-1/2}}}{\Delta x} = \frac{\frac{T_{m+1} - T_m}{\Delta x} - \frac{T_m - T_{m-1}}{\Delta x}}{\Delta x}$$

... which reduces to:


$$\frac{\partial^2 T}{\partial x^2} \Big|_{x_m} \approx \frac{T_{m-1} - 2T_m + T_{m+1}}{\Delta x^2}$$

The equation for *steady one-dimensional heat conduction* now becomes:

$$\frac{T_{m-1} - 2T_m + T_{m+1}}{\Delta x^2} + \frac{\dot{g}}{k} = 0$$

Exercise: Centre temperature in a plate by the finite difference method

Consider a aluminium plate of length $L = 0.5$ cm and thermal conductivity $k = 205 \text{ W}/(\text{m}\cdot\text{K})$ in which no heat is generated ($\dot{g} = 0$). One side of the plate is maintained at 0°C by icy water while the other is maintained at 100°C . Estimate the temperature in the centre at node 1.




Energy balance method for 1D problems

Notation for *1D energy balance* problems

A *1D plane wall* is defined as being infinitely long (i.e. heat transfer only occurs in one direction)

- *Position* is denoted by x
 - $x = 0$ at left side of wall
 - $x = L$ at right side of wall
- *Node number* is denoted by m
 - $m = 1$ at left side of wall
 - $m = M$ at right side of wall
- *Volume elements* with *width* Δx
 - Properties are assumed constant within each volume element
 - The finer the mesh (smaller Δx), the more accurate the solution
- Notation:
 - T_5 : Temperature at $m = 5$
 - ρ_5 : Density at node $m = 5$
 - ...



The energy balance equation for interior nodes

We *sum up heat transfer to/from* volume element:

$$\left(\begin{array}{c} \text{Sum of heat} \\ \text{transfer rate} \\ \text{across surfaces} \\ \text{of volume element} \end{array} \right) + \left(\begin{array}{c} \text{Rate of heat} \\ \text{generation} \\ \text{inside the} \\ \text{element} \end{array} \right) = \left(\begin{array}{c} \text{Rate of change} \\ \text{of the energy} \\ \text{content of} \\ \text{the element} \end{array} \right)$$


- For *steady* heat transfer (no change in time):

$$\sum_{\text{all surfaces}} \dot{Q} + \dot{G}_{\text{element}} = \frac{\Delta E_{\text{element}}}{\Delta t} = 0$$

- \dot{G}_{element} is the heat generation rate in the element (W):


$$\dot{G}_{\text{element}} = \dot{g} V_{\text{element}}$$

- \dot{g} is the volumetric heat generation rate in the element (W/m^3)



Convention for heat transfer direction

Assumed direction of heat transfer is *irrelevant as long as we are consistent*




Energy balance on control volume:

$$kA \frac{T_{m-1} - T_m}{\Delta x} - kA \frac{T_m - T_{m+1}}{\Delta x} + \dot{g}_m A \Delta x = 0$$

Conclusion: In both cases, it reduces to *the same expression*:

$$T_{m-1} - 2T_m + T_{m+1} + \frac{\dot{g}_m \Delta x^2}{kA} = 0$$



Energy balance on control volume:

$$kA \frac{T_{m-1} - T_m}{\Delta x} + kA \frac{T_{m+1} - T_m}{\Delta x} + \dot{g}_m A \Delta x = 0$$

The four boundary condition types

We have to specify **boundary conditions** on each non-internal node.

- *Four common* boundary condition types:

1. *Constant temperature*

$$T_0 = c$$

2. *Constant heat flux*

$$\dot{Q}_{\text{left,surface}} = \dot{q}A = c$$


3. *Convection*

$$\dot{Q}_{\text{left,surface}} = hA(T_{\infty} - T_0) = c$$

4. *Radiation*

$$\dot{Q}_{\text{left,surface}} = \epsilon\sigma A (T_{\text{surr}}^4 - T_0^4) = c$$

- .. or any combination of type 2, 3 and 4



Incorporating the different boundary conditions

Type 1 (constant temperature):

- We simply *set the temperature* of the node, e.g. $T_0 = c$


Type 2-4:

- We apply an *energy balance* on the volume element:

$$\sum_{\text{all surfaces}} \dot{Q} + \dot{G}_{\text{element}} = 0,$$

$$\dot{Q}_{\text{left,surface}} + kA \frac{T_1 - T_0}{\Delta x} + \dot{g}_0 \left(\frac{\Delta x}{2} A \right) = 0.$$


- Expression for $\dot{Q}_{\text{left,surface}}$ depends on boundary condition type



Incorporating mixed boundary condition types

All BC types (**heat flux**, **convection** and **radiation**) can easily be added to form mixed types:

$$\dot{Q}_{\text{left,surface}} = \dot{q}_0 A + hA(T_\infty - T_0) + \epsilon\sigma A(T_{\text{surr}}^4 - T_0^4)$$



Mirror concept for insulated boundaries (e.g zero heat flux)


Insulated boundary (zero heat flux) can be modelled using *mirror nodes*:

- For interior nodes:

$$\frac{T_{m+1} - 2T_m + T_{m-1}}{\Delta x^2} + \frac{\dot{g}}{k} = 0$$

- For insulated boundaries:

$$\frac{T_1 - 2T_0 + T_1}{\Delta x^2} + \frac{\dot{g}}{k} = 0$$




Interfaces between different materials

Starting with the general energy balance:

$$\sum_{\text{all surfaces}} \dot{Q} + \dot{G}_{\text{element}} = 0,$$


- Assuming *perfect contact (no air gaps)* at the interface, the energy balance becomes:

$$k_1 A \frac{T_{m-1} - T_m}{\Delta x_1} + k_2 A \frac{T_{m+1} - T_m}{\Delta x_2} + \dot{g}_A A \Delta \frac{x}{2} + \dot{g}_B A \Delta \frac{x}{2} = 0$$



Exercise: Centre temperature in a plate by the energy balance method

Consider a aluminium plate of length $L = 4\text{ cm}$ and thermal conductivity $k = 28\text{ W}/(\text{m}\cdot\text{K})$ in which heat is generated at a rate $\dot{g} = 5 \cdot 10^6\text{ W/m}^3$. The left side is maintained at 0°C and the right side is exposed to convection with $h = 45\text{ W}/(\text{m}^2\cdot\text{K})$ and ambient temperature of $T_\infty = 30^\circ\text{C}$. Find T_2 .




Energy balance method for 2D (and 3D) problems

Notation for 2D energy balance problems

Double subscripts (m, n) to denote two dimensions (triple for three dimensions)

- m used for x -direction
- n used for y -direction
- Temperature at node ($m = 1, n = 0$) is written $T_{1,0}$
- Distances between nodes are Δx and Δy
- Form volume elements around each node
- Convert from node number to actual coordinates by:
 - $x = m\Delta x$
 - $y = n\Delta y$



The energy balance equation for *interior nodes*

We *sum up heat transfer to/from* volume element:

$$\left(\begin{array}{c} \text{Sum of heat} \\ \text{transfer rate} \\ \text{across surfaces} \\ \text{of volume element} \end{array} \right) + \left(\begin{array}{c} \text{Rate of heat} \\ \text{generation} \\ \text{inside the} \\ \text{element} \end{array} \right) = \left(\begin{array}{c} \text{Rate of change} \\ \text{of the energy} \\ \text{content of} \\ \text{the element} \end{array} \right)$$

- For *steady* heat transfer (no changes in time):


$$\sum_{\text{all surfaces}} \dot{Q} + \dot{G}_{\text{element}} = \frac{\Delta E_{\text{element}}}{\Delta t} = 0$$

- Sum up heat transfer to/from volume element:

$$\dot{Q}_{\text{left,cond}} + \dot{Q}_{\text{right,cond}} + \dot{Q}_{\text{bottom,cond}} + \dot{Q}_{\text{top,cond}} + \dot{G}_{\text{element}} = 0$$

- .. or in terms of node numbers:

$$kA \frac{T_{m-1,n} - T_{m,n}}{\Delta x} + kA \frac{T_{m+1,n} - T_{m,n}}{\Delta x} + kA \frac{T_{m,n-1} - T_{m,n}}{\Delta y} + kA \frac{T_{m,n+1} - T_{m,n}}{\Delta y} + \dot{g}_{m,n}(\Delta x \Delta y) = 0$$



The energy balance equation for *boundary nodes*

We *sum up heat transfer to/from* volume element:

$$\left(\begin{array}{c} \text{Sum of heat} \\ \text{transfer rate} \\ \text{across surfaces} \\ \text{of volume element} \end{array} \right) + \left(\begin{array}{c} \text{Rate of heat} \\ \text{generation} \\ \text{inside the} \\ \text{element} \end{array} \right) = \left(\begin{array}{c} \text{Rate of change} \\ \text{of the energy} \\ \text{content of} \\ \text{the element} \end{array} \right)$$


- For a volume element on the left boundary:

$$\dot{Q}_{\text{left,surface}} + \dot{Q}_{\text{right,cond}} + \dot{Q}_{\text{bottom,cond}} + \dot{Q}_{\text{top,cond}} + \dot{G}_{\text{element}} = 0$$

- .. or in terms of node numbers:

$$\begin{aligned} \dot{Q}_{\text{left surface}} &+ k\Delta y \frac{T_{1,n} - T_{0,n}}{\Delta x} + k \frac{\Delta x}{2} \frac{T_{0,n-1} - T_{0,n}}{\Delta y} \\ &+ k \frac{\Delta x}{2} \frac{T_{0,n+1} - T_{0,n}}{\Delta y} + \dot{g}_{0,n} \left(\frac{\Delta x}{2} \Delta y \right) = 0 \end{aligned}$$



- The expression for $\dot{Q}_{\text{left surface}}$ depends on the type of boundary condition



Handling *irregular* boundaries

Different approaches to irregular boundaries:

- *Baseline*: Approximate the shape using regular grid (stair-step approach)
- Use *smaller* volume elements near the boundary to better approximate the shape
- Use *irregular* boundary volume elements that conform to the shape



Exercise: Steady Two-Dimensional Heat Conduction

Determine the temperature at the 15 nodes. Thermal conductivity is $k = 15 \text{ W/m}\cdot\text{K}$, and heat is generated in the body at a rate of $\dot{q} = 2 \times 10^6 \text{ W/m}^3$. The left surface of the body is insulated, and the bottom surface is maintained at a uniform temperature of 90°C . The entire top surface is subjected to convection to ambient air at $T_\infty = 25^\circ\text{C}$ with a convection coefficient of $h = 80 \text{ W/m}^2\cdot\text{K}$, and the right surface is subjected to heat flux at a uniform rate of $\dot{q}_R = 5000 \text{ W/m}^2$. The nodal network of the problem consists of 15 equally spaced nodes with $\Delta x = \Delta y = 1.2 \text{ cm}$.

