

Maxbotix Test Box

Instructions:

- 1. Plug in Maxbotix sensor to the Pins in the top of thr box
- 2. Hold something above the sensor to see the distance reading on the OLED



Jakob Sperry https://github.com/wpi-rbe-la/maxbotix_test_box