
AZAL SOFT

Water Management Platform

USER MANUAL

A practical guide to managing subscribers, wells, meter readings, consumption, reports, and financial transactions.


https://azalsoftplatform.web.app/



English Edition · Version 1.0

1. Sign in


Open the platform in your browser, then enter your username/email and password and select Sign in. You may use the demo account option when available for evaluation.
https://azalsoftplatform.web.app/



- Use the address above on desktop and mobile; the same account works on both.
- A username without @ is treated as <username>@mywater.com.
- The demo account opens a read-only tour of the platform.
- If the connection is still starting, wait for the notice to clear and press Sign in again.

2. Main dashboard


The dashboard provides access to the platform’s main modules.



- Reading Cycle: record opening and closing meter readings.
- Setup: configure subscribers, wells, usage types, well equipment, and financial accounts.
- Reports: view subscriber account reports and well/cycle consumption reports.
- Inquiry: search and review platform records.
- Payment Voucher and Receipt Voucher: record expenses and payments/collections.

3. Setup – Add a subscriber


Create subscriber records before linking them to a well.



- Choose Setup, then Add subscriber.
- Enter the subscriber number, water usage type, name, phone, address, and other required details.
- Save the subscriber record.

4. Link a subscriber to a well


A subscriber must be linked to the relevant well to participate in its reading cycles.



- Open Add well subscriber.
- Select the village/well and choose the subscriber.
- Tap Add and link the subscriber to complete the association.

5. Reading Cycle

A reading cycle runs from one meter reading to the next for a single subscriber. Open it when the subscriber starts, close it at the end of the period, and the platform bills the difference.
Example: the meter reads 15000 when the subscriber starts and 15200 at the end, so the consumption is 200 m³ and the subscriber is billed for 200 m³ only.



1. Choose the well, then the subscriber on “Select well subscriber” — the subscriber whose cycle you open.

2. In Reading Cycle select Opening reading and photograph the meter: AI extracts the digits and you confirm them. Typing the number manually is still possible.

3. Choose Well equipment — the equipment that runs the well (pump, solar unit, generator); each entry carries its own price.

4. Save: the cycle is now open for that subscriber (15000).

5. At the end of the period select Closing reading for the same subscriber, again by photographing the meter.

6. Consumption = closing – opening (15200 – 15000 = 200 m³), multiplied by the equipment price to give the amount.

7. Closing ends the period and the closing reading becomes the next cycle’s opening: 15200 in, 15200 out. The platform fills it in and rejects any other number, so no water is counted twice or lost between cycles.

6. Current readings and consumption


The current readings screen shows the selected well and its subscriber reading status.



- Select the well and review its open cycles.
- Enter or confirm the closing reading after the service period (for example after one hour or more, according to the local operating process).
- The platform calculates consumption from the difference between closing and opening readings.

7. Reports


Use Reports to monitor subscriber accounts and well consumption.



- Account report: review subscriber balances and financial transactions.
- Cycle report: review meter readings and consumption by cycle/well.
- Energy consumption report: review solar/diesel usage and operating hours, where configured.
- Accounting tree: review assets, liabilities, revenue, and expenses.

8. Receipt Voucher – Collection


Use a receipt voucher when money is received, such as a subscriber payment.



- Select the village and well.
- Choose the subscriber and, if applicable, the related cycle.
- Enter the amount and complete the voucher details.
- Save the voucher. The transaction updates the relevant account balance.

9. Payment Voucher – Expense

Use a payment voucher to record money paid from the well fund.



- Select the village and well fund.
- Choose the debit account/operator or expense category.
- Enter the amount and description.
- Save the voucher to record the expense and update the accounting balance.

10. Recommended operating workflow

Follow this order when a village joins the platform.

- Configure the village, wells, usage types, well equipment, and financial accounts.
- Register each subscriber and link them to the correct well.
- Record opening meter readings at the start of a cycle.
- Record closing readings at the end of the cycle; verify any AI-extracted values.
- Review calculated consumption and close the cycle according to your operating procedure.
- Record collections with Receipt Vouchers and expenses with Payment Vouchers.
- Use Account and Cycle Reports to check balances, transactions, and consumption.
- Important: AI meter recognition is an assistance feature — always verify the displayed digits before saving. Labels and features may vary by account permissions and platform updates.

Appendix – Well agent

The well agent screen gathers, for one well, everything the agent needs in a single place. Open it by tapping the well on the Wells screen.

- Subscribers: how many subscribers are linked to this well, with each one’s last reading, consumption and number of cycles.
- Accounts: the four balances of the well — Sales, Fund (the well cash box), Expenses and Operator.
- Metered water: the consumption already billed from closed cycles, used as the denominator of the loss percentage.
- Loss per cycle: entered manually. Type the loss volume in m³; the percentage is calculated from the metered water if you leave it empty. A note can explain the cause (leak repaired, meter replaced).
- Readings before the platform: add a photo of the old register with its number and date. These entries form the baseline the platform continues from, so the first cycle does not start from zero.
- Pull down to refresh after any change, or use the refresh icon in the app bar.

The loss is manual by design: only the agent knows what happened at the well. Recording it next to the metered water turns an estimate into a number that can be audited.

Platform access

https://azalsoftplatform.web.app/

Open the platform at the address below and sign in with your supervisor or manager account. For new accounts, roles, and permissions, contact your platform administrator.