6.5 How are site-specific default NO_x emission rates determined for an LME unit?

There are three basic sources of information that may be used to determine the site-specific NO_x emission rate(s) for a LME unit. These are:

- Emission testing;
- Historical CEMS data; and
- Previous Appendix E test results