OVERVIEW

The *Trends Tab*, as seen in <u>FIGURE ERROR!</u> No text of specified style in document.-1, provides the enduser with the ability to select historical trend data from predefined trends. The trend pens can be turned on and off, the trend zoomed in and out, and the historical data window can be changed to display older data. The timeline zoom bar, located at the bottom of the pane, allows for selecting the date range.




Figure Error! No text of specified style in document.-1 Trends Tab

To select, or deselect, pen, click on the check box, as seen in <u>Figure Error!</u> No text of specified style in document.-2.




Figure Error! No text of specified style in document.-2 Trend Pens Control