Manual Calibration

In addition to auto-calibration, manual calibration can be performed, as required, on instruments. The difference between the two being that auto-calibration takes care of all calibrations tied to the instrument, where manual calibrations exist for each calibration gas.

To manually calibrate a selected instrument with a selected calibration gas, perform the following.

- 1. Click on the expansion button for the requisite instrument.
- 2. Click on the ellipsis button for the instrument.
- 3. Under the requisite Man CG(x) heading, click on **Start** or **Stop** as required to start or stop the manual calibration.