

## Activating Calibration Gas Cylinders

To activate a calibration gas cylinder, perform the following steps.

- 1. In the **Bottle Inventory** section, on the desired bottle, left-click and hold the mouse button down.
- 2. Drag the bottle into the **QA Outputs** section, and release the mouse button.