UNINSTALL PROCESS

SpectraView® Prism may be uninstalled using "Programs and Features" accessible under the Control Panel as follows.

- 1. Open the Control Panel.
- 2. Select Programs and Features.
- 3. Select the SpectraView® Prism program.
- 4. Click once to highlight the program (The program is highlighted in Figure 2-3.).




Figure **Error! No text of specified style in document.**-1 SpectraView® Prism Client Removal

5. Right click and select **Uninstall**, or select **Uninstall** at the top of the screen.