## **Manual Calibration**

In addition to auto-calibration, manual calibration can be performed, as required, on individual instruments. The difference between the two being that auto-calibration takes care of all calibrations tied to the probe, where manual calibrations exist for each instrument.

To manually calibrate a selected instrument, perform the following.

- 1. Click on the expansion button for the requisite probe.
- 2. Double-click on the requisite instrument's heading.
- 3. Click on the ellipsis button for the requisite calibration for the instrument.
- 4. Under the requisite *Man Cal* heading, click on **Start** or **Stop** as required to start or stop the manual calibration.
- 5. The Instrument view may be closed by double-clicking on the instrument's heading.