Data Sub-Tab

The *Data Sub-Tab* is used to display current compliance data. The parameters will be plant specific. The timed averages will be programed by *Spectrum Systems, Inc.* and will display on the screen, as seen in <u>FIGURE ERROR!</u> No text of specified style in document.-1.




Figure Error! No text of specified style in document.-1 Data Sub-Tab