Instrument Service

The instruments listed on the data lists may be taken in and out of service for maintenance purposes.

To place an instrument in or out of service, perform the following steps.

- 1. Click on the expansion button for the requisite instrument.
- 2. Click on the ellipsis button for the instrument.
- 3. Under the *Instrument Service* heading, click on **Out of Service** or **In Service** as required to place the instrument in or out of service.