OVERVIEW

The I/O Points Tab allows the end-user to observe the data from the system Sources, to include data from the SpectraPak®-E and Modbus devices, etc., as seen in Figure Error! No text of specified style in document.-1. The right side of the I/O Points Tab contains all of the Sources in the system. By selecting one of these sources, the end-user can view all of the I/O points associated with that source.




Figure Error! No text of specified style in document.-1 I/O Points Tab

There are three sub-tabs contained in the *I/O Points Tab*. They are the *Raw Points* sub-tab, the *Sequences* sub-tab, and the *Data Collector Service* sub-tab. An explanation of each follows.