Alarm Configuration

The *Alarm Configuration Tool* in the *Admin Tab* allows for the addition or modification of alarms, including system alarms, compliance alarms, warnings, instrument faults, and other alarms. Initial creation of alarms should be performed by Spectrum Systems, Inc. Changes to Alarms are easy to complete using the existing points. The *Alarm Configuration Tool* consists of two sub-tabs; the *Alarms Sub-Tab*, and the *Outputs Sub-Tab*, as seen in **FIGURE ERROR! No text of specified style in document.**-1.


*Figure **Error! No text of specified style in document.**-1 Alarm Configuration Tool*