## 6.2 What is a low mass emissions (LME) unit?

Low mass emission units are defined in Table 13.

**Table 13. Low Mass Emissions Units** 

A combustion unit may qualify as a low mass emissions, or "LME" unit if it meets the definition of a gas-fired or oil-fired unit in §72.2, and if its SO<sub>2</sub> and/or NO<sub>x</sub> mass emissions meet the following limits: . . . .

Tollowing limits	
For Acid Rain and CAIR SO <sub>2</sub> Program units:	For CAIR NO <sub>x</sub> Program units:
• ≤ 25 tons of SO <sub>2</sub> per year	<ul> <li>≤ 50 tons of NO<sub>x</sub> per ozone season<sup>a</sup></li> </ul>
and	and
• < 100 tons of NO <sub>x</sub> per year	• < 100 tons of NO <sub>x</sub> per year <sup>b</sup>

<sup>&</sup>lt;sup>a</sup> This limit does not apply to CAIR NO<sub>x</sub> units in GA, TX, and MN.

<sup>&</sup>lt;sup>b</sup> This limit does not apply to non-EGUs in CAIR, or to CAIR NO<sub>x</sub> units in MA, CT, and AR.