## **Question 3.11**

**Topic:** Test Method 2H -- Applying the Default Wall Effects Adjustment Factor (WAF)

**Question:** Can I apply the default WAF to data reported by my flow monitor?

Answer: The WAF is applied only to the reference method value obtained by Method 2, 2F, or 2G in the RATA, not to the values reported by the flow monitor. However, immediately before performing this RATA, new parameter values or parameter value adjustments may be programmed into the flow monitor to make the flow monitor readings agree with the selected reference method(s). See Question 3.10 for a more detailed discussion of these adjustments.

**References:** 40 CFR Part 60, Appendix A-2 (RM 2H); 40 CFR Part 75, Appendix B, Sections 2.3.2(b)(1), 2.3.2(b)(2) and 2.3.2(b)(3)

**History:** First published in October 1999 Revised Manual; revised in October 2003 Revised Manual