



UV DTF Sticker Application Instructions

For clean, bubble-controlled application on hard goods

You Need: • UV squeegee • UV DTF sticker • Clean hard-good surface

1

Prep + Pre-Squeegee

Clean the surface when needed with soap and water or a 50/50 rubbing alcohol/water mix. Cut out the sticker, place it face down with the carrier side up, then squeegee firmly back and forth 2-4 passes. Use extra pressure on thin lines or small text.

2

Peel the Backing

Gently separate the sheets while watching the design lift onto the clear carrier. Peel slowly, especially around small separated details. If any part stays behind, lay it back down, re-squeegee from the back, and peel again from a different angle.

3

Place on Item

Line up the design on the hard good. For designs 4 in. or smaller, place with two hands. For designs 6 in. or larger, start at one side and lay it down toward the other side to reduce bubbles and wrinkles.

4

Squeegee + Final Peel

Once placed, squeegee firmly over the whole design 2-4 passes. Peel the carrier slowly while watching every element stick. If anything lifts, lay the carrier back down, squeegee again, and peel from another angle.

!

Important Application Tips

Watch the design, not just your hands. Peel slowly and confirm every detail transfers cleanly. Do not fully press one carrier corner onto the product; leaving a loose corner makes the final peel easier. Thin lines, small text and separated elements need slower peeling plus extra squeegee pressure.

If The Design Does Not Lift or Adhere Properly:

Lay the carrier/backing down, squeegee again with firm pressure, then peel slowly from a different angle.