

OREGON STATE UNIVERSITY CBEE Department of Chemical Engineering

CHE 331
Transport Phenomena1

Dr. Goran Jovanovic

Mechanical Energy Balance Equation Flow Through Fluidized Beds

Please turn-off cell phones



Fluidized Bed Operations

There are two types of Fluidized Bed applications


Fluidized Bed Reactors Fluidized Bed Operations

- 1. Oil Cracking

- 1. Drying of solids
- Coal Burning
 Heat recuperation
- 3. Pyrolysis of FeS 3. Mixing of Particles
- 4. Fuel Synthesis 4. Separation of Particles
- 5. Penicillin Production 5. Coating of Particles
 - 6. Adsorption
 - 7. Cooling of fluids




Fluidized Bed Operations



CHE 331 Fall 2022



Fluidized Bed Operations



Frictional Pressure Drop

Cross Sectional Area of Bed

Volume of Bed


Fraction of Bed Consisting of Solids

Specific Buoyant Weight of Solids

$$\Delta P_{Bed} \times \left(\frac{\pi D_{Bed}^2}{4}\right) = \left(\frac{\pi D_{Bed}^2}{4}\right) \cdot L_{Bed} \times (1 - \varepsilon) \times \left[\left(\rho_{par} - \rho_{flu}\right) \cdot g\right]$$




Fluidized Bed Operations





Fluidized Bed Operations


Consider Ergun Equation at the moment just before the fluidization occurs; i.e. while the bed is still packed bed.



CHE 331 Fall 2022



Fluidized Bed Operations






Fluidized Bed Operations

$$\left\{\Delta P_{friction}A_{t}\right\} = \left\{A_{t}L_{mf}\left(1-\varepsilon_{mf}\right)(\rho_{part}-\rho_{fluid})g\right\} \qquad Eq.2$$

From the MEB equation we can estimate: $\Delta P_{friction}$

$$g\Delta Z + \frac{\Delta \overline{u}^2}{2} + \int_{P_1}^{P_2} \frac{dP}{\rho} + W_{Sout} + \sum F = 0$$

If we assume that: $\Delta P_{bed} < 0.1 P_{average}$



$$g\Delta Z + \frac{\Delta P}{\rho} + \sum F = 0 \implies \sum F = -g\Delta Z - \frac{\Delta P}{\rho}$$



Fluidized Bed Operations

For gas-solid system:
$$\sum F = -g\Delta Z - \frac{\Delta P}{\rho}$$

Now we can substitute Eq.1 and Eq.2 into above equation and obtain:

$$\frac{150(1-\varepsilon_{mf})^{2}\mu u_{mf}L_{mf}}{\varepsilon_{mf}^{3}d_{part}^{2}} + \frac{1.75\rho(1-\varepsilon_{mf})u_{mf}^{2}L_{mf}}{\varepsilon_{mf}^{3}d_{part}} = \left\{L_{mf}\left(1-\varepsilon_{mf}\right)(\rho_{part}-\rho_{fluid})g\right\}$$

$$\frac{150(1-\varepsilon_{mf})}{\varepsilon_{mf}^{3}}\operatorname{Re}_{p,mf} + \frac{1.75}{\varepsilon_{mf}^{3}}\operatorname{Re}_{p,mf}^{2} = \frac{d_{p}^{3}\rho_{f}(\rho_{p}-\rho_{f})g}{\mu^{2}}$$



For predominantly viscous/laminar flow:

$$u_{mf} = \frac{d_p^2 \left(\rho_p - \rho_f\right)}{150\mu} \frac{g \varepsilon_{mf}^3}{1 - \varepsilon_{mf}} \quad \text{for } \text{Re}_{p,mf} < 20$$

For predominantly turbulent flow:

$$u_{mf}^{2} = \frac{d_{p}(\rho_{p} - \rho_{f})}{1.75\rho_{f}} g \varepsilon_{mf}^{3} \quad \text{for } \operatorname{Re}_{p,mf} > 1000$$

And for any Re:

$$\frac{d_p u_{mf} \rho_f}{\mu} = \sqrt{28.7^2 + \frac{0.0494 d_p^3 \rho_f (\rho_p - \rho_f) g}{\mu^2}} - 28.7$$



Fluidized Bed Operations


$$1 = \frac{V_{particles}}{V_{Total}} + \frac{V_{fluid}}{V_{Total}} \Rightarrow 1 = \delta + \varepsilon = (1 - \varepsilon) + \varepsilon$$

$$Voidage = \frac{V_{fluid}}{V_{Total}} = \varepsilon$$
Voidage

It is also true:
$$Voidage = \frac{A_{fluid}}{A_{Total}} = \varepsilon$$



MECHANICAL ENERGY BALANCE EQUATION – Particle Size



$$\begin{vmatrix} x_1 = \frac{w_1}{W}; & x_2 = \frac{w_2}{W}; & x_3 = \frac{w_3}{W}; & x_4 = \frac{w_4}{W} \\ d_{scr·i} = \frac{\text{(upper screen size + lower screen size)}}{2} \\ d_{pi} = d_{scr·i} \times \Phi$$

 $\Rightarrow \overline{d}_p = \frac{1}{\sum_{\text{all size cuts}} \left(\frac{x_i}{d_{pi}}\right)}$

MECHANICAL ENERGY BALANCE EQUATION – Particle Size




Fig. 6.2. Histogram representing the size distribution of particles in a packed bed.

$$\overline{d}_p = \begin{cases} \text{the nominal size of particles which would have the same total} \\ \text{surface area as the size mixture in question - same total bed} \\ \text{volume and same bed voidage in both cases} \end{cases}$$

$$\overline{d}_{p} = \frac{1}{\sum_{\text{all size cuts}} \left(\frac{x_{i}}{d_{pi}}\right)}$$



Tyler Standard Screen Sizes

Mesh number (number of wires/in)	Aperture, µm (opening between adjacent wires)	Mesh number (number of wires/in)	Aperture, µm (opening between adjacent wires)
3	6680	35	417
4	4699	48	295
6	3327	65	208
8	2362	100	147
10	1651	150	104
14	1168	200	74
20	833	325	53
28	589	400	38

Unfortunately there is no general relationship between $d_{\rm scr}$ and d_p . The best we can say for pressure drop considerations in packed beds is

• for irregular particles with no seeming long or shorter dimension take

$$d_p \cong \phi d_{\rm scr} = \phi d_{\rm sph}$$




MECHANICAL ENERGY BALANCE EQUATION – Particle Size

Particle shape	Sphericity φ	
Sphere	1.00	
Cube	0.81	
Cylinder		
h = d	0.87	(Surface of Sphere
h = 5d	0.70	$ \Phi = \frac{\text{Surface of Sprice}}{ \Phi }$
h = 10 d	0.58	$\Phi = \left(\frac{\text{Surface of Sphere}}{\text{Surface of Particle}}\right)$
Disks		
h = d/3	0.76	$\Phi \leq 1$
h = d/6	0.60	$\Psi \leq 1$
h = d/10	0.47	
Old beach sand	As high as 0.8	36
Young river sand	As low as 0.5	3
Average for various types of sand	0.75	
Crushed solids	0.5 - 0.7	
Granular particles	0.7 - 0.8	
Wheat	0.85	
Raschig rings	0.26 - 0.53	
Berl saddles	0.30 - 0.37	
Nickel saddles	0.14	

SAME VOLUME

^aData from Brown (1950), and from geometrical considerations.





The voidage increases as the sphericity decreases for randomly packed beds of uniform particles.



People. Ideas. Innovation.

Thank you for your attention!