

The schematic shows the MPU-6050 chip with its pins connected as follows:

- VDD** (Pin 13) is connected to +3V3.
- GND** (Pin 18) is connected to ground.
- SCL** (Pin 23) is connected to IMU_SCL.
- SDA** (Pin 24) is connected to IMU_SDA.
- AD0** (Pin 9) is connected to ground.
- FSYNC** (Pin 11) is connected to ground.
- NC** (Pins 2, 4, 5, 7, 14, 15, 16, 17, 19, 20, 21, 27) are connected to ground.
- CLKIN** (Pin 1) is connected to ground.
- CLKOUT** (Pin 22) is connected to ground.
- AUX_CL** (Pin 7) is connected to ground.
- AUX_DA** (Pin 6) is connected to ground.
- RESV** (Pin 19) is connected to ground.
- INT** (Pin 12) is connected to IMU_INT.
- CPOUT** (Pin 20) is connected to IMU_CPOUT.
- VLOGIC REGOUT** (Pin 10) is connected to IMU_REGOUT.
- EP** (Pin 25) is connected to ground.

Capacitors C15, C16, C17, and C18 are used for decoupling at VDD, IMU_REGOUT, IMU_CPOUT, and IMU_INT respectively.

Title <i>STM32F4 Mixed-Signal Interface Board</i>			
Size A3	Number	Revision	
Date: 6/22/2026	File: D:\Users\...\STM32F4_Mixed-Signal_Interfaces\Board	Sheet of 2	Drawn by SchDoe