CodeGenerator v1.0 For Development Testing

CM Wu

2023/11/10

How to add a new Chip Series?

- Chip Name should use uppercase, EX: M2003C
  - Step 1: 在content-web-define.js的g_chipTypes新增 “M2003C”
  - Step 2: 在PeripheralConfigure資料夾底下新增 “NUC_M2003C_Content.js”

How to add a new Part No.?

- 在對應的NUC_XXX_Content.js 新增, EX: M2003XC1AE
  - Step 1: 在NUC_M2003C_Content.js的 NUTOOL_PER.g_cfg_chips 加入M2003XC1AE

```
// chip content
NUTOOL_PER.g_cfg_chips = [
    { name: "M2003FC1AE", pkg: "TSSOP20" },
    // { name: "M2003FC1AE", pkg: "QFN20" },
    { name: "M2003XC1AE", pkg: "QFN20" }
    // { name: "M2003FC1BE", pkg: "QFN20" },

    // { name: "M2003EC1AE", pkg: "TSSOP28" },
    // { name: "M2003PC1AE", pkg: "LQFP32 32K" },
    // { name: "M2003PE3AE", pkg: "LQFP32 128K" },

    // { name: "M2003TC1AE", pkg: "QFN33 32K" },
    // { name: "M2003TE3AE", pkg: "QFN33 128K" },
    // { name: "M2003LE3AE", pkg: "LQFP48" },
    // { name: "M2003SE3AE", pkg: "LQFP64" },
];
```

How to add a new Peripheral Function? (1/2)

- 新增對應的txt檔. EX: M2003C FMC
  - Step 1: 新增PeripheralConfigure/M2003C 資料夾.
  - Step 2: 在M2003C 裡面新增 FMC.txt
  - Step 3: 在NUC_M2003C_Content.js的NUTOOL_PER.g_cfg_perFunctions新增 FMC.txt



How to add a new Peripheral Function? (2/2)

- 若txt的檔名有底線(_)，會將底線前的名字視作第一層，
  然後底線後的會顯示在第二層。目前僅支援兩層樹狀圖結構。

```
NUTOOL_PER.g_cfg_perFunctions = [
    ...
    'PDMA_CH0.txt',
    'PDMA_CH1.txt',
    'PDMA_CH2.txt',
    'PDMA_CH3.txt',
    'PDMA_CH4.txt',
    'PDMA_CH5.txt',
    'PDMA_CH6.txt',
    'PDMA_CH7.txt',
    ...
];
```



Advanced Control of Peripheral Function(1/3)

- 定義在對應的NUC_XXX_Content.js
  - NUTOOL_PER.g_cfg_unusedPerFunctions: {“type or name”: [Unused peripheral]}

```
// chip content
NUTOOL_PER.g_cfg_chips = [
    //M251
    //{ name: "M251FB2AE", pkg: "TSSOP20", type: "M252_C" },
    { name: "M251FC2AE", pkg: "TSSOP20", type: "M252_C" },
    //{ name: "M251EB2AE", pkg: "TSSOP28", type: "M252_C" },
    { name: "M251EC2AE", pkg: "TSSOP28", type: "M252_C" },
    //{ name: "M251ZB2AE", pkg: "QFN33",  type: "M252_C" },
    { name: "M251ZC2AE", pkg: "QFN33",  type: "M252_C" },
```

```
NUTOOL_PER.g_cfg_unusedPerFunctions = {
    //M251/2
    "M252_G":{"SUBSTRING":["DAC1","LCD","TK","UART3","CRYPTO"]},
    "M252_E":{"SUBSTRING":["DAC0","DAC1","OPA","LCD","TK","UART3","CRYPTO"]},
    "M252_D":{"SUBSTRING":["DAC0","DAC1","OPA","PDMA_CH5","PDMA_CH6","PDMA_CH7","EBI","GPIO_PE","USCI2_
    "M252_C":{"SUBSTRING":["DAC0","DAC1","OPA","ACMP","UART2","PDMA_CH5","PDMA_CH6","PDMA_CH7","PSIO","
```

```
"M251FB2AE": {"SUBSTRING": ["USBD"]},
"M251FC2AE": {"SUBSTRING": ["USBD"]},
```

Advanced Control of Peripheral Function(2/3)

- NUTOOL_PER.g_cfg_perFuncMutex: 互斥, 將多選的方框變成單選的原框.
  EX: `NUTOOL_PER.g_cfg_perFuncMutex = ["USCI0", "USCI1", "USCI2"];`



Advanced Control of Peripheral Function(3/3)

- NUTOOL_PER.g_cfg_downloadBSP: Download BSP information as below

```
NUTOOL_PER.g_cfg_downloadBSP = {
    repository: "M251BSP",
    commitID: {
        "V0.41.0006": "0a9ce54018361897633fd328f680ac8734dfdc61"
    }
```



Txt Tag Syntax(1/7)

1. id: must be unique.
2. type: determines the type of UI.
3. label: determines the description text shown around the UI.
4. data: stores the current value of UI.
5. default: stores the default value of UI.
6. helper: determines the helper text following UI.
7. enum :determines the option data array.
8. optionLabels: determines the option label array which should corresponds to enum.

Txt Tag Syntax(2/7)

9. maximum: determines the maximum input value.
10. minimum: determines the minimum input value.
11. group: determines the title text following UI.
12. filterExp: built-in conditions.
    - EX: GPIO pins have built-in condition called Px_dotx.
    - EX: In NUC_MXXX_Content.js, type is defined in NUTOOL_PER.g_cfg_chips.

```
                                        groupId:Group15;
                                        filterExp:PD_dot15==1;!>
#endif //(NUCODEGEN_GPIO_PD_PIN15_MODE == NUCODEGEN_GPIO_PD_MODE_OPEN_DRAIN)
#endif //NUCODEGEN_GPIO_PD_PIN15_EN

#define NUCODEGEN_GPIO_PD_CLR_DB_ICLKON     <!id:GPIOPDCLRDBICLKONCheckboxBoolean;
                                        type:checkboxBoolean;
                                        label:Clear GPIO_PD de-bounce circuit interrupt clock on;
                                        data:false;
                                        default:false;
                                        enum:[true];
                                        optionLabels:[<br>];
                                        dependencies:none;
                                        dependenciesOption:none;
                                        groupId:Group;
                                        groupName:GPIO PD common configuration;
                                        filterExp:type!="M252_C";!>
```

Txt Tag Syntax(3/7)

(UI renders only when data of another UI meets some kind of conditions.)

13. dependencies: determines the id of dependent UI.
14. dependenciesOption: determines the expression.
    EX: dependencies supports bitwise operation has Boolean or (|), Boolean and (&) and Boolean not (!).

```
67  <!id:BPWM0CH1UNITTIMEInteger;
68  type:integer;
69  label:The BPWM0 CH1 unit time of counter(nano sec);
70  data:80;
71  default:10000;
72  helper:Enter unit time of counter(MAX is).;
73  sort:false;
74  minimum:0;
75  maximum:20000;
76  dependencies:(UseADCCMP0Boolean|!ADCOperationModeSelect)&BPWM0SSRCRadio;
77  dependenciesOption:{
78  ⟶"UseADCCMP0Boolean":·"1",·
79  ⟶"ADCOperationModeSelect":·"ADC_OPERATION_MODE_SINGLE",·
80  ⟶"BPWM0SSRCRadio":·"BPWM_SSCTL_SSRC_PWM0"};
```

Txt Tag Syntax(4/7)

Example: dependenciesOption supports Greater than, Equal to, and Less than

```
<!id:CLK_HxtFrequencyDetectorIntCheckbox;
type:checkbox;
label:;
data:0;
default:0;
helper:;
sort:false;
enum:[1];
optionLabels:[Enable Hxt Frequency Detector Interrupt];
vertical:true;
dependencies:CLK_HxtFrequencyUpperBoundInteger;
dependenciesOption:>512;!>

#define ADC_CMP0_CHANNEL     <!id:ADCCmp0ChannelSelect;
dependencies:CLK_HxtFrequencyUpperBoundInteger;
dependenciesOption:==512;
!>


#define ADC_CMP0_CONDITION   <!id:ADCCmp0ConditionSelect;
dependencies:CLK_HxtFrequencyUpperBoundInteger;
dependenciesOption:<512
!>
```

Txt Tag Syntax(5/7)

Example: dependenciesOption supports bitwise operation (|) (&) (!) and.

```
<!id:UART1EnableINTCheckbox;type:checkbox;label:Enable Interrupts We Want for UART1;
data:0;
enum:[UART_INTEN_RDAIEN_Msk, UART_INTEN_THREIEN_Msk, UART_INTEN_RLSIEN_Msk, UART_INTEN_MODE

<!id:UART0BaudrateRadio;type:radio;label:UART0 Baud Rate;data:38400;helper:Select your UART
dependencies:UART1EnableINTCheckbox;
dependenciesOption:[UART_INTEN_RDAIEN_Msk,UART_INTEN_THREIEN_Msk];!>

<!id:i2c0_wakeup_en; type:checkbox;
label:Enable I2C0 wakeup function;
data:0; default:0; helper:Enable I2C0 wake-up function;
sort:false; enum:[1];
optionLabels:[Enable I2C0 wakeup function];
dependencies:UART1EnableINTCheckbox;
dependenciesOption:UART_INTEN_RDAIEN_Msk|UART_INTEN_THREIEN_Msk;!>

<!id:i2c_submode_select;
type:radio;
label:Select I2C0 FunctionMode;
data:I2C0_SUBMODE_SMBUS;
default:I2C0_SUBMODE_NORMAL;
enum:[I2C0_SUBMODE_NORMAL, I2C0_SUBMODE_SMBUS];
optionLabels:[Normal, SMBUS];
dependencies:UART1EnableINTCheckbox;
dependenciesOption:(UART_INTEN_RDAIEN_Msk|UART_INTEN_THREIEN_Msk)&UART_INTEN_RLSIEN_Msk;!>
```

Txt Tag Syntax(6/7)

Example: Support multi conditions.

```
<!id:UART0RS485WakeupCheckbox;
type:checkbox;
label:;
data:0;
default:0;
enum:[1];
optionLabels:[Enable RS-485 Address Match (AAD Mode) Wake-up];
dependencies:[UART0ADDRDENCheckbox, UART0RS485CTLRadio];
dependenciesOption:{"UART0ADDRDENCheckbox": "UART_ALTCTL_ADDRDEN_Msk",
                    "UART0RS485CTLRadio": "UART_ALTCTL_RS485AAD_Msk"};!>
```

Txt Tag Syntax(7/7)

- Each field name (e.g. optionLabels) of tag is fixed and case sensitive
- Each field should end with semicolon
- If the value of field is array, it should be enclosed in brackets.
- If field is unused, the input should be none.
- The start and end symbols of tags are <! and !>, and the content in the middle is free to edit.

Functional Tests

- Purpose

  Run functional tests to ensure the correctness of .txt files and generated code.

- Flow



Functional Tests - parsingexcel.exe

- 解析 TagReg Mapping Table.xlsx, 產生 test_database.txt
- external.parsingexcel(chipType, peripherals)
  - chipType : <String> “M251”/”M031”/…
    => Determines chipType, default is GUI selected.
  - peripherals: <String> “all”/”CRC”/”CRC FMC”/…
    => Determines peripherals, default is “all”.

PS: This function require “XXX TagReg Mapping Table.xlsx”



Functional Tests – headerGenerator.exe

- 根據選擇的條件, 產生對應的header files
- external.headerGenerator(partNo, peripherals, tagId)
  - partNo: <String> “M251EC2AE”/…
    => Determines part No., default is GUI selected.
  - Peripherals: <String> “CRC”/“FMC+WWDT”/”All”/…
    => Determines peripherals, default is GUI selected.
  - tagId: <String> "CLK_HXT_FailDetectorRadio"/” WWDT_PrescalerSelect“/…
    => Determines id in related txt file, default is null.

Functional Tests – basic_test.exe

- 測試result底下的header file, 是否與test_database.txt 一致
- external.basic_test(mode, chipType)
  - mode: <String> “-keil”/”-keil+download”/”-iar”/”-gcc”/”-all”
    => Run basic_test.exe with this this value, default=“-keil”.
  - chipType : <String> “M251”/”M031”/…
    => Determines chipType, default is GUI selected.

PS: This function require related application(Keil / Iar / Gcc).

Functional Tests – Execute All

- Execute parsingexcel.exe + headerGenerator.exe + basic_test.exe
- external.execAllFunctionalTests(chipType, partNo, peripherals, mode)
  - chipType : <String> “M251”/”M031”/…
    => Determines chipType, default is GUI selected.
  - partNo: <String> “M251EC2AE”/…
    => Determines part No., default is GUI selected.
  - Peripherals: <String> “CRC”/“FMC+WWDT”/”All”/…
    => Determines peripherals, default is GUI selected.
  - mode: <String> “-keil”/”-keil+download”/”-iar”/”-gcc”/”-all”
    => Run basic_test.exe with this this value, default=“-keil”.

Functional Tests

- Usage

  Step 1: Open CodeGenerator v1.0.

  Step 2: Select items which want to test. EX: M251 -> M251EC2AE -> CRC+FMC

  Step 3: Download related BSP, move to correct path and rename it.



Functional Tests

Step 4: Press keys Ctrl + Shift + I, launch Developer Tools, click Console tab.



Functional Tests

Step 5: Input external.parsingexcel().



Functional Tests

Step 6: Input external.headerGenerator().



Functional Tests

Step 7: Input external.basic_test().



Functional Tests

Note 1: Input external.execAllFunctionalTests() instead of Step 5 + Step 6 + Step 7



Functional Tests

Note 2: Input external.autoTestHelper() can get **the latest usage**.