

Build and Debug Environment Setup – IAR

This document illustrates how to build Realtek low power Wi-Fi software under IAR SDK environment.



Table of Contents

1.	Introduction	.3
2.	How to get IAR	.3
	How to build and download code	
4.	How to debug	.6



1. Introduction

This document illustrates how to build Realtek low power Wi-Fi software under IAR SDK environment.


2. How to get IAR

IAR provides an IDE environment for code building, downloading, and debugging. Please check "IAR Embedded Workbench" on http://www.iar.com/, and trail version is available.

3. How to build and download code

Step 1: Open IAR Workbench

Step 2: To open project, click File → Open → Workspace




2014-03-21



REALTEK

Step 3: Select Project.eww in project\project_name_xxxx\EWARM-RELEASE


Step 4: To build project, click Project → Rebuild All



2014-03-21 4



Step 5: To download code, Click Project \rightarrow Download \rightarrow Download active application.




2014-03-21 5



4. How to debug

To debug or trace code step by step, click Project \rightarrow Download and Debug / Debug without Downloading.



2014-03-21 6