

STANDARD OPERATING PROCEDURE FOR ROLL SETTING

- Relevant PPE's such as hand gloves, safety helmets, and safety shoes are to be used.
- Check whether there is a play in arbors.
- If play is found inform Superiors/Maintenance department and start setting, only after play is rectified.
- Shift the Cassettes by EOT crane using chain/wire rope.
- Before lifting check the stand hooks of the Cassettes.
- Set the drive end spacer as per layout drawings.
- Adjust the spacers and sim on the arbor, to get rolls as per setting layout.
- Tightly fix the key bar at arbor for cassettes.
- Use wire rope to lift the cassettes while placing the cassettes out to the machine
- Set the cassettes pass wise as per lay out drawings.
- Use EOT cranes to place the arbor on the tail stand and choke should be tighten & check / nut bolts.
- Check the cassettes alignment with thread line.
- Check the sheet gap with feeler gauge.
- After setting done, lead end of the sheet is passed to check the quality parameters in the formed profiles.
- At shearing point, check the section cutoff, deflections up and down.
- If any deviations found check the cassettes gap and sheet gap with feeler gauge and cassettes alignment using thread line.