

STANDARD OPERATING PROCEDURE OF PRESS BRAKE

- Relevant PPE's such as hand gloves, safety helmets, and safety shoes are to be used.
- Identify profile sheets with the help of the route card.
- Keep the required material at the press with the help of EOT crane
- Before starting the press check for loose of any clamps of the tool.
- Select the Die and Punch tool according to required shape of the job.
- Check for working of press photo safety guards.
- Check for emergency stopper button working.
- Check for two hand push button operation.
- Check for an abnormal noise in the press.
- Load the component on locater properly.
- Set the blank on the blank holder and touch to the stopper pins on the lower die.
- Operate the machine from control desk and press both the both push buttons at a same time.
- If all parameters are "ok" then start the production.
- Note down the details in production report.
- After completion of the production switch off the machine.