

STANDARD OPERATING PROCEDURE for ETP and RO

- Use personnel protective equipment's such as Safety helmet, safety shoes, cotton gloves (operators), pvc gloves (sludge handling) and pvc aprons.
- Collect the contamination/effluent water from STP/SCP/Hot dip galvanization and store in collection tank.
- Above water transfer into neutralization tank and neutralize the collected effluent water in neutralization tank by adding sufficient quantity of caustic lye.
- Use spent acid (lime powder) for neutralize the low Total Dissolved Solids (TDS) effluent.
- After neutralization of low TDS transfer through filter press.
- After completion of filter press activity collect the sludge in solid form and shift into the elevated platform.
- Filter press out let water passing through tube settler into RO feed tank.
- Start the RO operation with the RO feed tank water.
- Before store the RO product water check water Ph, low TDS and ensure as per the standards.
- Product water should be collect in storage RO water tank and stored RO product water feed to SCP operation.
- RO reject water again feed into second RO operation.
- Second RO product should store in RO water storage tank
- High Total Dissolved Solids water pass through filter press.
- Collected sludge cake from filter press stored at elevated platform.
- Evaporate the collected high TDS alkaline after from ETP.
- After evaporation feed water use as cooling tower makeup water and collected sludge from ATFD send to Ramkey or TSDF.