

STANDARD OPERATING PROCEDURE (SOP) for Lorry

Loading and Unloading

- Ensure before starting the work use Safety Helmet, Safety Shoe, Cotton Hand Gloves.
- Park on Firm and Level Ground.
- Ensure before loading the Truck / Lorry side poles as per the Height must be Arranged.
- Check the web slings which is being used for loading of truck.
- While lifting the lots for loading in to the truck the lots should be balanced uniformly.
- While loading the different thickness materials, small thickness materials should be loaded on top.
- While loading trucks, ensure all the lots are secured with binding straps and properly loaded to avoid shifting while being transported. Use healthy web slings to guard against shifting.
- Use the Packing materials below the Bundles, while placing on the Truck.
- Remove the web slings from the lot after the loading person steps down from the truck.
 - After Truck loading tie the materials with Rope / Chain. After checking properly tied, then give the clearance for the Vehicle movement.