

STANDARD OPERATING PROCEDURE FOR MATERIAL HANDLING WITH CHAIN SLING

- ❖ Only authorized crane operators to be operate.
- ❖ Crane operator should have special dress code (i.e. Red Helmet & Reflective jacket).
- ❖ Inspect all the lifting accessories (Chains, web slings, crane wire rope etc.) before each lifting for this worthier to high load with these.
- ❖ Use lifting chain equipment only for its intended purpose. Cranes and lifts are rated for the maximum loads they can carry safely, and these ratings should be posted on the equipment where they can be seen.
- ❖ Chains should be used by its capacity and it should be inspected before each lift.
- ❖ Chain slings should never be overloaded, because doing so can either directly cause an accident or damage the equipment so that it is no longer safe.
- ❖ Keep work spaces clear. The worker space should be clear of items that could accidentally be struck and knocked over. Similarly, workers should stay out of the area where cranes or lifts are operating unless they are directly involved in the work being performed.
- ❖ Know the weight of the load and select a proper lifting tool with a Safe Working Load (SWL) that is 50% to 100% higher than the load weight.
- ❖ Knots must be removed from the chain slings before used for lifting.
- ❖ Do not make lifts beyond the rated load capacity of the crane, sling chains etc.