

STANDARD OPERATING PROCEDURE for RAW MATERIAL STORAGE FOR HR COILS

- **PPE:** Relevant PPE's such as Red helmet, safety shoes & Reflective jacket are used for crane operator and helper used cotton hand gloves, yellow helmet and safety shoes.

Storage facility management

1. Store coils securely:

- Store HR coils properly in the designated coil storage area, ensuring they are placed securely and safely to avoid movement or falling.
- **Lifting equipment/slings capacity:** Use 25 percent higher capacity of EOT crane and lifting chains than the lifting material.
- **Authorised Crane Operator:** Crane operator should be trained and authorise and before lifting material should ensure the safe condition of capacity of crane, material and lifting chains and hook.
- Coils or HR coils never store closely to the building walls or machinery, walkways the at least one feet distance.
- All HR coils should be store without slide or slope to prevent sliding
- Use wooden spacers between stacked coils to prevent roll of the coil.
- Provide the wooden stopper for vehicle tyres to prevent movement of vehicle and apply the hand brake of vehicle while loading and unloading time.
- High width surface coils or plates should be bottom and low width coils or plates comes to top during stacking.